

[Manuals.plus](#) /

› [Lorell](#) /

› Lorell Serenity Series Executive Multifunction High-Back Chair Model 59529 User Manual

## Lorell 59529

# Lorell Serenity Series Executive Multifunction High-Back Chair

Model: 59529

### IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.


- **Weight Capacity:** Do not exceed the maximum weight capacity of 275 pounds (125 kg). Exceeding this limit may cause damage to the chair or result in personal injury.
- **Assembly:** Ensure all components are properly assembled and tightened according to the instructions. Improper assembly can lead to instability and potential injury.
- **Adjustments:** Use all adjustable features, such as seat height, arm height, and tilt mechanism, safely and as intended. Avoid sudden movements or excessive force when adjusting.
- **Stability:** Always maintain proper balance when sitting in the chair. Avoid standing on the chair or using it as a step stool.
- **Children:** Keep children away from the assembly area. Small parts may pose a choking hazard.

### PRODUCT OVERVIEW

The Lorell Serenity Series Executive Multifunction High-Back Chair is designed for ergonomic comfort and support during extended periods of sitting. It features durable leather upholstery and a range of adjustable functions to customize your seating experience.

#### Key Features:

- Ergonomically designed for seating comfort.
- Lumbar support that adapts to various sitting positions.
- Unique synchro-slide mechanism for synchronized back and seat movement.
- Adjustable arms for height, pivot, and width.
- Stylish and durable leather upholstery.



**Figure 1:** Front view of the Lorell Serenity Series Executive Multifunction High-Back Chair, showcasing its design and high backrest.





**Figure 2:** Side view of the chair, highlighting the armrests and the base with casters.

## SETUP AND ASSEMBLY

The Lorell Serenity Series chair requires assembly. The process involves attaching the backrest, seat, arms, and base components. Please ensure all parts are present before beginning assembly. A Phillips head screwdriver may be required (not included).

### General Assembly Steps:

1. Unpack all components and verify against the parts list (typically found in the included assembly guide).
2. Assemble the chair base by inserting the casters into the star base.
3. Insert the gas lift cylinder into the center of the assembled base.
4. Attach the seat mechanism to the underside of the seat cushion using the provided screws.
5. Mount the backrest to the seat mechanism or seat frame, securing it with screws.
6. Attach the armrests to the seat or backrest according to the specific design, ensuring they are firmly secured.

7. Place the assembled seat and backrest onto the gas lift cylinder.
8. Test all functions and ensure all connections are secure before use.

Refer to the detailed assembly instructions provided in the product packaging for step-by-step diagrams and specific hardware information.

## OPERATING INSTRUCTIONS

The Lorell Serenity Series chair offers multiple adjustments to optimize your comfort and support.

### 1. Seat Height Adjustment:

To adjust the seat height, locate the lever typically found on the right side beneath the seat. While seated, lift the lever to lower the seat. To raise the seat, lift the lever while taking your weight off the seat. Release the lever at the desired height.

### 2. Arm Adjustments (Height, Pivot, Width):

The armrests can be adjusted for height, pivot, and width. A control button is hidden under the arm pad for these adjustments.

- **Height:** Press the button located on the side or underside of the armrest support and slide the armrest up or down to the desired height. Release the button to lock.
- **Pivot:** Some arm pads can pivot inward or outward. Gently twist the arm pad to achieve the desired angle.
- **Width:** The armrests can be adjusted in width. This adjustment typically involves a lever or knob located beneath the seat or on the armrest support. Adjust to provide comfortable clearance.

### 3. Lumbar Support Adjustment:

The chair features dynamic lumbar support that moves with you. No manual adjustment is typically required for this feature, as it is designed to adapt automatically to provide continuous support to your lower back.

### 4. Tilt Mechanism (Back and Seat Synchronization, Tilt Angle, Locking Positions):

The unique synchro-slide mechanism synchronizes the movement of the back and seat, allowing for a comfortable recline. The chair offers a larger back tilt angle up to 35 degrees and five locking positions with 7 degrees of adjustment for each.

- **Tilt Tension:** A knob, usually located under the front of the seat, controls the resistance of the tilt. Turn clockwise to increase tension (harder to recline) and counter-clockwise to decrease tension (easier to recline).
- **Tilt Lock:** A lever, often on the left side beneath the seat, allows you to lock the chair in one of the five desired tilt positions. Push the lever in to lock the tilt, and pull it out to allow free tilting.
- **Synchro-Tilt:** This mechanism ensures that as the backrest reclines, the seat also tilts slightly, maintaining an open hip angle for improved circulation and comfort.

## MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Lorell Serenity Series chair.

- **Cleaning:** For the leather upholstery, spot clean only. Use a soft, damp cloth with a mild soap solution for spills or stains. Avoid harsh chemicals, abrasive cleaners, or excessive moisture. Test any cleaning solution on an inconspicuous area first.
- **Regular Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and safety.

- **Casters:** Keep casters clean from debris (hair, dust, etc.) to ensure smooth movement.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause leather to fade or crack.

### TROUBLESHOOTING

This section addresses common issues you might encounter with your office chair.

- **Chair Sinks or Does Not Hold Height:** This typically indicates an issue with the gas lift cylinder. Ensure the height adjustment lever is not stuck in the 'up' position. If the problem persists, the gas lift may need replacement.
- **Chair Wobbles or is Unstable:** Check all assembly bolts and screws, especially those connecting the seat to the mechanism and the base. Tighten any loose fasteners. Ensure the casters are fully inserted into the base.
- **Casters Do Not Roll Smoothly:** Inspect casters for accumulated dirt, hair, or debris. Clean them thoroughly. If they are damaged, they may need replacement.
- **Squeaking Noises:** Squeaking can often be resolved by tightening loose bolts. A small amount of silicone-based lubricant applied to moving parts (like the tilt mechanism or gas lift connections) can also help, but avoid applying to the gas lift shaft directly.
- **Tilt Mechanism Not Working:** Ensure the tilt lock lever is disengaged. Check the tilt tension knob; if it's too tight, it may feel like the tilt is not working. Adjust the tension to a comfortable level.

If you encounter issues not listed here or if troubleshooting steps do not resolve the problem, please contact customer support.

### SPECIFICATIONS

Detailed specifications for the Lorell Serenity Series Executive Multifunction High-Back Chair, Model 59529.



**Figure 3:** Detailed dimensional drawing of the chair, showing various measurements.

| Feature                        | Detail                                     |
|--------------------------------|--------------------------------------------|
| Brand                          | Lorell                                     |
| Model Name                     | Serenity                                   |
| Item Model Number              | 59529                                      |
| Color                          | Black                                      |
| Material                       | Leather (Upholstery), Foam (Fill Material) |
| Product Dimensions (D x W x H) | 23.3"D x 25.3"W x 40.5"H                   |
| Item Weight                    | 56 pounds (25.4 kg)                        |
| Maximum Weight Recommendation  | 275 Pounds (125 kg)                        |
| Back Style                     | High Back                                  |

| Feature                  | Detail                        |
|--------------------------|-------------------------------|
| Arm Style                | With arms (Adjustable)        |
| Seat Height              | Adjustable, up to 20.5 Inches |
| Seat Depth               | 18.8 inches                   |
| Chair Backrest Width     | 18.8 Inches                   |
| Reclining Position Count | At least 5                    |
| Recommended Uses         | Office                        |
| Surface Recommendation   | Hard Floor                    |
| UPC                      | 035255595292                  |

### WARRANTY INFORMATION

For specific warranty details regarding your Lorell Serenity Series Executive Multifunction High-Back Chair, please refer to the warranty card included with your product packaging or contact Lorell customer service directly. Warranty terms typically cover manufacturing defects and material flaws for a specified period from the date of purchase.

### SUPPORT

If you require further assistance, have questions about assembly, operation, or need to report a problem, please contact Lorell customer support.

- **Manufacturer:** Lorell
- **Website:** Visit the official Lorell website for support resources and contact information.
- **Retailer Support:** You may also contact the retailer from whom you purchased the chair for assistance.