

Manuals.plus /

› ACCUTIME /

› ACCUTIME XOXO Women's XO5846 Analog Display Analog Quartz Gold Watch User Manual

## ACCUTIME XO5846

# ACCUTIME XOXO Women's XO5846 Analog Display Analog Quartz Gold Watch User Manual

Model: XO5846 | Brand: ACCUTIME

## 1. INTRODUCTION

---

Welcome to the user manual for your new ACCUTIME XOXO Women's Analog Display Analog Quartz Gold Watch, model XO5846. This guide provides essential information on how to set up, operate, maintain, and troubleshoot your watch to ensure its longevity and accurate performance. Please read this manual carefully before using your watch.

## 2. SAFETY INFORMATION

---

To ensure safe and proper use of your watch, please observe the following precautions:

- **Not Water Resistant:** This watch is **not water resistant**. Avoid exposure to water, moisture, rain, or submersion. Water damage is not covered under warranty.
- **Battery Safety:** The watch contains a small battery. Keep out of reach of small children. If swallowed, seek immediate medical attention.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) as this can affect battery life and watch performance.
- **Chemicals:** Do not expose the watch to solvents, detergents, perfumes, or cosmetic sprays, as they may damage the case, band, or internal components.
- **Impact:** Protect the watch from strong impacts or shocks, which can damage the movement or crystal.

## 3. PRODUCT OVERVIEW

---

The ACCUTIME XOXO Women's XO5846 watch features a classic analog display with a quartz movement, housed in a rose gold-tone case with a matching alloy band. The bezel is adorned with faceted rounds, complementing the sunray dial with Arabic numeral indices.







**Figure 3.1:** Front view of the ACCUTIME XOXO Women's XO5846 Gold Watch. This image displays the rose gold-tone watch with its sunray dial, Arabic numeral indices, and the crystal-studded bezel.



**Figure 3.2:** The ACCUTIME XOXO Women's XO5846 Gold Watch as worn on a wrist, demonstrating its size and appearance in use.

## 4. SETUP

---

### 4.1 Initial Setup

1. **Unboxing:** Carefully remove the watch from its packaging. Ensure all protective films and tags are removed from the watch face, case back, and band.
2. **Crown Position:** The watch may arrive with the crown (the small knob on the side) pulled out to save battery life. Push the crown in towards the watch case to start the movement.

### 4.2 Setting the Time

1. **Pull the Crown:** Gently pull the crown out to the first click position. The second hand will stop.
2. **Adjust Time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
3. **Push the Crown In:** Once the correct time is set, push the crown back in fully towards the watch case. The second hand will resume movement.

## 5. OPERATING YOUR WATCH

---

Your ACCUTIME XOXO watch is designed for simple, reliable timekeeping. Once the time is set, the quartz movement will maintain accurate time.

- **Wearing the Watch:** Adjust the fold-over clasp on the alloy band to comfortably fit your wrist. If the band is too loose or too tight, it may require professional adjustment to remove or add links.
- **Daily Use:** The watch is intended for daily wear. However, due to its non-water-resistant nature, it should be removed before washing hands, showering, swimming, or any activity involving water.

## 6. CARE AND MAINTENANCE

---

Proper care will help preserve the appearance and functionality of your watch.

- **Cleaning:** Wipe the watch case and band regularly with a soft, dry cloth to remove dust, dirt, and oils. Do not use chemical cleaners or abrasive materials.
- **Storage:** When not in use, store your watch in a dry place, away from direct sunlight and extreme temperatures. The original watch box is ideal for storage.
- **Battery Replacement:** The watch is powered by a product-specific battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to avoid damaging the movement or compromising the case seal.
- **Band Adjustment:** For band adjustments (adding or removing links), it is recommended to visit a professional jeweler or watch repair service.





**Figure 6.1:** The ACCUTIME XOXO Women's XO5846 Gold Watch stored within its original black presentation box, ideal for protection and storage.

## 7. TROUBLESHOOTING

---


If you encounter any issues with your watch, please refer to the following common problems and their solutions:

Problem	Possible Cause	Solution
Watch is not running.	Crown is pulled out; battery is depleted.	Push the crown fully in. If it still doesn't run, the battery may need replacement by a professional.
Time is inaccurate.	Time was not set correctly; watch experienced a shock.	Re-set the time following the instructions in Section 4.2. If the issue persists, professional inspection may be required.
Condensation under the crystal.	Exposure to moisture or extreme temperature changes.	This watch is not water resistant. Avoid all contact with water. If condensation appears, seek professional service immediately to prevent internal damage.
Band feels too tight/loose.	Incorrect band size.	Visit a professional jeweler to have links added or removed for a comfortable fit.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	XO5846
Brand	ACCUTIME
Movement	Quartz
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	34 mm
Dial Window Material	Glass
Band Material	Alloy
Clasp Type	Fold-over clasp
Water Resistance	Not water resistant
Batteries	1 Product Specific battery (included)
Package Dimensions	11.99 x 7.49 x 5.11 cm
Item Weight	68.04 g
Manufacturer	Accutime Watch Corp.



**Figure 8.1:** General watch size guide illustrating different watch diameters for reference. The XO5846 model has a 34mm case diameter.

## 9. WARRANTY AND SUPPORT

### 9.1 Warranty Information

Specific warranty details for your ACCUTIME XOXO watch are typically provided with the product packaging or can be obtained from the retailer or manufacturer. Please retain your proof of purchase for warranty claims. Note that damage due to water exposure is not covered as this watch is not water resistant.

### 9.2 Customer Support

For further assistance, technical support, or inquiries regarding your watch, please contact the retailer where you purchased the product or refer to the official ACCUTIME website for customer service contact information.

