

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Urmet](#) /

› [Urmet Atlantico 1132/53 Adjustable Call Volume Kit User Manual](#)

Urmet 1132/53

Urmet Atlantico 1132/53 Adjustable Call Volume Kit User Manual

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of the Urmet Atlantico 1132/53 Adjustable Call Volume Kit. Please read this manual thoroughly before attempting to install or operate the device to ensure safe and correct usage. Keep this manual for future reference.

2. SAFETY INFORMATION

- Always disconnect power before performing any installation or maintenance.
- Installation should be performed by qualified personnel in accordance with local electrical codes and regulations.
- Do not expose the device to moisture, extreme temperatures, or direct sunlight.
- Use only original Urmet replacement parts and accessories.
- Avoid placing the unit near sources of strong electromagnetic interference.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged upon opening the package:

- Urmet Atlantico 1132/53 Intercom Unit
- Mounting Bracket
- Mounting Screws and Wall Plugs
- Connection Cables (if included in kit)
- User Manual (this document)

If any items are missing or damaged, please contact your supplier immediately.

4. PRODUCT OVERVIEW

The Urmet Atlantico 1132/53 is an adjustable call volume kit designed for intercom systems. It allows users to customize the loudness of the incoming call signal.



Figure 1: Front view of the Urmet Atlantico 1132/53 Intercom Unit. This image displays the main body of the intercom unit, typically showing the speaker, microphone, and call button area.

Key components typically include:

- **Call Button:** Initiates communication with the outdoor unit.
- **Speaker:** For listening to the outdoor unit and incoming calls.
- **Microphone:** For speaking to the outdoor unit.
- **Volume Control:** A rotary knob or switch to adjust the call volume.

5. INSTALLATION AND SETUP

Follow these general steps for installation. Refer to the specific wiring diagram provided with your complete intercom system for detailed connections.

1. **Prepare the Installation Area:** Choose a suitable indoor location, typically near the entrance, ensuring it is free from moisture and extreme temperatures.
2. **Mount the Bracket:** Secure the mounting bracket to the wall using the provided screws and wall plugs. Ensure it is level and firmly attached.
3. **Wiring Connections:** Connect the intercom unit to the main intercom system wiring. Pay close attention to the polarity and terminal designations (e.g., power, audio in, audio out, call signal). Ensure all connections are secure.
4. **Attach the Unit:** Carefully attach the Urmet Atlantico 1132/53 unit to the mounted bracket. Ensure it clicks into place or is securely fastened.
5. **Power On and Test:** Restore power to the intercom system. Test the call function and audio clarity.

6. OPERATION

The Urmet Atlantico 1132/53 is designed for straightforward operation:

- **Receiving a Call:** When someone presses the call button on the outdoor unit, your Atlantico 1132/53 unit will emit a call tone.
- **Answering a Call:** Press the designated call answer button (if present on your specific model or system) to establish communication.
- **Adjusting Call Volume:** Locate the volume control knob or switch on the unit. Rotate the knob clockwise to increase the call volume and counter-clockwise to decrease it. Adjust to a comfortable listening level.
- **Speaking:** Speak clearly into the microphone area of the unit.
- **Ending a Call:** Replace the handset (if applicable) or press the call end button.

7. MAINTENANCE

To ensure optimal performance and longevity of your Urmet Atlantico 1132/53 unit, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the surface.
- **Inspection:** Periodically check the unit for any visible damage or loose connections.
- **Environment:** Ensure the unit remains in a dry, well-ventilated area, away from direct heat sources or excessive dust.

8. TROUBLESHOOTING

If you encounter issues with your Urmet Atlantico 1132/53, refer to the following common problems and solutions:

- **No Call Tone:**

- Check if the system has power.
- Ensure all wiring connections are secure and correct.
- Verify the call volume is not set to minimum.

- **Low or Distorted Audio:**

- Adjust the call volume control.
- Check for loose or corroded wiring connections.
- Ensure the microphone and speaker are not obstructed.

- **Unit Not Responding:**

- Cycle the power to the entire intercom system (turn off, wait 30 seconds, turn on).
- Inspect for any visible damage to the unit or wiring.

If the problem persists after attempting these solutions, contact a qualified technician or Urmet customer support.

9. SPECIFICATIONS

Brand	Urmet
Model Number	1132/53
ASIN	B017XZKAWW
First Available Date	October 1, 2015

10. WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your product or visit the official Urmet website. Keep your proof of purchase for warranty claims.

Urmet Official Website: www.urmet.com

© 2023 Urmet. All rights reserved. Information in this manual is subject to change without notice.