

Accutime BAT4405SR

Accutime Batman DC Comics Boys Digital Watch

Model: BAT4405SR | Brand: Accutime

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Accutime Batman DC Comics Boys Digital Watch. Designed for young fans, this watch features a digital time display, flashing lights, and unique sound effects. Please read this manual thoroughly to ensure proper use and longevity of your product.

PRODUCT FEATURES

- **Digital Time Display:** Clear LCD screen for easy time reading.
- **Flashing LCD Lights:** Activated by pressing the top cover.
- **Flip-Open Cover:** Protects the display and reveals the time when opened.
- **Musical Sound Effects:** Features "To The Bat Mobile" and other sounds, activated by a side button.
- **Durable Plastic Band:** Comfortable and designed for active wear.
- **Batman Theme:** Iconic Batman design on the watch face and band.



Figure 1: Front view of the Accutime Batman Digital Watch with its flip-open cover raised, revealing the digital display and Batman artwork.

SETUP

Battery Installation

Your Accutime Batman Digital Watch comes with 5 product-specific batteries pre-installed. No initial battery installation is required for first use. For future battery replacement, please refer to the "Maintenance" section.

Setting the Time

1. Locate the small buttons on the side of the watch case. There are typically two buttons: one for 'Mode' and one for 'Set' or 'Adjust'.
2. Press the 'Mode' button repeatedly until the hour digits begin to flash.

3. Use the 'Set' or 'Adjust' button to change the hour. Pressing it once will advance the hour by one.
4. Press the 'Mode' button again to move to the minute digits.
5. Use the 'Set' or 'Adjust' button to change the minutes.
6. Continue pressing the 'Mode' button to cycle through other settings like month, day, and year if available, adjusting each with the 'Set' button.
7. Once all settings are correct, press the 'Mode' button one last time to exit the setting mode. The time will stop flashing and begin to run.



Figure 2: Close-up view of the digital time display on the watch face.

OPERATING INSTRUCTIONS

Displaying Time

To view the digital time, simply flip open the top cover of the watch. The time will be displayed on the LCD screen beneath the Batman graphic.

Activating Flashing Lights

Press the top cover of the watch down firmly to activate the flashing LCD lights. The lights will illuminate around the watch face.

Activating Sound Effects

Press the designated side button (often labeled "Push Here for Sound" or similar) to hear the "To The Bat Mobile" sound effect and other musical sounds.



Figure 3: The watch packaging illustrating the interactive features: sound effects and flashing lights.

MAINTENANCE

Cleaning

To clean your watch, gently wipe it with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the watch casing. Do not use harsh chemicals or abrasive cleaners.

Battery Replacement

When the display dims or the lights and sounds stop functioning, it may be time to replace the batteries. This watch requires 5 product-specific batteries. Battery replacement should ideally be performed by an adult.

1. Carefully locate the battery compartment on the back of the watch. It may be secured by small screws.
2. Using a small screwdriver (if applicable), open the battery compartment.
3. Remove the old batteries, noting their orientation (+/-).
4. Insert the new batteries, ensuring correct polarity.
5. Securely close the battery compartment.
6. Dispose of old batteries responsibly according to local regulations.



Figure 4: Rear view of the watch, indicating the location of the battery compartment and product information.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead batteries.	Replace batteries (refer to Maintenance section).
Lights or sounds not working.	Low batteries or button not pressed correctly.	Ensure batteries are fresh. Press the respective buttons firmly.
Time is incorrect.	Time needs to be reset.	Reset the time (refer to Setup section).

SPECIFICATIONS

- **Model Number:** BAT4405SR
- **Brand:** Accutime
- **Case Diameter:** 25mm
- **Movement:** Analog-quartz
- **Material:** Plastic
- **Recommended Age:** 6 - 6 years
- **Batteries:** 5 Product Specific batteries (included)
- **Water Resistance:** Not Water Resistant
- **Package Dimensions:** 6.26 x 2.87 x 2.52 inches
- **Item Weight:** 1.6 ounces

SAFETY INFORMATION

- **Not Water Resistant:** This watch is not designed to be submerged in water. Avoid contact with water, including swimming, bathing, or heavy rain, to prevent damage.
- **Battery Safety:** Keep batteries out of reach of small children. If swallowed, seek immediate medical attention.
- **Choking Hazard:** This product contains small parts and is not suitable for children under the recommended age due to potential choking hazards.

WARRANTY AND SUPPORT

Specific warranty details are not included in this instruction manual. For warranty information, product support, or to inquire about replacement parts, please visit the official Accutime website or contact their customer service directly. Contact information can typically be found on the product packaging or the manufacturer's official website. For additional product information or to explore other Accutime products, you may visit the [Accutime Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0183IUYW4>

More documents and user manuals: **<https://manuals.plus/>**