



Manuals.plus /

› Royalty Line /

› Royalty Line RL-SME600 Blender Instruction Manual

Royalty Line RL-SME600

Royalty Line RL-SME600 Blender Instruction Manual

Model: RL-SME600

1. INTRODUCTION

Thank you for purchasing the Royalty Line RL-SME600 Blender. This manual provides important information regarding the safe operation, maintenance, and care of your appliance. Please read these instructions thoroughly before first use and keep them for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions.

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids. Clean only with a damp cloth.
- Unplug from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts. Blades are sharp. Handle with care.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always operate the blender with the lid in place.

- Do not blend hot liquids. Allow hot liquids to cool before blending to avoid pressure buildup and potential injury.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PRODUCT OVERVIEW

The Royalty Line RL-SME600 is a powerful blender designed for various kitchen tasks, from smoothies to sauces. It features a robust motor and durable construction.

Components:

- Motor Base (with control dial)
- Blending Jar (with integrated blades)
- Lid
- Measuring Cup (integrated into lid)

Features:

- 2 Speed Settings
- Adjustable Speed Control
- Durable Metal Construction
- 220 Volt Operation





Image: The Royalty Line RL-SME600 Blender, showing the motor base, blending jar, and lid assembled.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean Before First Use:** Wash the blending jar, lid, and measuring cup in warm, soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
3. **Assemble the Jar:** Ensure the blade assembly is securely attached to the bottom of the blending jar.
4. **Place Jar on Base:** Position the blending jar onto the motor base, ensuring it is seated correctly and locked into place (if applicable to your model).
5. **Connect Power:** Plug the power cord into a standard 220V electrical outlet.

5. OPERATING INSTRUCTIONS

1. **Prepare Ingredients:** Cut solid ingredients into small pieces (approximately 2-3 cm) to facilitate blending.
2. **Add Ingredients:** Place ingredients into the blending jar. For best results, add liquids first, then soft ingredients, followed by harder ingredients and ice. Do not exceed the maximum fill line indicated on the jar.
3. **Secure Lid:** Place the lid firmly onto the blending jar. Ensure the measuring cup is inserted into the lid opening.
4. **Select Speed:** Turn the control dial to your desired speed setting (Speed 1 or Speed 2). For short bursts, use the pulse function (if available, typically a momentary setting).
5. **Blend:** Allow the blender to operate until the desired consistency is achieved. If ingredients stick to the sides, turn off the blender, remove the lid, and use a spatula to push them down. Never use your hands or utensils while the blender is running.
6. **Turn Off:** Once blending is complete, turn the control dial to the 'OFF' position.
7. **Unplug:** Always unplug the blender from the power outlet after use.
8. **Pour:** Carefully remove the lid and pour out the blended contents.

6. CLEANING AND MAINTENANCE

Regular cleaning will ensure the longevity and optimal performance of your blender.

1. **Unplug:** Always ensure the blender is unplugged before cleaning.
2. **Disassemble:** Remove the blending jar from the motor base. Carefully remove the lid and measuring cup.
3. **Clean Blending Jar and Lid:** Wash the blending jar, lid, and measuring cup immediately after use. You can rinse them under running water or wash them in warm, soapy water. Use a brush for thorough cleaning around the blades. *Caution: Blades are sharp. Handle with extreme care.*
4. **Clean Motor Base:** Wipe the motor base with a soft, damp cloth. Do not use abrasive cleaners or immerse the motor base in water.
5. **Dry and Store:** Ensure all parts are completely dry before reassembling or storing the blender. Store in a clean, dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet not active; jar not correctly seated on base.	Ensure power cord is securely plugged in. Check power outlet with another appliance. Ensure blending jar is properly aligned and locked onto the motor base.
Ingredients are not blending smoothly.	Too little liquid; too many ingredients; ingredients too large.	Add more liquid. Reduce the amount of ingredients. Cut ingredients into smaller pieces. Use the pulse function for stubborn ingredients.
Blender leaks from the bottom of the jar.	Blade assembly not tightened; jar overfilled.	Ensure the blade assembly is securely tightened to the jar. Do not fill past the maximum fill line.
Motor smells or overheats.	Overloading; continuous operation for too long.	Reduce the load. Turn off the blender and allow it to cool down for at least 15-20 minutes before resuming operation.

8. SPECIFICATIONS

Brand:	Royalty Line
Model:	RL-SME600
Color:	Silver
Voltage:	220 Volts
Number of Speeds:	2
Special Feature:	Adjustable Speed Control
Material:	Metal

9. WARRANTY AND SUPPORT

Royalty Line products are manufactured to high-quality standards. For any questions, technical support, or warranty claims, please contact your retailer or the official Royalty Line customer service. Please have your model number (RL-SME600) and purchase information ready when contacting support.

Keep your purchase receipt as proof of purchase for warranty purposes.