

Hotpoint AQC9 BF7 S1 (UK)

Hotpoint AQC9 BF7 S1 (UK) Dryer Drain Hose Instruction Manual

Brand: Hotpoint | Model: AQC9 BF7 S1 (UK)

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Hotpoint AQC9 BF7 S1 (UK) Dryer Drain Hose. Please read this manual thoroughly before installation to ensure safe and efficient use of the product. This drain hose is specifically designed for the Hotpoint AQC9 BF7 S1 dryer model.

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent damage to the product, property, or personal injury:

- Ensure the dryer is unplugged from the power outlet before attempting any installation or maintenance.
- Do not use the drain hose if it appears damaged, kinked, or has any visible defects.
- Ensure all connections are secure to prevent water leaks, which can cause property damage.
- Keep the drain hose clear of obstructions and sharp objects.
- This hose is designed for water drainage only. Do not use it for any other purpose.
- If you are unsure about any step, consult a qualified technician.

3. PRODUCT OVERVIEW

The Hotpoint AQC9 BF7 S1 (UK) Dryer Drain Hose is a crucial component for your condenser dryer, responsible for safely channeling condensed water away from the appliance to a suitable drain. It is a flexible, durable hose designed for a secure fit and reliable performance.



Image: A long, white, flexible drain hose, typically used for a dryer, shown against a white background. This hose is designed to connect the dryer's water reservoir to an external drain.

4. SETUP (INSTALLATION)

Follow these steps to correctly install the drain hose:

1. **Prepare the Dryer:** Ensure your Hotpoint AQC9 BF7 S1 dryer is unplugged from the main power supply. Locate the drain outlet on the back or side of the dryer. Refer to your dryer's main instruction manual for the exact location.
2. **Remove Existing Hose (if applicable):** If replacing an old hose, carefully disconnect it from both the dryer and the drain point. Be prepared for any residual water.
3. **Connect to Dryer:** Securely attach one end of the new drain hose to the dryer's drain outlet. Depending on your dryer model, this may involve a push-fit connection or a clamp. Ensure the connection is tight and leak-free.
4. **Route the Hose:** Carefully route the hose to your chosen drain point (e.g., a standpipe, sink, or waste trap). Avoid kinks, sharp bends, or excessive stretching of the hose, as this can impede water flow or cause damage.
5. **Connect to Drain:** Securely connect the other end of the hose to the drain point. Ensure the hose is positioned so that water can flow downhill without pooling. If connecting to a standpipe, ensure there is an air gap to prevent siphoning.
6. **Check for Leaks:** Once installed, plug in the dryer and run a short cycle (e.g., a damp load or a test cycle if available) to check for any leaks at both connection points. Address any leaks immediately by tightening connections.

5. OPERATING CONSIDERATIONS

While the drain hose itself does not have operational controls, its proper function is critical for the dryer's operation. Ensure the hose remains:

- **Unkinked:** Kinks or sharp bends will restrict water flow and can lead to water accumulation in the dryer or leaks.
- **Unobstructed:** Ensure nothing is pressing against or blocking the hose.

- **Properly Sloped:** The hose should have a continuous downward slope from the dryer to the drain to allow gravity to assist water flow.
- **Securely Connected:** Regularly check that both ends of the hose are firmly attached to prevent accidental disconnections during dryer operation.

6. MAINTENANCE

Regular maintenance helps prolong the life of your drain hose and ensures efficient dryer operation:

- **Visual Inspection:** Periodically inspect the entire length of the hose for any signs of wear, cracks, punctures, or damage. Check for discoloration or hardening of the material, which could indicate aging.
- **Connection Check:** Every few months, check the tightness of the connections at both the dryer and the drain point. Gently wiggle the hose at the connections to ensure they are secure.
- **Clear Obstructions:** If you notice slow drainage or water backing up, disconnect the hose (with the dryer unplugged) and check for any lint, debris, or blockages inside the hose. Clear any obstructions carefully.
- **Avoid Harsh Chemicals:** Do not use harsh chemical cleaners on or inside the hose, as they can degrade the material.
- **Replacement:** If the hose shows significant signs of wear, damage, or becomes brittle, it should be replaced immediately with an authentic Hotpoint AQC9 BF7 S1 (UK) replacement part to prevent leaks and ensure proper dryer function.

7. TROUBLESHOOTING

If you encounter issues with your drain hose, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Water leaking from connections	Loose connections, damaged hose end, incorrect installation.	Ensure dryer is unplugged. Tighten connections. Inspect hose ends for damage; replace if necessary. Re-install following Section 4.
Water not draining or slow drainage	Kinked hose, blocked hose (lint/debris), improper slope, blocked drain point.	Ensure dryer is unplugged. Straighten any kinks. Disconnect and clear any blockages from the hose. Ensure continuous downward slope. Check if the drain point itself is blocked.
Hose appears damaged (cracks, holes)	Wear and tear, physical damage, aging material.	The hose cannot be repaired. Replace the damaged hose immediately with a genuine Hotpoint AQC9 BF7 S1 (UK) replacement part.

If troubleshooting steps do not resolve the issue, contact Hotpoint customer support or a qualified appliance technician.

8. SPECIFICATIONS

Attribute	Detail
Brand	Hotpoint
Model Number	31908-AQC9 BF7 S1 (UK)

Attribute	Detail
ASIN	B0189G1XT8
Compatibility	Specifically for Hotpoint AQC9 BF7 S1 dryer model
Product Type	Dryer Drain Hose

9. WARRANTY AND SUPPORT

Warranty information for this product is typically provided by the retailer or manufacturer at the time of purchase. Please refer to your purchase documentation or contact the seller (Shop4Spares) or Hotpoint directly for specific warranty terms and conditions.

For technical support or further assistance, please contact Hotpoint customer service or visit their official website. When contacting support, please have your product model number (AQC9 BF7 S1 (UK)) and ASIN (B0189G1XT8) ready.

Manufacturer: Hotpoint
Seller: Shop4Spares

© 2023 Hotpoint. All rights reserved. This manual is for informational purposes only.
For the latest information, please visit the official Hotpoint website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

