

RockJam RJ654

RockJam 54 Key Keyboard Piano User Manual

Model: RJ654

Brand: RockJam

INTRODUCTION

Welcome to the user manual for your new RockJam 54 Key Keyboard Piano. This versatile electronic keyboard is designed for aspiring pianists of all ages and skill levels, offering a comprehensive set of features for learning, practice, and creative expression. Its compact and portable design allows for musical exploration anywhere, whether at home or on the go.



Image: The RockJam 54 Key Keyboard Piano, showcasing its compact design with an attached music stand holding a tablet.

WHAT'S IN THE BOX

Upon unboxing your RockJam 54 Key Keyboard Piano, please ensure all the following items are present:

- RockJam 54 Key Digital Electronic Piano Keyboard
- Sheet Music Stand
- Power Supply (AC Adapter)
- Piano Note Stickers (optional use)
- User Guide (physical copy)
- Simply Piano Lessons Voucher

SETUP GUIDE

1. **Power Connection:** Connect the included AC adapter to the DC 9V input jack located on the back of the

keyboard. Plug the adapter into a standard wall outlet. Alternatively, for portable use, insert 6 x 1.5V 'D' batteries (not included) into the battery compartment on the underside of the keyboard.

2. **Attach Music Stand:** Insert the tabs of the included sheet music stand into the corresponding slots on the top rear of the keyboard. Ensure it is securely in place. This stand is ideal for holding sheet music or a tablet device.
3. **Apply Note Stickers (Optional):** For beginners, the included piano note stickers can be applied to the keys to help identify notes. Carefully peel and stick them onto the white keys as indicated on the sticker sheet. These can be removed later without residue.



Image: A close-up view of the keyboard keys with optional note stickers applied, showing musical notation and key labels.

OPERATING INSTRUCTIONS

Power On/Off

Press the red 'POWER' button located on the left side of the control panel to turn the keyboard on or off. The LCD screen will illuminate when powered on.

Volume Control

Adjust the overall sound volume using the 'MASTER VOLUME' buttons (up/down arrows) on the control panel. The 'RHYTHM VOLUME' buttons control the volume of the accompaniment rhythms.

Selecting Tones and Rhythms

The keyboard features 100 different tones (instrument sounds) and 100 rhythms (accompaniment styles). Use the numeric keypad (0-9) to directly input the desired tone or rhythm number, or use the '+' and '-' buttons to cycle through them. The selected number will be displayed on the LCD screen.



Image: A detailed view of the RockJam keyboard's central control panel, highlighting the LCD screen, numeric keypad, and various function buttons for tone and rhythm selection.

Learning Features

The integrated teaching tool utilizes the LCD screen to provide visual guidance, indicating which chords or notes to play. This feature is designed to assist beginners in learning musical pieces effectively. For an enhanced learning experience, the RockJam keyboard is compatible with the Simply Piano application. Use the provided voucher to access exclusive content within the app. The app offers real-time feedback, guided lessons, and a wide selection of songs to learn. Simply place your tablet on the music stand and

connect it to the keyboard (if applicable, via auxiliary cable or wirelessly if supported by your device and the app).

Video: An official product video demonstrating the integration of the RockJam keyboard with the Simply Piano app, showing how the app provides interactive lessons and real-time feedback.



Image: A tablet displaying the Simply Piano application's interface, resting on the keyboard's music stand, illustrating the interactive learning setup.

Record and Playback

The keyboard includes a record and playback function, allowing you to capture your performances. Press the 'RECORD' button to begin recording your playing. Press 'PLAY' to listen to your recorded music. This feature supports recording up to 41 notes.

Headphone Use

For private practice, connect standard 3.5mm headphones to the 'HEADPHONES' jack located on the back of the keyboard. This will mute the built-in speakers.



Image: A close-up of one of the keyboard's built-in stereo speakers, highlighting the grille design.



Image: The rear view of the keyboard, showing the power input and 3.5mm headphone jack for connectivity.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard's surface. For stubborn marks, a slightly damp cloth can be used, but ensure no moisture enters the internal components. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, store the keyboard in a cool, dry place away from direct sunlight, extreme temperatures, and excessive humidity.
- **Handling:** Always handle the keyboard with care. Avoid dropping it or placing heavy objects on top of it.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No power/Keyboard does not turn on	Power adapter not connected or faulty; Batteries drained or incorrectly inserted.	Ensure AC adapter is securely plugged into keyboard and wall outlet. If using batteries, replace them or check polarity.
No sound from speakers	Volume too low; Headphones connected; Tone selected has no sound.	Increase 'MASTER VOLUME'. Disconnect headphones. Select a different tone.
Keys not responding	Keyboard may be in a specific mode (e.g., demo mode).	Ensure the keyboard is not in demo mode. Refer to the user guide for specific mode controls.
Simply Piano app not connecting	Incorrect connection method; App settings.	Ensure auxiliary cable is correctly connected (if applicable). Check app's connection settings and permissions.

SPECIFICATIONS

Feature	Detail
Number of Keys	54 Full-Sized Keys
Dimensions (L x W x H)	33.5" x 13" x 4.7"
Weight	8.27 Pounds
Power Source	AC Adapter (included) or 6 x 1.5V 'D' Batteries (not included)
Speakers	2 Inbuilt Stereo Speakers (5 Watts Output)
Tones	100
Rhythms	100
Special Features	LCD Display, Portable, Headphone Jack, Record/Playback Function, Digital Effects
Connectivity	3.5mm Jack (Auxiliary)
Compatible Software	Simply Piano (iOS, Android)
Color	Black
Manufacturer	PDT Ltd - IMPORT (UK Vendor, Product FOB China)
Country of Origin	China

WARRANTY AND SUPPORT

For detailed warranty information, technical support, and further assistance, please refer to the comprehensive User Manual (PDF) provided with your product or visit the official RockJam support website. The User Guide (PDF) can also be accessed online for additional details.

Download User Manual
(PDF)