

- Manuals.plus /
- > [Altec Lansing](#) /
 - > Altec Lansing IMW120 Solo Motion Portable Bluetooth Wireless Speaker User Manual

Altec Lansing IMW120-BLK

Altec Lansing IMW120 Solo Motion Portable Bluetooth Wireless Speaker

Model: IMW120-BLK
Brand: Altec Lansing

1. PRODUCT OVERVIEW

The Altec Lansing IMW120 Solo Motion is a compact and portable Bluetooth wireless speaker designed for on-the-go audio. It features a single 1.375-inch driver, an integrated microphone for hands-free communication, and on-board controls for song navigation. With a built-in rechargeable battery, it provides up to 4 hours of audio playback, making it suitable for various portable audio needs.



Figure 1: Altec Lansing IMW120 Solo Motion Portable Bluetooth Wireless Speaker in its retail packaging. This image displays the Altec Lansing IMW120 Solo Motion speaker within its clear retail packaging, highlighting its compact size and integrated carry strap. The packaging also features icons indicating effortless Bluetooth pairing, hands-free speakerphone capability, and a built-in rechargeable battery.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- Altec Lansing IMW120 Solo Motion Bluetooth Speaker
- Auxiliary (AUX) in jack cable
- Integrated carry strap (pre-attached)

3. KEY FEATURES

- **Portable Design:** Compact and lightweight with an integrated carry strap for easy transport.
- **Bluetooth Connectivity:** Wireless audio streaming with a range of up to 33 feet (10 meters).
- **Hands-Free Communication:** Built-in microphone for taking calls directly through the speaker.
- **On-Board Controls:** Easy-to-use touch controls for song navigation and volume adjustment.
- **Rechargeable Battery:** Provides up to 4 hours of continuous music playback.

- **Auxiliary Input:** 3.5mm AUX in jack for wired connection to audio devices.

4. CONTROLS AND INDICATORS

The Altec Lansing IMW120 Solo Motion speaker features intuitive touch controls for managing audio playback and calls. Specific button locations and functions are typically found on the top or side panel of the device.



Figure 2: Front view of the Altec Lansing IMW120 Solo Motion Portable Bluetooth Wireless Speaker. A front view of the Altec Lansing IMW120 Solo Motion speaker, showcasing its black perforated grille and the Altec Lansing logo centrally located. The integrated carry strap is visible at the top, emphasizing its portability.

Common Controls (Touch Method):

- **Power Button:** Press and hold to turn the speaker on or off.
- **Bluetooth Pairing Button:** Activates Bluetooth pairing mode.
- **Volume Up/Down:** Adjusts the audio output level.
- **Play/Pause:** Controls music playback.
- **Track Skip:** Navigates to the next or previous song.
- **Call Answer/End:** Manages incoming and outgoing phone calls.

Indicators:

- **LED Indicator:** Typically shows power status, charging status, and Bluetooth pairing status (e.g., solid for connected, blinking for pairing).

5. SETUP

5.1 Initial Charging

Before first use, fully charge your Altec Lansing IMW120 Solo Motion speaker. Connect the charging cable to the speaker's charging port and a compatible USB power source. The LED indicator will typically show charging status and turn off or change color when fully charged.

5.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the LED indicator lights up.
- **To Power Off:** Press and hold the Power button again until the LED indicator turns off.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

1. Ensure the speaker is powered on and within 33 feet (10 meters) of your Bluetooth device.
2. The speaker will automatically enter pairing mode when powered on for the first time, or if no device is connected. The LED indicator will typically blink rapidly.
3. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings and search for available devices.
4. Select "IMW120 Solo Motion" or a similar name from the list of found devices.
5. Once paired, the speaker will provide a voice confirmation, and the LED indicator will typically turn solid.
6. The speaker will automatically reconnect to the last paired device when powered on, if that device is within range and has Bluetooth enabled.

6.2 Audio Playback

- After successful Bluetooth pairing, begin playing audio from your connected device.
- Use the on-board touch controls on the speaker or your connected device to adjust volume, play/pause, and skip tracks.
- For wired connection, insert the 3.5mm auxiliary cable into the speaker's AUX input and the other end into your audio device's headphone jack.

6.3 Hands-Free Calling

- When a call comes in while connected via Bluetooth, the speaker will typically ring.
- Press the Call Answer button (often the Play/Pause button) on the speaker to answer the call.
- Speak into the speaker's built-in microphone.
- Press the Call End button to end the conversation.

7. CHARGING THE BATTERY

The Altec Lansing IMW120 Solo Motion speaker is equipped with a high-quality built-in Lithium battery, providing up to 4 hours of playback time on a full charge.

- Connect the speaker to a standard USB power adapter (not included) or a computer's USB port using the appropriate charging cable.
- The charging indicator light will illuminate during charging.
- Once fully charged, the indicator light will typically change color or turn off.
- A full charge usually takes a few hours.

8. MAINTENANCE

To ensure the longevity and optimal performance of your speaker:

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** This speaker is NOT waterproof. Avoid exposure to water or excessive moisture.
- **Charging Port:** Handle the charging port with care to prevent damage. Avoid forcing cables into the port.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; Device's Bluetooth is off; Speaker is too far from device.	Ensure speaker is in pairing mode (blinking LED); Turn on Bluetooth on your device; Move speaker closer to your device (within 33 feet).
No sound or low volume.	Volume on speaker or device is too low; Speaker is not connected; Audio source issue.	Increase volume on both speaker and connected device; Re-pair the Bluetooth connection; Check audio source (e.g., music app).
Charging issue.	Faulty cable or power source; Damaged charging port.	Try a different charging cable and USB power source. If the charging port appears damaged, contact customer support.
Bluetooth connection cuts out.	Interference; Device too far; Low battery.	Move speaker closer to the device; Avoid obstacles between speaker and device; Ensure speaker is fully charged.

10. SPECIFICATIONS

Model Name	iMW120-BLK
Speaker Type	Portable Bluetooth Speaker
Connectivity Technology	Bluetooth, Auxiliary (3.5mm)
Wireless Range	Up to 33 feet (10 meters)
Battery Life	Up to 4 hours
Power Source	Battery Powered
Control Method	Touch
Built-in Microphone	Yes (for hands-free calls)
Product Dimensions (D x W x H)	1.75"D x 2.37"W x 3.5"H
Item Weight	0.55 Pounds (approx. 8.8 ounces)
Color	Black
Waterproof	No
UPC	021331713346

11. WARRANTY INFORMATION

The Altec Lansing iMW120 Solo Motion Portable Bluetooth Wireless Speaker comes with a **Limited Warranty**. Please refer to the warranty card included with your product or visit the official Altec Lansing website for detailed terms and conditions regarding warranty coverage, duration, and claims procedures.

12. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Altec Lansing IMW120 Solo Motion speaker, please visit the official Altec Lansing website or contact their customer service department. Contact information can typically be found on the manufacturer's website or in the product packaging.

Website: www.alteclansing.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B018CA0UOA>

More documents and user manuals: <https://manuals.plus/>