

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Artos](#) /

› [Artos F907-4/5BN 8-inch Shower Rainhead with 4.75-inch Arm Installation and User Manual](#)

## Artos F907-4/5BN

# Artos F907-4/5BN 8-inch Shower Rainhead with 4.75-inch Arm Installation and User Manual

Model: F907-4/5BN | Brand: Artos

## IMPORTANT SAFETY INFORMATION

- Read all instructions thoroughly before beginning installation or use.
- Ensure the main water supply to the installation area is completely turned off before starting any plumbing work.
- If you are uncertain about any step of the installation process, consult a qualified professional plumber.
- Do not use harsh chemicals, abrasive cleaners, or scouring pads on the product's finish, as this may cause damage.

## PACKAGE CONTENTS

- 8-inch Shower Rainhead
- 4.75-inch Ceiling Mount Shower Arm
- Decorative Flange/Escutcheon
- Installation Hardware (e.g., Pipe Thread Sealant Tape)

## TOOLS REQUIRED

- Adjustable Wrench
- Pipe Thread Sealant Tape (Teflon Tape)
- Soft Cloth

## SETUP: INSTALLATION INSTRUCTIONS


Follow these steps carefully to ensure proper installation of your Artos F907-4/5BN shower rainhead and ceiling mount arm.

1. **Prepare the Installation Area:** Ensure the main water supply to the bathroom is turned off. Clear the area around the shower ceiling connection point.
2. **Apply Thread Sealant:** Wrap pipe thread sealant tape (Teflon tape) clockwise around the threaded end of the 4.75-inch ceiling mount shower arm that will connect to the water supply pipe in the ceiling. Apply 3-4 layers for a secure seal.
3. **Install Shower Arm:** Thread the shower arm into the ceiling water supply pipe. Hand-tighten, then use an adjustable wrench to tighten an additional 1/4 to 1/2 turn. Do not overtighten. Ensure the arm is securely mounted and positioned correctly.
4. **Install Flange/Escutcheon:** Slide the decorative flange/escutcheon over the shower arm, pushing it flush against the ceiling to cover the opening and provide a finished look.
5. **Attach Rainhead:** Apply pipe thread sealant tape to the threaded connection on the shower arm where the rainhead will attach. Thread the 8-inch shower rainhead onto the shower arm. Hand-tighten, then use an adjustable wrench to tighten slightly. Do not overtighten.
6. **Check for Leaks:** Slowly turn on the main water supply and carefully inspect all connections for any signs of leaks. If leaks are detected, turn off the water, re-tighten the connections, and re-check.

## COMPONENTS OVERVIEW

---

The following image illustrates a typical Artos shower component, providing a visual reference for general product design and finish. Please note that this image does not depict the F907-4/5BN rainhead and ceiling mount arm directly.



*Figure 1: Example of an Artos shower slide bar with handheld shower. This image is for illustrative purposes of general design and finish.*

## OPERATING INSTRUCTIONS

---

The Artos F907-4/5BN shower rainhead operates by directing water flow from your shower valve. To use:

- Ensure your shower valve is in the "off" position before entering the shower enclosure.
- Turn on the hot and cold water supplies at your shower valve to achieve the desired water temperature.
- The rainhead will deliver a consistent, wide spray pattern for a full and immersive shower experience.

- After use, turn off the water supply completely at the shower valve.

## MAINTENANCE

Regular cleaning and maintenance will help preserve the finish and functionality of your Artos shower rainhead.

- **Cleaning:** Clean the rainhead and arm regularly with a soft cloth and mild soap or a non-abrasive cleaner specifically designed for bathroom fixtures.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the brushed nickel finish.
- **Mineral Deposits:** If mineral deposits accumulate on the rainhead nozzles, gently rub them with your finger or a soft brush to dislodge them. For stubborn deposits, a solution of white vinegar and water can be applied with a soft cloth, then rinsed thoroughly.
- **Drying:** After cleaning, wipe the product dry with a soft cloth to prevent water spots and maintain the finish.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Pressure	Partially closed main water valve; Clogged rainhead nozzles; Debris in the shower arm.	Ensure main water valve is fully open. Clean rainhead nozzles by gently rubbing them. Disassemble and check shower arm for debris if necessary.
Leaks at Connections	Improperly tightened connections; Insufficient thread sealant tape.	Turn off water supply. Re-tighten connections. Apply more thread sealant tape if necessary and re-assemble.
Water Spots/Stains	Hard water deposits; Not drying after use.	Wipe the product dry after each use. For stubborn spots, use a vinegar solution as described in the Maintenance section.

## SPECIFICATIONS

**Model:** F907-4/5BN  
**Brand:** Artos  
**Rainhead Size:** 8 inches  
**Shower Arm Length:** 4.75 inches  
**Mounting Type:** Ceiling Mount  
**Material:** Nickel (Brushed Nickel Finish)  
**Part Number:** F907-45BN  
**UPC:** 646791262373






## WARRANTY AND SUPPORT

For specific warranty information regarding your Artos F907-4/5BN shower rainhead and ceiling mount

arm, please refer to the warranty documentation provided with your purchase or visit the official Artos website. For technical support or assistance, please contact Artos customer service directly.


**Artos Official Website:** [www.artos.com](http://www.artos.com) (Note: This is a placeholder link; please refer to your product documentation for the correct support contact information.)

Related Documents - F907-4/5BN

	<p><a href="#">Shower Installation Guide: Component Dimensions</a></p> <p>An installation guide detailing the dimensions of shower arm length, shower head width, and valve trim width for a shower system.</p>
	<p><a href="#">AXOR Montreux 4-Hole Bathtub Rim Tap with Lever Handles - Technical Specifications and Parts List</a></p> <p>Detailed information on the AXOR Montreux 4-hole bathtub rim tap with lever handles, including features, technology, dimensions, flow rate diagrams, exploded views, and a comprehensive spare parts list. Finished in Brushed Nickel.</p>
	<p><a href="#">Shower Faucet Installation Guide - Dimensions and Connections</a></p> <p>Comprehensive installation guide for a shower faucet system, detailing all critical dimensions, connection types (NPT, G), and adjustable mounting options for easy setup.</p>
	<p><a href="#">Shower Fixture Installation Guide: Dimensions and Connections</a></p> <p>Comprehensive installation guide for a shower fixture, detailing dimensions, connection types (NPT, G 3/4), faucet body spacing, and spout reach for accurate setup.</p>
	<p><a href="#">17 Stories 4-Light Semi Flush Mount Ceiling Light Fixture Installation Guide</a></p> <p>Step-by-step installation and assembly instructions for the 17 Stories 4-Light Modern Industrial Semi Flush Mount Ceiling Light Fixture. Includes parts list, wiring guidance, and safety precautions for professional installation.</p>

ASSEMBLY INSTRUCTION

- NOTE:** Please read all safety instructions before using this product. For more information, please refer to the user manual.
1. **SAFETY:** Always use caution when using this product. Do not touch the light fixture or the wiring when the light is on. Do not use the light fixture in areas where it could be a fire hazard.
  2. **INSTALLATION:** The light fixture must be installed in a dry location. Do not install the light fixture in areas where it could be exposed to water or moisture.
  3. **WIRING:** The light fixture must be wired to a standard 120V AC power source. Do not use the light fixture in areas where it could be exposed to high voltage or current.
  4. **MAINTENANCE:** The light fixture must be maintained in good working order. Do not use the light fixture if it is damaged or if it is not working properly.
  5. **DISPOSAL:** The light fixture must be disposed of properly. Do not throw the light fixture away with regular trash.
  6. **WARRANTY:** The light fixture is covered by a limited warranty. For more information, please refer to the warranty card.



[Assembly Instructions for LW-SC536030 Flush Mount Light](#)

Step-by-step assembly instructions for the LW-SC536030 2-Light 4.88-inch Brushed Nickel Incandescent Flush Mount Light, including important safety notes and a diagram description.