



Manuals.plus /

› HONEYSEW /

› HONEYSEW Overlock Serger 6 Presser Feet Set Instruction Manual

## HONEYSEW BF-6

# HONEYSEW Overlock Serger 6 Presser Feet Set Instruction Manual

Model: BF-6

Brand: HONEYSEW

[Introduction](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance  
Support](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

## INTRODUCTION

This manual provides instructions for the HONEYSEW 6-piece Overlock Serger Presser Feet Set (Model BF-6). This set is designed to expand the capabilities of compatible overlock serger machines, allowing for specialized sewing techniques such as gathering, elastic application, cording, blind hemming, beading, and lace application. Please read these instructions carefully before use to ensure proper operation and to achieve optimal results.



Image: The complete set of six HONEYSEW overlock serger presser feet, each designed for a specific sewing function.

## SETUP AND COMPATIBILITY

### Compatibility

This presser feet set is compatible with various overlock serger machines, including but not limited to:

- Singer models: 14CG754, 14SH654, 14SH754, 14HD854, 14U554, 14U555, 14U557, 14U595, 14U955
- Consew models: 14TU5432, 14TU2345
- Pfaff model: 4870
- Yamata model: FY14U4A
- Juki models: 644D, 04D, RS20, 735

Always refer to your serger machine's manual for specific instructions on changing presser feet.

### Attaching a Presser Foot

1. Ensure your serger machine is turned off and unplugged for safety.
2. Raise the presser foot lifter to its highest position.

3. Locate the presser foot release lever or screw on your serger.
4. Remove the existing presser foot.
5. Align the new HONEYSEW presser foot with the presser foot holder. The bar on the presser foot should fit into the groove of the holder.
6. Lower the presser foot lifter slowly until the foot snaps into place or can be secured with the screw.
7. Gently tug on the foot to ensure it is securely attached before turning on the machine.



Image: The HONEYSEW presser feet neatly organized within their protective storage case.

## OPERATING INSTRUCTIONS FOR EACH FOOT

Each presser foot in this set is designed for a specific function. Always perform a test stitch on scrap fabric before working on your main project.

### 1. Gathering/Shirring/Ruffling Foot (550620)

This foot is used to create gathers or ruffles on fabric. It features a guide that helps feed the fabric evenly while the serger stitches, creating a gathered effect. Adjusting the differential feed and stitch length on your serger will control the density of the gathers.

- **Usage:** Place the fabric to be gathered under the foot. For gathering one layer to another, place the flat fabric on top of the foot and the fabric to be gathered underneath.
- **Tip:** Experiment with differential feed settings (higher numbers for more gathering) and stitch length to achieve desired fullness.

### 2. Elastic Foot (550621)

The elastic foot is designed to attach elastic to fabric while stretching it, creating a neat, professional finish for waistbands, cuffs, and lingerie. It often has a guide or roller to help feed the elastic smoothly.

- **Usage:** Feed the elastic through the guide on the foot. Place the fabric edge under the foot. The foot will stretch the elastic as it is sewn to the fabric.

- **Tip:** Adjust the tension on the elastic (if your foot has this feature) and the differential feed on your serger to control the amount of stretch and gather.

### 3. Cording/Piping Foot (550622)

This foot is used for inserting cording or piping into seams. It has grooves on the underside that allow the cord to pass through smoothly, ensuring the needle stitches close to the cord for a secure and decorative finish.

- **Usage:** Place the cording or piping into the groove of the foot. Position the fabric so the seam allowance is aligned, and stitch.
- **Tip:** This foot is ideal for adding decorative elements to cushions, garments, and upholstery.

### 4. Blind Hem Foot (550623)

The blind hem foot helps create invisible hems on garments. It features an adjustable guide that ensures the needle catches only a small amount of fabric from the main garment, resulting in a nearly invisible stitch on the right side.

- **Usage:** Fold and press the hem according to your fabric type. Position the fabric under the foot so the guide runs along the folded edge, allowing the needle to just catch the fold.
- **Tip:** Practice on scrap fabric to fine-tune the guide position and serger settings for the best blind hem result.

### 5. Beading Foot (550624)

This foot is designed for attaching strings of beads or pearls to fabric edges or surfaces. It typically has a channel or groove to guide the bead string, allowing the serger stitches to secure it neatly.

- **Usage:** Feed the string of beads through the channel on the foot. Position the fabric and stitch, ensuring the needle clears the beads.
- **Tip:** Use a longer stitch length and adjust tensions as needed to accommodate the beads.

### 6. Lace Application Foot (550769)

The lace application foot assists in attaching lace or trim to fabric edges. It often has a guide to keep the lace aligned with the fabric edge, ensuring a precise and even attachment.

- **Usage:** Place the lace or trim under the foot, aligning its edge with the fabric edge. Stitch to attach.
- **Tip:** This foot is useful for decorative finishes on garments, home decor, and crafts.

## MAINTENANCE

---

Proper care of your presser feet will ensure their longevity and optimal performance.

- **Cleaning:** After each use, gently brush away any lint or thread buildup from the presser foot. A soft cloth can be used to wipe down the metal surfaces.
- **Storage:** Store the presser feet in their provided protective case (or a similar secure container) to prevent damage and loss. Keep them in a dry environment.
- **Inspection:** Periodically inspect each foot for any signs of wear, bending, or damage. Damaged feet can affect stitch quality and potentially harm your machine.

## TROUBLESHOOTING

---

If you encounter issues while using your HONEYSEW presser feet, consider the following:

- **Foot not attaching securely:** Ensure the presser foot is correctly aligned with the presser foot holder and the release lever/screw is fully engaged.
- **Poor stitch quality:**
  - Check your serger's tension settings. Different feet and fabrics may require tension adjustments.
  - Verify that the correct needle type and size are being used for your fabric.
  - Ensure the serger is threaded correctly.
  - Clean any lint buildup around the feed dogs and under the presser foot.
- **Fabric not feeding evenly:**
  - Adjust your serger's differential feed settings.
  - Ensure the fabric is placed correctly under the foot, especially when using feet with guides.
- **Foot appears damaged:** Discontinue use immediately and replace the foot. Do not attempt to bend or repair a damaged foot as it may cause further issues with your machine.

For persistent issues, consult your serger machine's instruction manual or contact HONEYSEW customer support.

## PRODUCT SPECIFICATIONS

<b>Model Number</b>	BF-6
<b>Brand</b>	HONEYSEW
<b>Material</b>	Plastic (likely referring to the case, feet are metal)
<b>Product Dimensions (Set)</b>	4 x 3 x 1 inches (approximate)
<b>Item Weight (Set)</b>	0.01 ounces (This seems incorrect for a set of 6 metal feet, likely a placeholder or error in source data. Actual weight may vary.)
<b>UPC</b>	778564231825, 601420038729

*Note: Specifications are subject to change without notice.*

## WARRANTY AND SUPPORT

For warranty information, product support, or inquiries regarding your HONEYSEW Overlock Serger Presser Feet Set, please contact the manufacturer directly through their official website or the retailer from whom the product was purchased.

**Manufacturer:** sewing (as listed in product data, likely a generic placeholder or internal name)

**Brand:** HONEYSEW

For the most up-to-date contact information, please visit the HONEYSEW Store on Amazon.

