

[manuals.plus](#) /› [iClever](#) /› [iClever BK05 Backlit Foldable Keyboard User Manual](#)

## iClever IC-BK05

# iClever BK05 Backlit Foldable Keyboard User Manual

Comprehensive instructions for setting up, operating, and maintaining your iClever BK05 Wireless Folding Keyboard. This manual covers Bluetooth connectivity, backlight customization, and multi-device management for seamless productivity across various operating systems.

## 1. PRODUCT OVERVIEW

---

The iClever BK05 is a versatile tri-fold backlit keyboard designed for portability and multi-device compatibility. Its compact design and robust aluminum alloy construction make it ideal for travel and various work environments. The keyboard features adjustable backlighting and supports seamless switching between up to four connected devices.



Figure 1: iClever BK05 Backlit Foldable Keyboard in its unfolded state, ready for use, with a smartphone positioned on a stand in the background.

# Tri-Fold Portable Keyboard



Figure 2: The iClever BK05 keyboard shown in both its folded and unfolded states, highlighting its compact dimensions (6.5in x 4.7in folded) and extended size (10.9in x 4.2in unfolded), with a weight of 9.9 oz.

## 2. SETUP AND CONNECTION

### 2.1 Charging the Keyboard

Before first use, fully charge the keyboard using the provided USB-C cable. Connect the USB-C end to the keyboard's charging port and the USB-A end to a power adapter or computer USB port. The charging indicator light will show charging status.



Figure 3: The iClever BK05 keyboard connected via its USB-C port for charging, indicating its rechargeable battery feature.

A full charge can last up to 5 months with 2 hours of daily usage without backlight, or up to 5 hours with continuous backlight use. The power indicator will flash when the battery is below 15%.

## 2.2 Powering On/Off

To power on the keyboard, simply unfold it. The keyboard will automatically power off when folded closed.

## 2.3 Bluetooth Pairing

The iClever BK05 keyboard supports connection with up to 4 devices simultaneously (3 via Bluetooth 5.1 and 1 via wired connection). Follow these steps to pair:

1. Unfold the keyboard to power it on.
2. Press **Fn + C** to enter pairing mode. The Bluetooth indicator light will blink.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for "iClever IC-BK05 Keyboard" in the list of available devices.

4. Select the keyboard to connect. Once connected, the Bluetooth indicator light will stop blinking.



Figure 4: The iClever BK05 keyboard demonstrating multi-device connection capability, pairing with up to 4 devices including a tablet, smartphone, and laptop.

Your browser does not support the video tag.

Video 1: Official iClever demonstration of the Backlit Bluetooth Keyboard's features, including pairing and backlight functions. This video provides a visual guide to the keyboard's operation.

## 2.4 Switching Between Devices

To switch between paired Bluetooth devices, press **Fn + Q** (for device 1), **Fn + W** (for device 2), or **Fn + E** (for device 3). The keyboard will seamlessly connect to the selected device.




Figure 5: A close-up of the iClever BK05 keyboard highlighting the Fn+Q, Fn+W, and Fn+E key combinations used for quickly switching between up to three connected Bluetooth devices.

## 2.5 Operating System Mode Switching

For optimal performance and key mapping, switch the keyboard to the correct operating system mode:

- For iOS/iPadOS/macOS: Press **Fn + A**.
- For Android: Press **Fn + S**.
- For Windows/Chrome OS: Press **Fn + D**.



Figure 6: The iClever BK05 keyboard positioned on a desk with various devices, illustrating its wide compatibility with Android, Windows, iOS, and Mac operating systems.

## 3. OPERATING THE KEYBOARD

### 3.1 Backlight Control

The keyboard features 3 backlight colors (Red, Green, Blue) and 2 brightness levels. To adjust the backlight:

- To change backlight color: Press **Fn + Alt + Right Arrow** or **Fn + Alt + Left Arrow**.
- To adjust brightness (2 levels + off): Press **Fn + Alt + Up Arrow** or **Fn + Alt + Down Arrow**.

# Adjustable Backlight

## Bright Keys for Day or Night



Figure 7: The iClever BK05 keyboard illuminated with a green backlight, demonstrating its adjustable backlight feature for comfortable typing in various lighting conditions.



Figure 8: An overhead view of the iClever BK05 keyboard, showcasing its full layout with the keys brightly lit by the green backlight.

## 3.2 Special Function Keys

The keyboard includes function keys (F1-F12) with integrated multimedia and system controls. To activate these functions, press the **Fn** key simultaneously with the desired function key.




Figure 9: A visual guide to the iClever BK05 keyboard's function keys (F1-F12) and their corresponding multimedia and system controls, activated by pressing the Fn key.

Common shortcuts for text editing and navigation:

- **Select All:** **Win + A** (iOS/macOS) or **Ctrl + A** (Android/Windows)
- **Copy:** **Win + C** (iOS/macOS) or **Ctrl + C** (Android/Windows)
- **Paste:** **Win + V** (iOS/macOS) or **Ctrl + V** (Android/Windows)

## 4. MAINTENANCE AND CARE

### 4.1 Cleaning

To clean the keyboard, use a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture and abrasive cleaners.

### 4.2 Battery Care

To prolong battery life, avoid exposing the keyboard to extreme temperatures. Recharge the battery when the low power indicator flashes to maintain optimal performance.

## 5. TROUBLESHOOTING

### 5.1 Connection Issues

- **Keyboard not pairing:** Ensure the keyboard is fully charged and in pairing mode **Fn + C**. Check that Bluetooth is enabled on your device and that the keyboard is within range.
- **Intermittent connection:** Move the keyboard closer to your device. Ensure there are no strong interference sources nearby (e.g., other wireless devices, microwaves).
- **Incorrect key input:** Verify that the keyboard is set to the correct operating system mode **Fn + A** for iOS, **Fn + S** for

Android, **Fn + D** for Windows).

## 5.2 Backlight Not Working

If the backlight is not working, ensure the keyboard has sufficient battery charge. Try adjusting the brightness levels using **Fn + Alt + Up/Down Arrow**.

## 6. SPECIFICATIONS

---

Feature	Description
Brand	iClever
Model Number	IC-BK05
Connectivity Technology	Bluetooth 5.1 / USB (Wired)
Compatible Devices	PC, Laptop, Tablet, Smartphone (iOS, iPadOS, macOS, Android, Windows 8/10/11, Chrome OS)
Backlight	3 Colors (Red, Green, Blue), 2 Brightness Levels
Battery Life (No Backlight)	Up to 5 months (2 hours daily usage)
Battery Life (With Backlight)	Up to 5 hours
Charging Port	USB-C
Item Weight	9.9 ounces
Product Dimensions (Folded)	6.46 x 4.65 x 0.63 inches
Material	Aircraft-grade aluminum alloy

## 7. WARRANTY AND SUPPORT

---

The iClever BK05 keyboard comes with a 12-month warranty. For product support, troubleshooting assistance, or warranty claims, please contact iClever customer service through their official website or the platform where the product was purchased.