

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [glion](#) /
- > [Dolly Lightweight Foldable Adult Electric Scooter](#)

glion GD200B1

Glion Dolly Lightweight Foldable Adult Electric Scooter Instruction Manual

Model: GD200B1 | Brand: glion

INTRODUCTION

Welcome to the Glion Dolly Lightweight Foldable Adult Electric Scooter manual. This guide provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new electric scooter. Please read this manual thoroughly before first use and keep it for future reference.



Figure 1: The Glion Dolly Lightweight Foldable Adult Electric Scooter in its upright, ready-to-ride position.

SETUP

1. Unboxing and Initial Assembly

Your Glion Dolly scooter comes mostly assembled. Carefully remove all packaging materials. Ensure all components are present before proceeding.

2. Charging the Battery

Before first use, fully charge the scooter's lithium-ion battery. The scooter is equipped with a premium 36V, 7.8Ah lithium-ion battery. A full charge typically takes approximately 3.25 hours.

- Locate the charging port on the scooter.
- Connect the charger to the scooter and then to a standard electrical outlet.
- The charging indicator light on the charger will change (e.g., from red to green) when charging is complete.

3. Unfolding the Scooter

The Glion Dolly features a patented folding mechanism for easy portability. To unfold:

1. Place the scooter on a flat, stable surface.
2. Release the main folding latch located near the base of the handlebar stem.
3. Carefully raise the handlebar stem until it locks securely into the upright position.
4. Extend the handlebars by pulling them outwards until they click into place.





Figure 2: The Glion Dolly in its folded, dolly-mode, allowing it to be rolled like luggage.



Figure 3: The Glion Dolly in its vertical self-standing folded position.



Cover Sold Separately

Figure 4: The Glion Dolly folded into its compact form, ready for storage or transport.

OPERATING INSTRUCTIONS

1. Powering On/Off

Press and hold the power button on the handlebar to turn the scooter on or off. The battery indicator lights will illuminate upon power-on.

2. Riding the Scooter

- Place one foot firmly on the scooter deck.
- Use your other foot to push off and gain initial momentum.
- Once moving, gently twist the throttle grip on the right handlebar to accelerate. The scooter features a powerful 250-watt (600-watt peak) DC hub motor.
- To brake, use the twist-grip electric hand brake on the left handlebar or the rear fender press brake. The electronic antilock brake provides maintenance-free stopping power.



Figure 5: Close-up of a rider's feet positioned on the scooter's deck, ready for operation.

3. Safety Guidelines

This scooter is designed for riders age 16 years and older. Always wear appropriate safety gear, including a helmet. Be aware of your surroundings and adhere to local traffic laws. The scooter features front tire suspension and Honeycomb never-flat airless rubber tires for a stable ride, but always be cautious of uneven surfaces.

4. Battery Indicator

The handlebar display shows the current battery level. Monitor this indicator to ensure you have sufficient charge for your journey. Recharge the battery when the indicator shows low power.

MAINTENANCE

1. General Cleaning

Regularly wipe down the scooter with a damp cloth to remove dirt and debris. Avoid using harsh chemicals or abrasive materials that could damage the finish.

2. Tire Care

The Glion Dolly uses Honeycomb never-flat airless rubber tires, eliminating the need for inflation. Periodically inspect the tires for any signs of wear or damage.

3. Brake System

The electronic antilock brake system is designed to be maintenance-free. However, regularly check the responsiveness of both the electric hand brake and the rear fender press brake to ensure they are functioning correctly.

4. Battery Longevity

To maximize battery life, avoid completely draining the battery before recharging. Store the scooter in a cool, dry place when not in use, and charge it periodically if stored for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Scooter does not power on.	Low or depleted battery.	Charge the battery fully.
Throttle not responding or delayed response.	Loose connection or internal issue with throttle mechanism.	Ensure all connections are secure. If issue persists, contact customer support.
Handlebars do not snap into place securely.	Improper alignment or issue with the locking mechanism.	Ensure the stem is fully extended and aligned. Check for obstructions in the locking mechanism. Refer to the unfolding instructions.
Reduced range or power over time.	Battery degradation due to age or improper charging habits.	Ensure proper charging practices. Battery replacement may be necessary after extended use.
Tail light not functioning.	Wiring issue or component failure.	Inspect wiring for damage. Contact customer support for repair or replacement.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact Glion customer support for assistance.

SPECIFICATIONS

Feature	Detail
Item Package Dimensions L x W x H	38.1 x 15.6 x 9.8 inches
Package Weight	17.58 Kilograms
Item Dimensions LxWxH	37.4 x 7.87 x 11.81 inches
Item Weight	27.34 Pounds
Brand Name	glion
Country of Origin	China

Feature	Detail
Model Name	FBA_GD200B1
Color	Black
Material	Aluminum
Suggested Users	unisex
Number of Items	1
Manufacturer	Probity Cell LLC
Part Number	GD200B1
Model Year	2022
ASIN	B018KTMOPG
Date First Available	November 26, 2015

WARRANTY & SUPPORT

Warranty Information

The Glion Dolly Lightweight Foldable Adult Electric Scooter comes with a **one-year manufacturer warranty** from the date of receipt. This warranty covers defects in materials and workmanship under normal use.

Customer Support

For technical assistance, warranty claims, or any questions regarding your Glion Dolly scooter, please visit the official Glion website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty services.

OFFICIAL PRODUCT VIDEOS

Glion Dolly Foldable Lightweight Adult Electric Scooter Overview

Your browser does not support the video tag.

This video provides a comprehensive overview of the Glion Dolly Foldable Lightweight Adult Electric Scooter, highlighting its key features and benefits for daily commuting.