

Vont VNT-CL02

Vont LED Camping Lantern Instruction Manual

Brand: Vont
Model: VNT-CL02

1. INTRODUCTION

The Vont LED Camping Lantern is a compact, bright, and durable lighting solution perfect for various situations, including camping, emergencies, and power outages. Equipped with 30 crazy bright LEDs, it cuts through 360 degrees of darkness, easily lighting up an entire tent or room.

Its collapsible design allows for easy brightness adjustment and compact storage, making it as small as a phone when collapsed. Constructed with military-grade materials, it is waterproof and able to survive a 10-foot drop, ensuring reliability in tough conditions. This lantern is designed for simplicity, requiring no complicated setup or tools, and operates without buttons, making it easy to use even in the dark. It offers up to 90 hours of lighting on a single set of batteries, providing long-lasting illumination.

2. SETUP

2.1 Battery Installation

The Vont LED Camping Lantern requires 3 AA batteries (included). To install or replace batteries:

1. Unscrew the base of the lantern by turning it counter-clockwise.
2. Insert 3 AA batteries into the battery compartment, ensuring correct polarity (+/-).
3. Screw the base back onto the lantern by turning it clockwise until secure.



Image: Vont LED Camping Lantern showing the lantern and included AA batteries.

3. OPERATING INSTRUCTIONS

3.1 Turning On/Off and Brightness Adjustment

The Vont LED Camping Lantern features a unique collapsible design that controls both power and brightness:

- To turn on the lantern, simply pull the top section upwards to expand it. The LEDs will illuminate automatically.
- To adjust brightness, continue to pull the top section further upwards for more light, or push it downwards to reduce light.
- To turn off the lantern, fully collapse the top section back into the base. The LEDs will turn off.



COLLAPSIBLE BRIGHTNESS CONTROL

Adjust the height of the lantern to control the amount of light emitted. No switches or buttons necessary.

Image: Vont LED Camping Lantern demonstrating how collapsing and expanding controls brightness.

3.2 Using the Handles

The lantern is equipped with two metal handles for versatile use:

- Use the handles to carry the lantern comfortably.
- Hang the lantern from a tent hook, branch, or other suitable fixture for overhead illumination.

4. MAINTENANCE

4.1 Cleaning

Wipe the exterior of the lantern with a soft, damp cloth. Do not use abrasive cleaners or immerse the entire unit in water.

4.2 Battery Replacement

When the light begins to dim, it is time to replace the batteries. Follow the steps in Section 2.1. For prolonged storage, remove the batteries to prevent leakage and damage to the lantern.

5. TROUBLESHOOTING

5.1 Light Not Turning On

- Ensure batteries are correctly installed with proper polarity.
- Check if the batteries are depleted and replace them if necessary.
- Make sure the lantern is fully expanded to activate the light.

5.2 Dim Light Output

- Replace old batteries with fresh ones.
- Fully expand the lantern to achieve maximum brightness.

6. SPECIFICATIONS

Brand	Vont
Model Name	VNT-CL02
Light Source Type	Light Emitting Diode (LED)
Brightness	140 Lumen
Battery Life	90 Hours
Number of Batteries	3 AA batteries required (included)
Material	Acrylonitrile Butadiene Styrene (ABS)
Water Resistance Level	Water Resistant
Product Dimensions	3.4"L x 3.4"W x 9.8"H
Item Weight	7.6 Ounces

7. WARRANTY & SUPPORT

7.1 Warranty Information

This Vont LED Camping Lantern is covered by a Lifetime Warranty against loss, theft, and defects in materials and workmanship for as long as you own the lanterns. It is CE/RoHS/EMC certified.

7.2 Customer Support

For any questions, concerns, or warranty claims, please contact Vont customer service through their official website or the retailer where the product was purchased. Please have your product model number and purchase details ready for faster assistance.