

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

## Status SLEDREDLANT1PKB2

# STATUS High Power 13 LED Lantern Instruction Manual

Model: SLEDREDLANT1PKB2

## INTRODUCTION

Thank you for purchasing the STATUS High Power 13 LED Lantern. This manual provides important information regarding the safe operation, maintenance, and specifications of your new lantern. Please read this manual thoroughly before use and retain it for future reference.

## SAFETY INFORMATION

Always observe the following safety precautions to prevent injury or damage to the lantern:

- Do not look directly into the LED light source when the lantern is on, as this may cause eye damage.
- Keep the lantern away from water and moisture. This product is not waterproof.
- Do not attempt to disassemble or modify the lantern. Repairs should only be performed by qualified personnel.
- Ensure batteries are inserted with correct polarity (+/-). Incorrect insertion can cause damage or leakage.
- Remove batteries if the lantern will not be used for an extended period to prevent leakage and corrosion.
- Keep out of reach of children.

## PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x STATUS High Power 13 LED Lantern
- 4 x D Batteries (included)

## SETUP

### Battery Installation

The STATUS High Power 13 LED Lantern requires 4 x D batteries for operation. These batteries are included with your purchase.

1. Locate the battery compartment cover, typically at the base or rear of the lantern.
2. Twist or unlatch the cover to open the compartment.
3. Insert the 4 D batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the

compartment.

4. If a battery saving plastic tag is present, remove it before inserting batteries.
5. Securely close the battery compartment cover.



Figure 1: Front view of the STATUS High Power 13 LED Lantern, illustrating its design and the array of 13 LED bulbs.

## OPERATING INSTRUCTIONS

### Turning On/Off

The lantern is equipped with a simple on/off switch.

- To turn the lantern **ON**, slide the switch to the 'ON' position. The 13 LEDs will illuminate.
- To turn the lantern **OFF**, slide the switch to the 'OFF' position. The LEDs will turn off.

## MAINTENANCE

### Cleaning

To clean the lantern, wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the lantern in water.

### Battery Replacement

When the light output diminishes, it is time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section to replace the 4 x D batteries.

*Note: Dispose of used batteries responsibly according to local regulations.*

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lantern does not turn on.	Batteries are dead or incorrectly inserted. Plastic battery saving tag not removed.	Check battery polarity and ensure they are fresh. Remove any plastic battery saving tags.

Problem	Possible Cause	Solution
Light is dim.	Batteries are low.	Replace all 4 D batteries with new ones.
Intermittent light.	Loose battery connection or faulty switch.	Ensure batteries are seated firmly. If problem persists, contact customer support.

## SPECIFICATIONS

<b>Brand</b>	Status
<b>Model Number</b>	SLEDREDLANT1PKB2
<b>Light Source Type</b>	LED
<b>Number of Lights</b>	13
<b>Power Source</b>	Battery Powered
<b>Battery Type</b>	4 x D Batteries
<b>Voltage</b>	6 Volts
<b>Material</b>	Plastic
<b>Colour</b>	Red
<b>Product Dimensions</b>	16 x 10.01 x 10.01 cm
<b>Item Weight</b>	500 g
<b>Area Lighting Classification</b>	IP00

## WARRANTY AND SUPPORT

For product support or warranty inquiries, please contact the manufacturer:

**Status International (UK) Ltd**

Unit 1, Whitehall 26 Business Park

Heathfield Lane, Birkenshaw

Bradford, BD11 2HW

United Kingdom

Please retain your proof of purchase for warranty claims.

