

Stoves 050528004

Stoves 050528004 Small Oven Inner Door Glass Instruction Manual

1. INTRODUCTION

This manual provides essential instructions for the safe and correct installation, maintenance, and care of your Stoves 050528004 Small Oven Inner Door Glass. Please read this manual thoroughly before proceeding with installation or maintenance to ensure proper function and safety. Retain this manual for future reference.

2. PRODUCT OVERVIEW

The Stoves 050528004 is a genuine replacement inner door glass panel designed specifically for compatible Stoves small oven models. This component is crucial for maintaining the thermal efficiency and safety of your oven. It is made from durable glass engineered to withstand high temperatures.



Image 1: The Stoves 050528004 Small Oven Inner Door Glass. The glass panel features markings indicating the correct

orientation ('THIS WAY UP') and insertion method ('SLIDE FULLY IN TO STOP') for proper installation.

This inner door glass is intended for use exclusively with Stoves oven models that specify part number 050528004.

3. SAFETY INFORMATION

- Always disconnect the oven from the main power supply before attempting any installation, removal, or maintenance.
- Wear appropriate personal protective equipment, such as cut-resistant gloves and safety glasses, when handling glass components to prevent injury.
- Glass can be fragile. Handle the inner door glass with care to avoid breakage.
- Ensure the oven and all its components are completely cool before beginning work.
- If you are unsure about any step, consult a qualified technician.

4. SETUP AND INSTALLATION

Follow these steps carefully to install the Stoves 050528004 Small Oven Inner Door Glass:

1. **Preparation:** Ensure the oven is completely cool and disconnected from the electrical supply. Open the oven door fully.
2. **Accessing the Inner Glass:** Depending on your specific oven model, you may need to remove the oven door or disassemble parts of the door to access the inner glass panel. Refer to your oven's primary instruction manual for detailed door removal procedures.
3. **Removing the Old Glass:** Carefully identify how the existing inner glass is secured. This typically involves clips, screws, or a sliding mechanism. Gently remove the old glass panel. Dispose of any broken glass safely.
4. **Cleaning:** Clean any debris, grease, or residue from the oven door frame and surrounding areas where the new glass will be installed.
5. **Installing the New Glass:**
 - Observe the markings on the new glass panel. Locate the text "**THIS WAY UP**" and ensure this side is oriented correctly.
 - Position the glass panel into its designated slot. The markings "**SLIDE FULLY IN TO STOP**" indicate the direction and extent of insertion. Gently slide the glass panel until it reaches the stop point and is securely seated.
6. **Securing the Glass:** Reattach any clips, screws, or securing mechanisms that hold the inner glass in place. Ensure all components are tightened appropriately, but do not overtighten, as this can damage the glass.
7. **Reassembly:** Reassemble the oven door if it was disassembled, and reattach it to the oven if it was removed.
8. **Functionality Check:** Gently open and close the oven door to ensure it operates smoothly and the glass is stable.
9. **Reconnect Power:** Once installation is complete and verified, reconnect the oven to the main power supply.

5. OPERATING CONSIDERATIONS

The inner door glass is an integral part of your oven's thermal insulation system. While the glass is designed for high temperatures, avoid direct impact or placing heavy objects on the oven door when open, as this can stress the glass.

6. MAINTENANCE AND CLEANING

Regular cleaning of the inner door glass helps maintain oven efficiency and visibility.

- Ensure the oven and glass are completely cool before cleaning.
- Use a soft cloth or sponge with a non-abrasive glass cleaner or a solution of warm water and mild dish soap.
- Avoid using harsh chemicals, abrasive pads, or metal scrapers, as these can scratch or damage the glass surface.
- Wipe the glass dry with a clean, lint-free cloth to prevent streaks.

7. TROUBLESHOOTING

- **Glass does not fit:** Double-check that the model number of your oven matches the compatibility requirements for the Stoves 050528004 inner door glass. Ensure the glass is oriented correctly according to the "THIS WAY UP" marking and fully inserted as indicated by "SLIDE FULLY IN TO STOP".
- **Glass breaks during installation:** This indicates improper handling or excessive force. Discard broken glass safely and obtain a new replacement part. Review the safety and installation instructions carefully before attempting re-installation.
- **Oven door does not close properly after installation:** Verify that the glass is correctly seated and all securing mechanisms are properly reattached. Ensure no components are obstructing the door's movement.







8. SPECIFICATIONS

Attribute	Detail
Brand	Stoves
Model Number	050528004
Manufacturer Reference	46392-050528004
Material	Glass
ASIN	B018MPU6YY

9. WARRANTY AND SUPPORT

Warranty information for replacement parts is typically provided with the original appliance or can be obtained directly from the manufacturer. For specific warranty details or technical assistance, please contact Stoves customer support or refer to the documentation that came with your oven. For further assistance, please visit the official Stoves website or contact their customer service department.

Related Documents - 050528004

	<p>Stoves Richmond DX 100/110cm Electric Induction Zoneless Installation Instructions</p> <p>Official installation instructions for the Stoves Richmond DX 100/110cm Electric Induction Zoneless range cooker, covering safety, dimensions, electrical connection, and commissioning.</p>
	<p>Stoves Richmond 90cm Dual Fuel Installation Instructions</p> <p>Official installation instructions for the Stoves Richmond 90cm Dual Fuel range cooker, covering regulations, dimensions, electrical and gas connections, commissioning, technical data, and energy efficiency.</p>
	<p>Stoves Richmond 100/110cm Electric Induction Range Cooker Installation Guide</p> <p>Official installation instructions for the Stoves Richmond 100/110cm Electric Induction range cooker. This guide covers pre-installation checks, dimensions, electrical connection procedures, and final commissioning steps.</p>
	<p>Stoves Richmond 90cm Dual Fuel Installation Instructions</p> <p>This document provides installation instructions for the Stoves Richmond 90cm Dual Fuel cooker. It covers essential information on regulations, safety, electrical and gas connections, dimensions, clearances, commissioning, technical data, and energy efficiency.</p>
	<p>Stoves Richmond DX 90CM Electric Induction Installation Instructions</p> <p>Comprehensive installation guide for the Stoves Richmond DX 90CM Electric Induction cooker, detailing safety precautions, physical installation steps, electrical connections, dimensions, clearances, commissioning, technical specifications, and energy data.</p>
	<p>Stoves EI (90 cm) Models Installation Instructions</p> <p>Comprehensive installation guide for Stoves EI (90 cm) models, covering before installation checks, dimensions, clearances, electrical connections (single and three phase), and commissioning procedures.</p>

