

[Manuals.plus](#) /

› [Terry](#) /

› Terry C-Rattan 680 Cabinet User Manual

Terry C-Rattan 680

Terry C-Rattan 680 Cabinet User Manual

Model: C-Rattan 680 | Brand: Terry

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Do not exceed the maximum weight limit of **20 kg (44 lbs) per shelf**. Overloading can cause the shelf to collapse.
- Be cautious when opening the doors, as they can open up to **180 degrees**. Ensure sufficient clearance to prevent impact.
- For secure closure, the cabinet is **padlock ready**. A padlock is not included and must be purchased separately.
- Always follow the provided assembly instructions carefully for safe and stable installation.
- This product is designed for storage. Do not climb on or lean heavily against the cabinet.

2. PRODUCT OVERVIEW

The Terry C-Rattan 680 is a durable, two-door storage cabinet designed for various organizational needs. It features a stylish rattan effect on the door exterior and includes one height-adjustable internal shelf.



Image 1: The Terry C-Rattan 680 cabinet shown in an outdoor environment, highlighting its design and potential use.

Key Features:

- **Material:** High-quality, durable polypropylene plastic.
- **Design:** Rattan effect exterior on doors, grey color.
- **Storage:** Two doors, one height-adjustable internal shelf.
- **Capacity:** Maximum 20 kg (44 lbs) per shelf.
- **Security:** Doors are padlock ready (padlock not included).

- **Eco-Friendly:** Made from 100% recycled plastic.

3. SETUP AND ASSEMBLY

The Terry C-Rattan 680 cabinet is designed for straightforward assembly. Please ensure all components are present before beginning. Assembly instructions are included in the packaging.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the included assembly guide are present and undamaged.
2. **Prepare Work Area:** Choose a clean, flat, and spacious area for assembly.
3. **Assemble Base and Sides:** Follow the step-by-step diagrams in the provided manual to connect the base, side panels, and back panel. Components are designed to clip together securely.
4. **Install Feet:** Attach the cabinet feet to the base. Note that this step may require more effort than other clip-on components.
5. **Insert Shelf:** Position the internal shelf at your desired height. The shelf is adjustable and can be placed in various slots along the side panels.
6. **Attach Doors:** Securely attach the two doors to the cabinet frame. Ensure they swing freely and close properly.
7. **Final Inspection:** Once assembled, gently shake the cabinet to ensure stability. Inspect for any excess plastic from the molding process and carefully trim if necessary for a smooth finish.



Image 2: Diagram showing the external dimensions of the cabinet: 26.77 inches (W), 15.35 inches (D), and 36.02 inches (H).



Image 3: Interior view of the cabinet with both doors open, showing the single adjustable shelf and multiple slots for height customization.

4. OPERATING INSTRUCTIONS

Opening and Closing Doors:

- The cabinet features two hinged doors that open up to 180 degrees for full access to the interior.
- To open, gently pull the door handles. To close, push the doors until they click securely into place.

Adjusting Shelf Height:

- The single internal shelf can be adjusted to different heights to accommodate various item sizes.
- To adjust, empty the shelf, carefully lift it from its current position, and re-insert it into the desired slots on the side panels. Ensure it is level and securely seated.

Using the Padlock Feature:

- For added security, the cabinet doors are designed to accept a standard padlock (not included).
- Align the padlock loops on both doors and insert your padlock to secure the contents.



Image 4: Close-up view of the integrated loop on the cabinet door, designed for securing with a padlock (padlock not included).

5. MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your Terry C-Rattan 680 cabinet.

- **Cleaning:** Clean the cabinet surfaces with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic.
- **Product Care:** The manufacturer recommends "Hand Wash" for cleaning.
- **Inspection:** Periodically check all connections and the stability of the cabinet, especially if it is frequently moved or heavily loaded.
- **Environmental Conditions:** While durable, prolonged exposure to extreme weather conditions (e.g., intense direct sunlight,

freezing temperatures) may affect the material over time.

6. TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following common problems and solutions:

- **Doors do not close properly:**
 - Ensure the cabinet is assembled correctly and all panels are securely clipped into place.
 - Check if the cabinet is placed on a level surface. Uneven surfaces can cause misalignment.
 - Verify that nothing inside the cabinet is obstructing the doors from closing fully.
- **Shelf feels unstable:**
 - Confirm the shelf is correctly seated in the designated slots on both side panels.
 - Ensure the weight on the shelf does not exceed the maximum capacity of 20 kg (44 lbs). Distribute weight evenly.
- **Difficulty during assembly (e.g., parts not fitting):**
 - Refer to the detailed assembly instructions provided with the product.
 - Ensure you are using the correct parts for each step. Some parts may look similar.
 - Check for any excess plastic molding that might be preventing parts from fitting smoothly. Carefully trim if necessary.

7. SPECIFICATIONS

Brand	Terry
Model Name	C-Rattan 680
Model Number	1002815
Material	Polypropylene (Plastic)
Color	Grey
Product Dimensions (W x D x H)	68 cm x 39 cm x 91.5 cm (26.77" x 15.35" x 36.02")
Item Weight	7.29 kg (16.07 lbs)
Number of Doors	2
Number of Shelves	1 (adjustable)
Max Weight Capacity per Shelf	20 kg (44 lbs)
Lock Type	Padlock ready (padlock not included)
Installation Type	Freestanding
Assembly Instructions	Included
Country of Origin	Italy

8. WARRANTY AND SUPPORT

Warranty Information:

Specific warranty details for the Terry C-Rattan 680 cabinet are not provided in this manual. Please refer to the warranty documentation included with your purchase or contact the retailer or manufacturer directly for information regarding warranty coverage and terms.

Customer Support:

For further assistance, technical support, or to report missing/damaged parts, please contact the retailer from whom you purchased the product. You may also visit the official Terry website for additional support resources.

© 2024 Terry. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question