

Oliso TG-1600

Oliso TG1600 Smart Iron User Manual

Featuring iTouch Self-Lifting Technology

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use, maintenance, and troubleshooting of your Oliso TG1600 Smart Iron. Please read all instructions carefully before using the appliance and retain this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always unplug the iron from the electrical outlet when filling with water, emptying, or when not in use.
- Do not operate the iron with a damaged cord or if the iron has been dropped or damaged. Contact customer service for repair.
- To avoid the risk of electric shock, do not immerse the iron in water or other liquids.
- Keep the iron and its cord out of reach of children.
- Never direct steam at people or pets.
- Use the iron only for its intended purpose.
- The soleplate and water reservoir can become very hot. Handle with care.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Oliso TG1600 Smart Iron.



An image showing the yellow and white Oliso TG1600 Smart Iron with its unique iTouch self-lifting mechanism, alongside its accompanying ironing board cover packaging.

- **Soleplate:** Stainless steel surface for ironing.
- **Water Tank:** Reservoir for steam generation.
- **Temperature Dial:** Adjusts heat settings for various fabric types.
- **Steam Button/Selector:** Controls steam output.
- **Spray Mist Button:** Releases a fine water spray.
- **iTouch Lifters:** Automatically raise and lower the iron.
- **Power Cord:** 12-foot cord with 360° rotation.

4. SETUP

4.1 Unpacking

1. Carefully remove the iron and all accessories from the packaging.
2. Remove any protective films or labels from the soleplate.
3. Inspect the iron for any signs of damage. Do not use if damaged.

4.2 Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet.
2. Open the water tank fill cap.
3. Fill the water tank with tap water up to the 'MAX' fill line. Distilled or demineralized water is recommended to prolong the life of the iron, especially in hard water areas.
4. Close the fill cap securely.

5. OPERATING INSTRUCTIONS

5.1 Powering On and Temperature Selection

1. Plug the iron into a standard electrical outlet. The indicator light will illuminate.
2. Turn the temperature dial to the desired fabric setting (e.g., Silk, Wool, Cotton, Linen). Allow the iron to heat up until the indicator light signals it has reached the set temperature.

5.2 iTouch Self-Lifting Technology

The Oliso TG1600 features patented iTouch technology. When you release the handle, the iron's feet automatically lower, lifting the soleplate off the ironing board. This prevents scorching and reduces wrist strain. When you grasp the handle, the feet retract, allowing the soleplate to contact the fabric.

5.3 Steam Ironing

1. Ensure the water tank is filled.
2. Set the temperature dial to a steam-appropriate setting (typically Wool, Cotton, or Linen). Steam will not generate at lower temperatures.
3. Adjust the steam selector to the desired steam level.
4. For a burst of steam, press the steam burst button. This is useful for stubborn wrinkles.

5.4 Dry Ironing

1. Ensure the water tank is empty or the steam selector is set to the 'DRY' position.
2. Set the temperature dial to the appropriate fabric setting.
3. Proceed with ironing as usual.

5.5 Spray Mist

Press the spray mist button to release a fine mist of water onto the fabric. This can help to dampen dry areas and ease wrinkle removal.

5.6 Auto Shut-Off

For safety, the Oliso TG1600 is equipped with an auto shut-off feature. If the iron is left unattended horizontally for 30 seconds, or vertically (on its iTouch lifters) for 8 minutes, it will automatically turn off. To restart, simply move the iron.

6. MAINTENANCE

6.1 Emptying the Water Tank

After each use, or before storing, ensure the iron is unplugged and cooled. Open the water tank fill cap and invert the iron over a sink to drain any remaining water.

6.2 Cleaning the Soleplate

- Ensure the iron is unplugged and completely cool.
- Wipe the soleplate with a damp cloth and a mild, non-abrasive cleaner if necessary.
- Do not use abrasive scouring pads or metallic cleaners, as these can scratch the soleplate.

6.3 Descaling / Self-Cleaning

Regular descaling helps maintain optimal steam performance. Refer to the specific instructions for your model's self-cleaning function, typically involving filling the tank, heating the iron, and then activating a self-clean button over a sink to flush out mineral deposits.

6.4 Storage

Once the iron is cool and empty, store it upright on its iTouch lifters in a safe, dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; Auto shut-off activated; Temperature dial set to OFF.	Check power connection; Move iron to reactivate; Turn temperature dial to desired setting.
No steam or insufficient steam.	Water tank empty; Temperature too low; Steam vents clogged.	Fill water tank; Set temperature to steam-appropriate level; Perform self-cleaning.
Water leaking from soleplate.	Temperature too low for steam; Overfilled water tank; Fill cap not closed properly.	Increase temperature; Do not overfill; Ensure fill cap is secure.
Fabric sticking to soleplate.	Soleplate is dirty; Temperature too high for fabric type.	Clean soleplate; Adjust temperature setting.

8. SPECIFICATIONS

- **Model:** TG-1600
- **Wattage:** 1800 watts
- **Product Dimensions:** 7.9 x 12.8 x 5.6 inches
- **Item Weight:** 4.5 pounds
- **Base Material:** Stainless Steel
- **Cord Length:** 12 feet with 360° swivel
- **Safety Features:** iTouch Self-Lifting Technology, 30-second/8-minute Auto Shut-Off

9. WARRANTY AND SUPPORT

Your Oliso TG1600 Smart Iron is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or to inquire about replacement parts, please contact Oliso customer service through their official website or the contact information provided in your product packaging. When contacting support, please have your model number (TG-1600) and purchase date available.