

Melitta 1017-02

Melitta Enjoy 1017-02 Filter Coffee Machine User Manual

Model: 1017-02

1. INTRODUCTION

Thank you for choosing the Melitta Enjoy 1017-02 Filter Coffee Machine. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new coffee maker. Please read these instructions carefully before first use and keep them for future reference.

The Melitta Enjoy 1017-02 is designed to brew delicious filter coffee with ease. It features a glass jug, an Aroma Selector for adjustable coffee intensity, and a capacity for up to 15 cups.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. SETUP

3.1 Unpacking

Carefully remove all packaging materials from the coffee machine. Ensure all components are present: coffee machine base, glass jug, and removable filter holder.

3.2 First Use Cleaning

1. Wash the glass jug and the removable filter holder with warm, soapy water. Rinse thoroughly and dry.
2. Fill the water tank to the maximum level with fresh water.
3. Place an empty filter paper (size 1x4) into the filter holder.
4. Run the coffee machine through a full brewing cycle without coffee grounds. Discard the water.
5. Repeat this process once more to ensure the appliance is clean and free of any manufacturing residues.

3.3 Placement

Place the coffee machine on a stable, flat, heat-resistant surface, away from water sources and direct heat. Ensure there is adequate space around the appliance for ventilation.



Image: The Melitta Enjoy 1017-02 coffee machine positioned on a kitchen counter, ready for use. This image shows the overall design and size of the appliance.

4. OPERATING INSTRUCTIONS

4.1 Filling the Water Tank

1. Open the lid of the water tank.
2. Fill the water tank with fresh, cold water using the glass jug. The tank has a dual graduation scale for 10 large cups (125ml each) or 15 small cups (85ml each). Do not exceed the 'MAX' mark.
3. Close the lid securely.



Image: A close-up view of the transparent water tank with clear markings for water levels, indicating capacity for multiple cups.

4.2 Inserting the Filter and Coffee

1. Swivel out the filter holder.
2. Insert a Melitta 1x4 filter paper into the filter holder.
3. Add the desired amount of ground coffee into the filter paper. A general guideline is one level tablespoon of coffee per cup, but adjust to your personal preference.
4. Swivel the filter holder back into position until it clicks.



Image: A detailed view of the filter holder, showing the '1x4' size indication for compatible filter papers.

4.3 Using the Aroma Selector

The Aroma Selector allows you to adjust the coffee intensity from mild to strong. Rotate the knob on top of the machine to your preferred setting:

- **Mild:** For a lighter, more delicate coffee flavor.
- **Intense:** For a richer, stronger coffee flavor.



Image: A hand turning the Aroma Selector dial on the top of the coffee machine, illustrating how to choose between mild and intense coffee strengths.

4.4 Starting the Brewing Process

1. Ensure the glass jug is correctly placed on the warming plate.
2. Plug the power cord into a suitable wall outlet.
3. Press the illuminated On/Off button located on the side of the machine. The light will illuminate, indicating that the brewing process has started.
4. The coffee will begin to brew and drip into the glass jug.



Image: A finger pressing the red power button on the side of the coffee machine, indicating the start of operation.

4.5 Keep Warm Function and Automatic Shut-off

After brewing, the warming plate will keep the coffee hot for approximately 30 minutes. The machine will

then automatically shut off for safety and energy saving. If you wish to keep the coffee warm for longer, you will need to restart the machine for another 30-minute cycle, though it is recommended to consume coffee fresh for optimal taste.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your coffee machine.

5.1 Daily Cleaning

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. Remove the glass jug and the removable swivel filter holder. These parts are dishwasher-safe. Alternatively, wash them with warm, soapy water, rinse, and dry thoroughly.
3. Wipe the exterior of the coffee machine with a soft, damp cloth. Do not use abrasive cleaners or immerse the appliance in water.
4. Clean the warming plate with a damp cloth. Do not use harsh or abrasive materials that could scratch the surface.

5.2 Descaling

Over time, mineral deposits (limescale) can build up in your coffee machine, affecting performance and coffee taste. Descaling should be performed regularly, depending on the hardness of your water and frequency of use.

1. Use a commercially available descaling solution suitable for coffee machines, following the manufacturer's instructions.
2. Alternatively, you can use a mixture of white vinegar and water (e.g., 1 part vinegar to 2 parts water).
3. Pour the descaling solution into the water tank.
4. Place an empty filter paper in the filter holder and the empty glass jug on the warming plate.
5. Start a brewing cycle. Allow about half of the solution to brew through, then turn off the machine and let it sit for 15-30 minutes to allow the solution to work.
6. Turn the machine back on to complete the brewing cycle.
7. After descaling, run at least two full cycles with fresh, clean water to rinse out any descaling solution residue.

6. TROUBLESHOOTING

- **Coffee does not brew:** Ensure the machine is plugged in, the power button is pressed (illuminated), and the water tank contains water. Check if the filter holder is correctly seated.
- **Coffee is too weak:** Increase the amount of ground coffee, or adjust the Aroma Selector to the 'Intense' setting. Ensure you are using fresh coffee grounds.
- **Coffee is too strong:** Decrease the amount of ground coffee, or adjust the Aroma Selector to the 'Mild' setting.
- **Water leaks from the machine:** Check that the water tank lid is properly closed and the glass jug is correctly positioned on the warming plate. Ensure the filter holder is securely closed.
- **Slow brewing or unusual noise:** This may indicate limescale buildup. Perform a descaling cycle as described in Section 5.2.

- **Machine does not turn on:** Check the power cord connection and the wall outlet. If the issue persists, contact customer support.

7. SPECIFICATIONS

- **Brand:** Melitta
- **Model Number:** 1017-02
- **Color:** Black
- **Dimensions (L x W x H):** 18.8 x 23 x 31.8 cm
- **Weight:** 1.6 Kilograms
- **Capacity:** 1.2 Liters (approx. 10 large cups / 15 small cups)
- **Power:** 1000 Watts
- **Material:** Plastic (housing), Borosilicate Glass (jug)
- **Special Features:** Anti-drip system, Aroma Selector, Automatic shut-off (after 30 minutes), Illuminated On/Off button, Removable swivel filter holder, Dishwasher-safe jug and filter holder.



8. WARRANTY AND SUPPORT

Specific warranty information for the Melitta Enjoy 1017-02 is not provided in this document. Please refer to the warranty card included with your product or visit the official Melitta website for detailed warranty terms and conditions applicable to your region.

For technical support, spare parts, or further assistance, please contact Melitta customer service through their official website or the contact information provided in your product packaging.

Related Documents - 1017-02

	Melitta Enjoy Top Timer Coffee Maker: User Manual and Operating Instructions Comprehensive user manual for the Melitta Enjoy Top Timer filter coffee maker, covering setup, operation, features like timer and Aroma Selector, cleaning, maintenance, and safety guidelines.
	Melitta Enjoy Top Filter Coffee Maker User Manual This user manual provides comprehensive instructions for operating, cleaning, and maintaining the Melitta Enjoy Top filter coffee maker. It includes safety warnings, step-by-step brewing guides, and warranty information.
	Melitta Enjoy Therm & Enjoy Top Therm Filter Coffee Maker User Manual Comprehensive user manual and safety instructions for the Melitta Enjoy Therm and Enjoy Top Therm filter coffee makers, detailing operation, cleaning, maintenance, and safety precautions.
	Melitta Aroma Tocco Glass Coffee Maker User Manual Comprehensive user manual for the Melitta Aroma Tocco Glass Drip Coffee Maker (Model MCM009) by Melitta. Covers operation, safety precautions, cleaning, maintenance, and warranty details. Features include a touchscreen interface, programmable timer, and adjustable coffee strength.

	<u>Melitta Enjoy Therm Filter Coffee Maker User Manual and Safety Guide</u> Comprehensive user manual for the Melitta Enjoy Therm filter coffee maker, covering operation, safety instructions, cleaning, maintenance, and warranty information.
	<u>Melitta MCM004 Aroma Enhance Thermal Coffee Maker User Manual</u> User manual for the Melitta MCM004 Aroma Enhance Thermal coffee maker, providing comprehensive instructions on operation, safety, cleaning, maintenance, and warranty information from Melitta and Wabilogic Inc.

Documents - Melitta – 1017-02

[illegible]


[\[pdf\]](#)

Melitta Enjoy AromaSelector 1017 02 ekspres przelewowy ze szklanym dzbankiem czarny z filtrem do kawy tworzywo sztuczne 1 2 litra 15 filiżanek Sklep internetowy stylem.pl melitta enjoy aromaselector
litr upload files product filizanek 337755 ||

Melitta Enjoy AromaSelector **1017-02** ekspres przelewowy ze szklanym dzbankiem,
czarny, z filtrem do kawy, tworzywo sztuczne, 1,2 litra, 15 filianek Indeks: 337755
Producent: MELITTA EUROPA GMBH CO. KG Kod producenta: **1017-02** Cena:
293.24 zł Opis Melitta Enjoy AromaSelector **1017-02** ekspres przelewow...
lang:pl score:28 filesize: 380.33 K page_count: 3 document date: 2024-04-16

[pdf] Specifications

Kutzbach Daniel informationen zum Melitta Easy Therm extra Kanne Top Steel 1023 06 05 08 10
Betriebsmodus Operating mode Mode de FCM INFORMATIONEN ZUM ENERGIEVERBRAUCH ts
1745323859 melitta de media cd 89 25 Filter coffee machines User Instruction Manuals Cafeteras
GoteoEasy de Manualesmelitta 1745323859melitta gl 1*o8czvx* gcl
au*MTI3OTk2NDQ2NS4xNzQ3MjMxNTIzmelitta de Standby standby veille ☐ja yes oui ☒nein no non
Leistungsaufnahme Aus Modus Power consumption off Consommation Manualesmelitta
Consommation Melitta One 100801 fonctionnement Netzangaben V Hz Main specifications
Caractéristiques du réseau Manualesmelitta international content dam cp c me manuals
energieverbräuche coremelitta réseau ManualesBedienungsanleitungenmelitta
au*MTI3OTk2NDQ2NS4xNzQ3MjMxNTIz FilterkaffeemaschinenCafeteras
réseau BedienungsanleitungenManualesBedienungsanleitungenmelitta
FilterkaffeemaschinenFilterkoffiemachinesCafeteras
réseau BedienungsanleitungenGebruiksaanwijzingManualesBedienungsanleitungenmelitta be ||| |||
INFORMATIONEN ZUM ENERGIEVERBRAUCH / INFORMATION ON ENERGY CONSUMPTION /
INFORMATIONS SUR LA CONSOMMATION D NERGIE FILTERKAFFEE MASCHINE/ FILTER COFFEE
MACHINE/ MACHINE CAF FILTRE 2 Inhaltsverzeichnis/ Table of contents/ Table des matires 1 |||
INFORMATIONEN ZUM ENERGIEVERBRAUCH / INFORMATION ON ENERGY CONSUMPTION /
INFORMATIONS SUR LA CONSOMMATION D NERGIE FILTERKAFFEE MASCHINE/ FILTER COFFEE
MACHINE/ MACHINE CAF FILTRE 2 Inhaltsverzeichnis/ Table of contents/ Table des matires 1 |||
INFORMATIONEN ZUM ENERGIEVERBRAUCH / INFORMATION ON ENERGY CONSUMPTION /
INFORMATIONS SUR LA CONSOMMATION D NERGIE FILTERKAFFEE MASCHINE/ FILTER COFFEE
MACHINE/ MACHINE CAF FILTRE 2 Inhaltsverzeichnis/ Table of contents/ Table des matires 1 |||
INFORMATIONEN ZUM ENERGIEVERBRAUCH / INFORMATION ON ENERGY CONSUMPTION /
INFORMATIONS SUR LA CONSOMMATION D NERGIE FILTERKAFFEE MASCHINE/ FILTER COFFEE
MACHINE/ MACHINE CAF FILTRE 2 Inhaltsverzeichnis/ Table of contents/ Table des matires 1
INFORMATIONEN ZUM ENERGIEVERBRAUCH / INFORMATION ON ENERGY
CONSUMPTION / INFORMATIONS SUR LA CONSOMM ... tname: Product name:
Nom du produit : Typennummer: Type number: Numro de type : Enjoy; Enjoy Top
1017-02, 1017-04, 1017-03, 1017-13 Betriebsmodus Operating mode Mode de
fonctionnement Netzangaben ...
lang:es **score:22** filesize: 593.73 K page_count: 37 document date: 2025-04-16



[pdf]

Melitta MaxiCoffee Acheter entre le 01 05 2018 et 31 07 une cafetière filtre Melitta® Look® ou Enjoy®
Look Selection 1011 03 04 17 Deluxe 06 Timer 08 Therm odr melitta cafetiere mug maxicoffee images
ODR |||
P Offre valable du 01/05/2018 au 31/07/2018 Melitta *Offre diffre. Melitta France SAS
RCS 7 our l ... barres original dcoup sur l emballage du produit *Offre valable sur les
produits : Enjoy 1017-01; **1017-02**; 1017-09 , Enjoy Top 1017-03; 1017-04 , Enjoy
Therm 1017-05; 1017-06; 1017-10 , Enjoy Top ...
lang:fr **score:21** filesize: 1.03 M page_count: 2 document date: 2018-03-02



[pdf]

Untitled Bekijk de handleiding Melitta Enjoy Filter koffiezetapparaat Zwart bol original media s0Ay8mpVB9IyK |||

Enjoy Moderne filterkoffiezetapparaten met handige functies AromaSelector Druppelstop Uitneembare zwenkfilter 2284 Registered trademark of a company of the Melitta Group 01/2016 Enjoy Koffie om van te genieten ENJOY filterkoffiezetapparaten bieden u Melitta kwaliteit om volop van te genieten ... lang:nl score:20 filesize: 602.85 K page_count: 2 document date: 2021-08-12



[pdf]

Untitled Bekijk de handleiding Melitta Enjoy II Filter koffiezetapparaat Zwart Rood bol original media s5AE7rgzy1g48 |||

Enjoy Moderne filterkoffiezetapparaten met handige functies AromaSelector Druppelstop Uitneembare zwenkfilter 2284 Registered trademark of a company of the Melitta Group 01/2016 Enjoy Koffie om van te genieten ENJOY filterkoffiezetapparaten bieden u Melitta kwaliteit om volop van te genieten ... lang:nl score:20 filesize: 602.16 K page_count: 2 document date: 2021-08-12



[pdf]

Untitled Bekijk de handleiding Melitta Enjoy II Koffiezetapparaat Wit 1000W bol original media sm7VqNjQM9ZIn |||

Enjoy Une cafetière filtre moderne avec des fonctions pratiques AromaSelector Systme anti-gouttes Arrt automatique Marque dpose d une socit du Groupe Melitta 04/2017 3441 Enjoy Juste l essentiel ENJOY est une cafetière de qualit Melitta un prix comptitif Elle rpond aux diffrentes attentes des... lang:fr score:20 filesize: 287.04 K page_count: 2 document date: 2021-08-12

