

SANSUI SKY48FB11FA

Sansui 122 cm (48 Inches) Full HD LED TV SKY48FB11FA User Manual

1. INTRODUCTION

Thank you for purchasing the Sansui 122 cm (48 Inches) Full HD LED TV, model SKY48FB11FA. This manual provides essential information for the safe and efficient operation of your television. Please read it thoroughly before using the product and retain it for future reference.



Front view of the Sansui 48-inch Full HD LED TV, displaying a vibrant nature scene with two boats on a lake, surrounded by mountains and forests.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Do not block ventilation openings. Ensure adequate space around the TV for proper airflow.
- Avoid placing the TV on unstable surfaces.
- Protect the power cord from being walked on or pinched.
- Unplug the TV during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. WHAT'S IN THE BOX

Carefully unpack your Sansui TV and check that all the following items are included:

- 1 x Sansui LED TV
- 1 x User Manual (this document)
- 1 x Warranty Card
- 1 x Remote Control
- 1 x Power Cable / Power Supply Adapter

4. SETUP

4.1 Physical Installation

Your Sansui TV can be installed on a stand or wall-mounted. For wall mounting, ensure you use a compatible VESA mount (not included) and follow the instructions provided with the wall mount kit. For professional installation or wall mounting, please contact Sansui support at 18004194040.

4.2 Connecting Peripherals

Connect your external devices to the TV using the appropriate ports:

- **HDMI (x4):** For high-definition audio and video from Blu-ray players, gaming consoles, set-top boxes, etc.
- **USB (x2):** For connecting USB storage devices to play media files.
- **VGA (x1):** For connecting a computer.
- **Component (x1):** For connecting older video devices using YPbPr cables.

4.3 Power Connection

After connecting all necessary peripherals, plug the power cable into the TV's power input and then into a wall outlet. The TV will enter standby mode.

5. OPERATING

5.1 Power On/Off

Press the Power button on the remote control or on the TV to turn the TV on or off (standby mode).

5.2 Input Source Selection

Press the 'Source' or 'Input' button on your remote control to cycle through available input sources (HDMI 1, HDMI 2, USB, VGA, Component, TV Tuner). Select the desired input for your connected device.

5.3 Basic Remote Control Functions

- **Volume Up/Down:** Adjusts the sound level.
- **Channel Up/Down:** Changes TV channels.
- **Mute:** Silences the TV audio.
- **Menu:** Accesses the TV's main settings menu.
- **Navigation Buttons (Up/Down/Left/Right):** Navigate through menus.
- **OK/Enter:** Confirms selections.
- **Exit/Back:** Returns to the previous screen or exits the menu.

5.4 Picture and Sound Settings

Access the 'Menu' to adjust picture settings (e.g., Brightness, Contrast, Color, Picture Mode) and sound settings (e.g., Bass, Treble, Sound Mode, Balance) to your preference.

6. MAINTENANCE

Proper care will extend the life of your TV:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for TVs, applied to the cloth, not directly to the screen.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Do not use abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked to prevent overheating.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Check if the power cable is securely plugged into the TV and the wall outlet. Ensure the wall outlet is functioning.
No picture, but sound is present	Verify the correct input source is selected. Check cable connections to external devices.
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Verify audio cable connections for external devices.
Remote control not working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
Poor picture quality	Adjust picture settings in the menu. Check the quality of the input signal or source device.

If the problem persists after trying these solutions, please contact Sansui customer support.

8. SPECIFICATIONS

Detailed technical specifications for the Sansui SKY48FB11FA LED TV:

Feature	Specification
Brand	SANSUI
Model	SKY48FB11FA
Screen Size	48 Inches (122 cm)
Display Technology	LED
Resolution	1920 x 1080 (Full HD)
Aspect Ratio	16:9
Viewing Angle	178 Degrees
HDMI Ports	4
USB Ports	2
VGA Input	1
Component Input	1
Audio Output Mode	Stereo
Speaker Configuration	2 Channel
Audio Wattage	20 Watts
Power Source	AC
Mounting Type	Wall Mount
Product Dimensions (LxWxH)	109.7 x 64.2 x 8.8 cm
Item Weight	11.6 kg

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This product comes with a **1-year warranty** provided by the manufacturer from the date of purchase. Please retain your purchase invoice for warranty claims.

9.2 Customer Support






For any installation requests, wall mounting, product demonstrations, or technical assistance, please

contact Sansui support directly:

- **Sansui Support Helpline:** 18004194040

When contacting support, please provide the product's model name (SKY48FB11FA) and details from your purchase invoice.

Related Documents - SKY48FB11FA

	<p>Sansui AU-101 Stereo Amplifier Service Manual</p> <p>Comprehensive service manual for the Sansui AU-101 stereo amplifier, providing technical specifications, circuit analysis, troubleshooting guides, and maintenance procedures. Includes comparisons to models like the AU-555A.</p>
	<p>Sansui Electronics Corporation Service Manual</p> <p>This document provides service information for Sansui Electronics Corporation products, including parts lists and technical specifications.</p>
	<p>SANSUI ES-24F2 Full HD Monitor User Manual: Setup, Operation & Safety</p> <p>Comprehensive user guide for the SANSUI ES-24F2 Full HD Monitor. Covers installation, safety precautions, OSD menu settings, troubleshooting, and more.</p>
	<p>SANSUI ES-22F1 Full HD Monitor User Manual</p> <p>Comprehensive user manual for the SANSUI ES-22F1 Full HD Monitor, detailing safety precautions, installation, connectivity, panel controls, OSD menu settings, troubleshooting, and technical compliance information.</p>
	<p>SANSUI ES-27X3 Full HD Monitor User Manual</p> <p>User manual for the SANSUI ES-27X3 Full HD Monitor, covering safety instructions, accessories, installation, cable connections, panel controls, OSD menu usage, and troubleshooting.</p>



User Manual



Full HD Monitor
ES-22X3

When using this product, please read the manual carefully and keep it for future reference.
The manufacturer is not responsible for any damage caused by the use of this product.
© 2010 Sansui Co., Ltd. All rights reserved. Sansui is a registered trademark of Sansui Co., Ltd.

[SANSUI ES-22X3 Full HD Monitor User Manual](#)

Comprehensive user manual for the SANSUI ES-22X3 Full HD Monitor, covering safety instructions, installation, cable connections, panel controls, OSD menu settings, troubleshooting, and compliance information.