

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Jensen](#) /
- › [Jensen JWM6A AM/FM/DVD Stereo User Manual](#)

Jensen JWM6A

Jensen JWM6A AM/FM/DVD Stereo User Manual

Model: JWM6A

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Jensen JWM6A AM/FM/DVD Stereo. Please read this manual thoroughly before using the product to ensure proper functionality and safety.



Figure 1: Front view of the Jensen JWM6A AM/FM/DVD Stereo, showing the display, control buttons, and disc slot.

SAFETY INFORMATION

Always observe the following safety precautions:

- Ensure the unit is powered by a 12 Volts DC source.
- Do not expose the unit to moisture or extreme temperatures.
- Refer all servicing to qualified personnel.
- Disconnect power before performing any wiring or maintenance.

SETUP AND INSTALLATION

The JWM6A is designed for wall-mount installation and has a standard footprint for easy upgrade. Professional installation is recommended.

Wiring Connections

The unit requires 12 Volts DC power and includes a blunt-cut labeled wiring harness. Ensure correct polarity when connecting power and ground. The unit has a red positive and black ground wire. Speaker wires are labeled for zones A, B, and C.

- **Power:** Connect the red wire to a 12V DC positive source and the black wire to ground.
- **Speakers:** The unit supports 3 zones and 8 speaker outputs. Connect speakers to the corresponding labeled wires (e.g., A FL+, A FL- for Zone A Front Left).
- **Auxiliary Inputs:** Front 1/8" auxiliary audio input, Rear Audio RCA Inputs.
- **Video Output:** HDMI Video Output with JCOM link, RCA Video Output.
- **USB:** Front USB port for MP3/WMA files and iPod/iPhone connectivity.

Mounting

The overall dimensions are 10.4" (W) x 7.0" (D) x 6.25" (H). Mounting hole dimensions are 9.3" (W) x 5.12" (H) with a mounting depth of 5.12".

OPERATING INSTRUCTIONS

Basic Controls



Figure 2: Detailed view of the Jensen JWM6A control panel, highlighting buttons for power, playback, mode, and speaker zones.

- **Power Button:** Located on the top left. Press to turn the unit on or off.
- **Mode/Display Button:** Cycles through available audio sources (AM/FM, DVD/CD, USB, AUX, Bluetooth).
- **Volume Knob:** Central knob to adjust volume.
- **Speaker Zone Buttons (A, B, C):** Activate or deactivate speaker zones.
- **Disc Slot:** Insert DVDs or CDs into the slot located below the main controls.
- **USB Port:** Located on the bottom right for USB devices.
- **AUX Input:** 1/8" jack located next to the USB port.

Radio Operation (AM/FM)

- **Tuning:** Use the seek buttons (<< / >>) to tune to stations.
- **Presets:** Store up to 30 stations (12 AM/18 FM). Use numbered buttons (1-6) to recall presets.
- **Auto-Store/Preset Scan:** Automatically scans and stores strong stations.

Disc Playback (DVD/CD)

- Insert a disc into the slot. The unit will automatically switch to DVD/CD mode.
- Use playback controls (Play/Pause, Skip, Stop) for media navigation.
- The unit is compatible with DVD/CD-R/RW and MP3 discs.

Bluetooth Operation

- **Pairing:** Enable Bluetooth on your device and search for "JWM6A". Select to pair.
- **Streaming:** Once paired, stream audio (A2DP, AVRCP) from your Bluetooth-enabled device.
- **jControl App:** Download the free jControl app to control stereo functions from your mobile device.

USB and AUX Playback

- **USB:** Insert a USB drive into the front USB port for MP3/WMA file playback. Supports iPod/iPhone connectivity.
- **AUX:** Connect external audio devices to the front 1/8" auxiliary input or rear RCA inputs.

Audio Settings

- **Equalizer:** Select from 5 pre-set equalizer settings (User, Flat, Pop, Classical, Rock).
- **Tone Control:** Electronic Bass, Treble, Balance, and Fader control.

Clock and Alarm

- **Time/Alarm Clock:** Set and view the current time and alarm.
- **Alarm On/Off:** Activate or deactivate the alarm function.
- **Alarm Set:** Configure alarm time.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the unit's exterior. Do not use abrasive cleaners or solvents.
- **Disc Care:** Handle discs by their edges. Keep them clean and free of scratches.
- **Firmware Updates:** Check the manufacturer's website for any available firmware updates.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Incorrect wiring; Blown fuse; Low battery voltage.	Check power and ground connections; Replace fuse; Check vehicle battery. The unit has a low battery alarm.
No sound	Speakers not connected; Volume too low; Mute activated; Incorrect speaker zone selected.	Verify speaker wiring; Increase volume; Deactivate mute; Select correct speaker zone (A, B, or C).
Disc not playing/ejecting	Disc inserted incorrectly; Damaged disc; Shipping screw not removed (if applicable).	Re-insert disc correctly; Try a different disc; Ensure shipping screw is removed.
Bluetooth pairing issues	Device not in pairing mode; Unit not discoverable; Interference.	Ensure Bluetooth is enabled on device and unit; Move closer to the unit; Restart both devices.
Remote control not working	Dead batteries; Obstruction between remote and unit; Incorrect remote mode.	Replace batteries; Remove obstructions; Ensure remote is pointed at the unit's IR receiver.

SPECIFICATIONS

Power Requirement: 12 Volts DC

Tuner: Digital AM/FM Tuner, 30 Presets (12 AM/18 FM)

Bluetooth: A2DP, AVRCP Streaming Audio, APP Ready (jControl)

Disc Compatibility: Slot type DVD/CD-R/RW, MP3 Compatible

USB: Playback of MP3/WMA Files, Made for iPod/iPhone (USB Input)

Auxiliary Inputs: 1/8" Front Auxiliary Audio Input, Rear Audio RCA Inputs

Video Outputs: HDMI Video Output with JCOM link, RCA Video Output

Audio Outputs: 3 Zone / 8 Speaker Output, RCA Coaxial Input, Optical Input

Equalizer: 5 Pre-set settings (User, Flat, Pop, Classical, Rock)

Display: White LED Backlight LCD

Dimensions (Overall): 10.4" (W) x 7.0" (D) x 6.25" (H)

Mounting Hole Dimensions: 9.3" (W) x 5.12" (H)

Mounting Depth: 5.12"

Weight: Approximately 4 pounds

WARRANTY AND SUPPORT

Warranty Information

For specific warranty details, please refer to the warranty card included with your product or visit the official Jensen website. Keep your purchase receipt as proof of purchase for warranty claims.

Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact Jensen customer support. Visit the [Jensen Store on Amazon](#) or their official website for contact information and additional resources.

© 2024 Jensen. All rights reserved.

Related Documents - JWM6A

	<p>Jensen JWM22 AM/FM/Bluetooth/USB/HDMI/Aux Stereo - Product Overview and Specifications</p> <p>Detailed overview of the Jensen JWM22 stereo system, including product features, technical specifications, and performance metrics. This document covers Bluetooth streaming, USB playback, HDMI connectivity, and audio output capabilities.</p>
	<p>Jensen VX7022 Operation Manual - 6.2" Multimedia Receiver</p> <p>Comprehensive operation manual for the Jensen VX7022 Double DIN Multimedia Receiver. Discover features like DVD/CD playback, SiriusXM Ready, Bluetooth, iPod/iPhone integration, Pandora, built-in navigation, and smartphone connectivity via HDMI/MHL. Includes setup, controls, troubleshooting, and specifications.</p>



CMN86
6.8" 2 DIN CAPACITIVE TOUCH SCREEN
MULTIMEDIA MECHLESS RECEIVER
AM/FM/DC with Navigation
USB Multimedia Player
Front / Rear Camera Inputs
INSTALLATION &
OWNER'S MANUAL



JENSEN

[JENSEN CMN86 Installation and Owner's Manual: Features, Setup, and Operation](#)

Comprehensive installation and owner's manual for the JENSEN CMN86 6.8-inch 2 DIN multimedia mechless receiver. Learn about navigation, Bluetooth, camera inputs, and system operation.



CAR7TC
7-Inch Capacitive Touch Screen
Multimedia Receiver with Bluetooth
and Apple CarPlay®
INSTALLATION &
OWNER'S MANUAL



JENSEN

[Jensen CAR7TC 7-Inch Car Stereo with Android Auto & Apple CarPlay: Installation and User Manual](#)

Comprehensive user and installation manual for the Jensen CAR7TC car stereo, featuring a 7-inch TFT display, Android Auto, Apple CarPlay, Bluetooth, and USB connectivity. Includes setup, operation, troubleshooting, specifications, and warranty information.



CDR6221
DVD Multimedia Receiver with Bluetooth
Featuring a 6.2" Touch-Screen Display
INSTALLATION &
OWNER'S MANUAL



JENSEN

[Jensen CDR6221 DVD Multimedia Receiver Installation and Owner's Manual](#)

This is the official Installation and Owner's Manual for the JENSEN CDR6221 DVD Multimedia Receiver. It provides detailed information on installation, operation, features like Bluetooth and touchscreen, media compatibility, specifications, troubleshooting, and warranty for this car audio system.



MPR420
INSTALLATION/OWNER'S MANUAL
MPR420 Receiver with Bluetooth
USB | MP3 | AUX
Bluetooth



JENSEN

[Jensen MPR420 AM/FM Receiver with Bluetooth: Installation and Owner's Manual](#)

This manual provides detailed instructions for installing and operating the Jensen MPR420 AM/FM Receiver with Bluetooth. It covers preparation, wiring, control functions, audio modes (AM/FM, USB, Bluetooth, AUX), app integration, voice activation, troubleshooting, specifications, and warranty information.