

ETA 8594043284036

User Manual: Vacuum Cleaner Supplies

Model: 8594043284036

Compatible with ETA 0409, 1409, 2409, 2409 Piccolo, Swing, Piccolo 0409; Philips Balai 700 W, Basket 69, Basket HR

1. INTRODUCTION

This manual provides essential information for the proper use, installation, and maintenance of your ETA 8594043284036 vacuum cleaner supplies. These supplies are designed to ensure optimal performance and filtration for compatible vacuum cleaner models. Please read this manual thoroughly before use.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always ensure your vacuum cleaner is unplugged from the power outlet before attempting to replace or handle vacuum cleaner bags.
- Do not attempt to wash or reuse disposable vacuum cleaner bags. They are designed for single use.
- Keep new vacuum bags out of reach of children to prevent suffocation hazards.
- Dispose of used vacuum bags according to local waste disposal regulations.
- Use only genuine or recommended replacement bags for your specific vacuum cleaner model to ensure proper fit and filtration.

3. INSTALLATION GUIDE

Follow these steps to correctly install a new vacuum cleaner bag:



This image displays a single, new vacuum cleaner dust bag. The bag is made of a white, non-woven fabric material, designed to filter dust and debris. At the top, it features a sturdy brown cardboard collar with a central black circular opening, which is the inlet for dust and connects to the vacuum cleaner's hose.

- Preparation:** Ensure your vacuum cleaner is unplugged from the power supply.
- Open Vacuum Cleaner:** Locate and open the dust compartment or bag housing on your vacuum cleaner. Refer to your vacuum cleaner's specific user manual if you are unsure.
- Remove Old Bag:** Carefully remove the full or old vacuum bag. Many bags have a self-sealing mechanism to prevent dust from escaping. Dispose of the old bag properly.
- Insert New Bag:** Take a new ETA 8594043284036 vacuum bag. Align the cardboard collar of the new bag with the bag holder or inlet nozzle inside the vacuum cleaner's dust compartment.
- Secure Bag:** Push the bag firmly onto the holder until it clicks into place or is securely seated. Ensure the opening of the bag is fully connected to the vacuum's inlet.
- Close Compartment:** Close the dust compartment lid or housing securely. Ensure it is properly latched to maintain suction.
- Ready for Use:** You can now plug in your vacuum cleaner and resume cleaning.

4. OPERATION AND REPLACEMENT

The vacuum cleaner bag collects dust, dirt, and debris during operation. The frequency of bag replacement depends on usage and the type of debris collected.

- When to Replace:** Replace the vacuum bag when it is full, or when you notice a significant decrease in suction power, even if the bag does not appear completely full. Some vacuum cleaners have an indicator light or gauge that signals when the bag needs changing.
- Optimal Performance:** Regularly changing the bag ensures optimal suction power and maintains the filtration efficiency of your vacuum cleaner.

5. CARE AND MAINTENANCE

These vacuum bags require minimal maintenance beyond proper installation and timely replacement.

- Storage:** Store unused vacuum bags in a cool, dry place away from direct sunlight and moisture.
- Disposal:** Once full, remove the bag as described in the installation section and dispose of it in your household waste bin. Ensure the bag's opening is sealed if possible to prevent dust from escaping.

6. TROUBLESHOOTING

If you experience issues related to the vacuum bag, consider the following:

Problem	Possible Cause	Solution
Reduced Suction Power	Bag is full or nearly full.	Replace the vacuum bag with a new one.
Dust Escaping from Vacuum	Bag not installed correctly or damaged.	Ensure the bag is securely seated in its holder. Check for any tears or holes in the bag. Replace if damaged.
Bag Does Not Fit	Incorrect bag model for your vacuum cleaner.	Verify that the bag model (ETA 8594043284036) is compatible with your specific vacuum cleaner model. Refer to your vacuum cleaner's manual.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	8594043284036
Item Weight	160 g
Package Dimensions	24.38 x 17.02 x 4.83 cm
Date First Available	11 Jun. 2022
Compatibility	ETA: 0409, 1409, 2409, 2409 Piccolo, Swing, Piccolo 0409; Philips: Balai 700 W, Basket 69, Basket HR

8. WARRANTY AND CUSTOMER SUPPORT

For information regarding warranty coverage or if you require further assistance with your ETA vacuum cleaner supplies, please refer to the documentation provided with your vacuum cleaner or contact the manufacturer's customer support directly.

Please have your product model number (8594043284036) ready when contacting support.