**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Dixie Chopper B89

# Dixie Chopper B89 Wrapped Belt Instruction Manual

Model: B89 | Brand: Dixie Chopper

### Introduction

This manual provides essential information for the Dixie Chopper B89 Wrapped Belt, including compatibility, general installation guidelines, and maintenance procedures. This belt is a genuine replacement part designed to ensure optimal performance and longevity for specific Dixie Chopper lawn mower models.

### Product Overview

The Dixie Chopper B89 Wrapped Belt (Part # 2010B89W, which replaces 2006B89R) is a high-quality, durable component constructed from plastic and rubber. It is engineered to provide reliable power transfer within your lawn mower's drive system.



Image: A brown wrapped belt, coiled and ready for installation. This belt is a critical component for the drive system of compatible Dixie Chopper lawn mowers.

## Compatibility

This B89 Wrapped Belt is compatible with the following Dixie Chopper Classic lawn mower models. Always verify the original Dixie Chopper part number in your owner's manual or on the appropriate parts diagram for your specific model to ensure correct fitment.

- 2013 Classic 2760
- 2013 Classic 2960EFI
- 2013 Classic 3360HP
- 2014 Classic 2760
- 2014 Classic 2960EFI
- 2014 Classic 3360HP
- 2015 Classic
- 2016 Classic
- 2016 Classic Rev1
- 2017 Classic
- 2018 Classic
- Classic 2550 (2011)
- Classic 2750HP (2011)
- Classic 2760 (2011)
- Classic 3060HP (2011)
- Classic 3360HP (2011)
- Classic 3372HP (2011)
- MID2013 Classic 2960EFI
- MID2013 Classic 3360HP

## Installation Guidelines

Proper installation is crucial for the longevity and optimal performance of your new belt. Always refer to your specific Dixie Chopper lawn mower's service manual for detailed, model-specific instructions. The following are general steps:

1. **Safety Precautions:** Ensure the mower is turned off, the engine is cool, and the spark plug wire is disconnected to prevent accidental starting. Wear appropriate safety gear.
2. **Accessing the Belt System:** Depending on your mower model, you may need to remove deck covers, guards, or other components to gain access to the belt drive system.
3. **Removing the Old Belt:** Carefully note the routing of the old belt before removal. Release any tensioners or idler pulleys as required to remove the worn belt.
4. **Installing the New Belt:** Route the new B89 belt exactly as the old one was installed. Ensure it sits correctly in all pulley grooves.
5. **Tension Adjustment:** Re-engage any tensioners or idler pulleys. Verify that the belt has the correct tension according to your mower's service manual. Incorrect tension can lead to premature wear or poor performance.
6. **Final Checks:** Reinstall all removed covers and guards. Before starting the engine, manually rotate the blades or drive system to ensure the belt moves freely and correctly without obstruction. Reconnect the spark plug wire.

## Operation Considerations

After installing the new belt, observe its performance during initial operation to ensure everything is functioning correctly.

- **Smooth Engagement:** The belt should engage smoothly without jerking or slipping when the drive system is activated.

- **No Unusual Noises:** Listen for any squealing, grinding, or other abnormal noises, which could indicate improper installation or tension.
- **Correct Power Transfer:** Ensure the mower's blades or drive wheels receive consistent power without hesitation.

## Maintenance

Regular inspection and maintenance will extend the life of your Dixie Chopper B89 Wrapped Belt.

- **Inspect for Wear and Tear:** Periodically check the belt for cracks, fraying, glazing, or excessive stretching. Replace the belt if any significant wear is observed.
- **Clean Debris:** Keep the belt and pulleys free from grass clippings, dirt, and other debris that can cause slippage or damage.
- **Check Tension:** Ensure the belt maintains proper tension as specified in your mower's manual. Over-tensioning can stress the belt and pulleys, while under-tensioning can cause slippage and premature wear.

## Troubleshooting Common Issues

If you experience problems with your belt, consider the following common issues and their potential causes:

- **Belt Slipping:** May be caused by incorrect tension (too loose), worn belt, glazed pulleys, or debris on the belt/pulleys.
- **Excessive Noise (Squealing):** Often indicates incorrect tension (too tight or too loose), a misaligned pulley, or a worn belt.
- **Premature Wear/Breakage:** Can result from improper installation, incorrect tension, misaligned pulleys, foreign objects, or using an incorrect belt type.

If troubleshooting steps do not resolve the issue, consult your mower's service manual or contact a qualified service technician.

## Product Specifications

- **Part Numbers:** 2010B89W (replaces 2006B89R)
- **Material:** Plastic, Rubber
- **Belt Style:** V-belt
- **Product Dimensions (Approximate):** 16"L x 4"W (packaged dimensions: 10.50" x 4" x 16")
- **Weight (Approximate):** 15.2 ounces
- **Manufacturer:** Dixie Chopper
- **Package Quantity:** (1) Dixie Chopper B89 Wrapped Belt

## Warranty Information

Specific warranty details for this Dixie Chopper B89 Wrapped Belt are not provided in the available product information. For warranty inquiries, please refer to your Dixie Chopper lawn mower's main owner's manual or contact Dixie Chopper customer support directly.

## Customer Support

For further assistance, technical support, or to locate authorized service centers, please contact Dixie Chopper directly. Refer to your original product documentation or the official Dixie Chopper website for current contact information.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0198S3IG2**

More documents and user manuals: **https://manuals.plus/**