

DARTSLIVE DARTSLIVE-200S

DARTSLIVE-200S Soft Darts Board Instruction Manual

Model: DARTSLIVE-200S | Brand: DARTSLIVE

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your DARTSLIVE-200S Soft Darts Board. Please read this manual thoroughly before use to ensure safe and optimal performance.

The DARTSLIVE-200S is an app-enabled home darts board designed to replicate the experience of the DARTSLIVE2 machine. It offers a quiet playing experience with improved segment design and integrates with a dedicated mobile application for enhanced gameplay and tracking.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- DARTSLIVE-200S Darts Board x 1
- Soft Tip Darts x 2 sets (6 pieces)
- Extra Tips x 10 pieces
- USB Cable x 1
- Attaching Screws x 5
- Anchors x 5
- Instruction Manual x 1 (This document)
- Warranty Card x 1
- Installation Guide Sheet x 1



Figure 2.1: Package Contents. This image displays the DARTSLIVE-200S dartboard accessories: two sets of soft tip darts, extra tips, a USB cable, and mounting hardware (screws and anchors).

3. SPECIFICATIONS

Feature	Detail
Dimensions (W x H x D)	570.6mm x 530mm x 41.5mm (22.46" x 20.87" x 1.63")
Playing Area	Approx. 15.5 inches
Weight	Approx. 3.68kg (8.11 lbs)
Material	Plastic (Main Body)
Connectivity	Bluetooth HID profile 3.0 or later
Power Supply	USB cable (requires minimal current, can be powered by USB port)



Figure 3.1: Product Dimensions. This image illustrates the width (22.46 inches) and height (20.87 inches) of the DARTSLIVE-200S dartboard.

4. SETUP

4.1 Wall Mounting

The DARTSLIVE-200S is designed for wall mounting. Use the included installation guide sheet to mark the drilling points accurately. Ensure the mounting surface is sturdy enough to support the dartboard's weight.

1. Select a suitable location on a wall, ensuring sufficient space around the board for throwing darts.
2. Use the provided installation guide sheet to mark the positions for the 5 attaching screws. The center of the bullseye should be 173 cm (68.11 inches) from the floor.
3. Drill pilot holes at the marked positions. Insert the anchors if drilling into drywall or similar materials.
4. Secure the dartboard to the wall using the provided screws.



Figure 4.1: Installation Guide. This diagram provides detailed measurements and steps for mounting the dartboard, including the recommended height for the bullseye.

4.2 Power Connection

Connect the DARTSLIVE-200S to a power source using the supplied USB cable. The board requires minimal current and can be powered by a standard USB wall adapter (not included) or a USB port on a television or computer.



Figure 4.2: Power Connection. This image highlights the location of the power button and the USB port on the side of the dartboard for connecting the power cable.

5. OPERATING INSTRUCTIONS

5.1 App Installation and Connection

The DARTSLIVE-200S operates in conjunction with a dedicated mobile application. Download the "DARTSLIVE-200S" app from your device's app store.

- **System Requirements:**
 - iOS: iPhone and iPad with OS 7 or later

- Android: Device with Android 4.0 or later that supports the Bluetooth HID profile 3.0 or later

Note: The DARTSLIVE-200S app is designed for smartphones and tablet PCs and is not compatible with desktop computers.

- Ensure Bluetooth is enabled on your mobile device.
- Open the DARTSLIVE-200S app and follow the on-screen instructions to pair your device with the dartboard via Bluetooth.



Figure 5.1: App Connection Steps. This section of the installation guide illustrates the process of downloading the app and connecting the dartboard via Bluetooth.

5.2 Game Modes and Features

The DARTSLIVE-200S app provides various game modes and features:

- **DARTSLIVE2 Replication:** Experience the same game interface and scoring as the DARTSLIVE2 arcade machine.
- **DARTSLIVE Rating System:** Track your progress and calculate your DARTSLIVE rating, allowing you to monitor your skill improvement over time.
- **Original Games:** Access exclusive games not found on DARTSLIVE2, such as the "CHALLENGE" mode for intensive training on specific targets like the Bull or Triple 20.
- **Visual Enhancements:** Enjoy DARTSLIVE THEMES and AWARD MOVIES directly from your device, enhancing the playing experience.

5.3 Noise Reduction and Segment Design

The DARTSLIVE-200S features improved noise reduction compared to previous models, making it suitable for home use. The segments are designed for easy dart sticking and reduced bounce-outs.



Figure 5.2: Bullseye Detail. This image provides a close-up of the bullseye and the textured surface of the dartboard segments, designed for improved dart retention.



Figure 5.3: Segment Detail. This image shows the individual segments of the dartboard, emphasizing their construction for durability and quiet operation.

6. MAINTENANCE

To ensure the longevity and optimal performance of your DARTSLIVE-200S dartboard, follow these maintenance guidelines:

- **Cleaning:** Wipe the surface of the dartboard with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as they may damage the plastic.
- **Dart Tips:** Regularly inspect your soft tip darts. Replace worn or broken tips to prevent damage to the dartboard segments and ensure accurate scoring.
- **Storage:** If storing the dartboard for an extended period, disconnect it from power and store it in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING

If you encounter issues with your DARTSLIVE-200S, refer to the following common problems and solutions:

7.1 Dartboard Not Responding / Incorrect Scoring

If the dartboard does not register hits correctly or scores are inaccurate:

1. **Check Connection:** Ensure the USB cable is securely connected to both the dartboard and the power source.
2. **Restart Board:** Turn the dartboard off and then on again using the power button.
3. **Re-pair Bluetooth:** Disconnect and re-pair the dartboard with your mobile device via Bluetooth. Sometimes, removing the device from your phone's Bluetooth settings and re-adding it can resolve connection issues.
4. **App Restart:** Close and reopen the DARTSLIVE-200S app on your mobile device.
5. **Device Verification:** If the score in the app does not match the number you hit, press the CHANGE (Red) and START (Yellow) buttons simultaneously on the dartboard to re-verify the device. This process may require entering a color password within the app.



Figure 7.1: Device Re-verification. This section of the guide illustrates the process of pressing the CHANGE and START buttons to re-verify the dartboard's connection and scoring accuracy.

7.2 Darts Not Sticking / Bounce-Outs

If darts frequently bounce out or do not stick to the board:

- **Inspect Tips:** Ensure your soft tips are not worn, bent, or broken. Replace them with new tips as needed.
- **Dart Weight:** Verify that the darts you are using are appropriate for soft tip dartboards.

8. WARRANTY AND SUPPORT

For any issues or concerns regarding your DARTSLIVE-200S product, please refer to the warranty certificate included in your package. Contact the manufacturer directly as specified on the warranty certificate for repair or support services. Please note that product specifications and attachments may be upgraded or changed without prior notice.

