

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [LEGO](#) /

> [LEGO Bricks & More Valentines Cupid Dog 40201 Building Kit Instruction Manual](#)

LEGO 40201

LEGO Bricks & More Valentines Cupid Dog 40201 Building Kit Instruction Manual

Model: 40201

Brand: LEGO

INTRODUCTION

This manual provides instructions for assembling and caring for your LEGO Bricks & More Valentines Cupid Dog 40201 Building Kit. This set is designed for ages 7 and over and contains 150 pieces, offering an engaging building experience.



Figure 1: Front of the product packaging, displaying the assembled Cupid Dog.



Figure 2: Back of the product packaging, highlighting the dog's poseable elements.

SETUP AND ASSEMBLY

Carefully unpack all components from the product box. Ensure all 150 LEGO building elements are present before beginning assembly. Refer to the included building guide for detailed, step-by-step assembly instructions. It is recommended to sort pieces by color or type to facilitate the building process.



Figure 3: Front view of the assembled LEGO Cupid Dog.



Figure 4: Side view of the assembled LEGO Cupid Dog.

PRODUCT FEATURES

The LEGO Valentines Cupid Dog model incorporates several distinct features:

- **Pink Tongue Element:** A small pink piece representing the dog's tongue.
- **White Shirt and Bow Tie Elements:** Decorative pieces forming the dog's attire.

- **Posable Arms, Legs, Tail, and Ears:** These components can be adjusted to create various poses.
- **Rotating Head:** The head assembly allows for 360-degree rotation.
- **Red Heart Accessory:** A prominent red heart, designed to be held by the dog.
- **Bow-and-Arrow Element:** A small, brown bow and arrow accessory.



Figure 5: Detailed view of the bow and arrow accessory.




Figure 6: Detailed view of the red heart accessory.

OPERATION

Once the Cupid Dog model is fully assembled, its posable elements allow for interactive display. Gently adjust the arms, legs, tail, and ears to create various positions and expressions. The head can be rotated to face different directions. Avoid excessive force when posing to prevent damage to the LEGO elements.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your LEGO model, follow these care guidelines:

- **Cleaning:** For general cleaning, use a soft, dry cloth to remove dust. For more thorough cleaning, a mild soap solution can be used. Rinse the pieces thoroughly with clean water and allow them to air dry completely before reassembly or storage.
- **Storage:** Store the model in a clean, dry environment away from direct sunlight and extreme temperatures. Prolonged exposure to sunlight can cause discoloration, and extreme temperatures may lead to warping of the plastic elements.
- **Handling:** Handle the model gently to prevent pieces from detaching or breaking.

TROUBLESHOOTING

Missing Pieces

In the rare event that you discover missing pieces during assembly, please contact LEGO Customer Service directly. Provide the set number (40201) and the specific part numbers or descriptions of the missing elements. Do not attempt to force incompatible pieces together, as this may cause damage.

SPECIFICATIONS

Feature	Detail
Brand	LEGO
Model Number	40201
Item Type	Building Kit Toy
Material Type	Plastic
Number of Pieces	150
Item Dimensions	5.55 x 4.8 x 2.4 inches
Item Weight	50 Grams
Recommended Age	7 years and over (84 to 144 months)
Assembly Required	Yes
Operation Mode	Manual
Additional Features	Non Toxic



Figure 7: Product dimensions for reference.

WARRANTY AND SUPPORT

This product is provided without a manufacturer's warranty. For any product-related inquiries, assistance with assembly, or to report missing parts, please visit the official [LEGO Store on Amazon](#) or contact LEGO Customer Service directly through their official channels.

