

Noritz RC-7626M

Noritz Water Heater Kitchen Remote Control RC-7626M User Manual

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Noritz RC-7626M Water Heater Kitchen Remote Control. Please read this manual thoroughly before installation and operation, and keep it for future reference. This remote control is designed to provide convenient access to your water heater's functions from your kitchen.

SETUP AND INSTALLATION

The Noritz RC-7626M remote control is designed for wall-mounted indoor installation. Proper installation is crucial for optimal performance and safety. It is highly recommended that installation be performed by a qualified professional to ensure compliance with local codes and safety standards.

Installation Steps (Professional Installation Recommended):

1. **Power Disconnection:** Ensure the main power supply to the water heater is turned off at the circuit breaker before beginning any installation work.
2. **Mounting Location:** Select a suitable wall location in the kitchen, away from direct heat sources, moisture, and direct sunlight. Ensure there is sufficient space for wiring.
3. **Wiring Connection:** Connect the remote control wiring to the designated terminals on the water heater unit according to the wiring diagram provided with your water heater and remote control. Pay close attention to polarity.
4. **Mounting the Unit:** Secure the remote control unit to the wall using appropriate screws and anchors.
5. **Power Restoration:** Once all connections are secure and the unit is mounted, restore power to the water heater.
6. **Initial Test:** Perform an initial test to ensure the remote control communicates correctly with the water heater.

Refer to the detailed wiring diagrams and specific instructions provided with your water heater and remote

control for precise connection details.



This image shows the Noritz RC-7626M kitchen remote control unit. It typically features a display screen and various buttons for controlling water heater functions.

OPERATING INSTRUCTIONS

The Noritz RC-7626M remote control provides intuitive access to your water heater's primary functions. Familiarize yourself with the buttons and display indicators for efficient use.

Basic Functions:

- **Power On/Off:** Press the **POWER** button to turn the water heater on or off. The display will indicate the current status.
- **Temperature Adjustment:** Use the **UP** and **DOWN** arrow buttons to adjust the desired water temperature. The display will show the set temperature. Allow a few moments for the water heater to reach the new setting.
- **Display Indicators:** The digital display provides information such as current water temperature, error codes, and operational status. Consult the water heater's main manual for a complete list of display codes.
- **Function Buttons:** Additional buttons may be present for specific functions like bath fill, economy mode, or priority settings. Refer to the water heater's main manual for detailed explanations of these features.

Always ensure the remote control display is clear and free from obstructions for accurate readings.

MAINTENANCE

Regular, simple maintenance will help ensure the longevity and proper functioning of your Noritz RC-7626M remote control.

Cleaning:

- Wipe the surface of the remote control with a soft, dry cloth.
- For stubborn marks, lightly dampen the cloth with water. Do not use abrasive cleaners, solvents, or

chemical sprays, as these can damage the display or casing.

- Ensure no liquid enters the unit.

General Care:

- Avoid exposing the remote control to extreme temperatures, high humidity, or direct sunlight for extended periods.
- Do not drop or subject the unit to strong impacts.
- If the display becomes dim or unresponsive, check the power supply to the water heater. The remote control draws power from the main unit.

TROUBLESHOOTING

If you encounter issues with your Noritz RC-7626M remote control, try the following troubleshooting steps before contacting service personnel.

Common Issues and Solutions:

- **Remote Control Not Responding:**
 - Check if the water heater unit has power.
 - Ensure the wiring connections between the remote control and the water heater are secure.
 - If the water heater itself is off, turn it on.
- **Incorrect Temperature Display:**
 - Verify the temperature setting on the remote control.
 - Allow time for the water heater to adjust to the new temperature setting.
 - If the issue persists, there might be a problem with the water heater's temperature sensor. Consult a professional.
- **Error Code Displayed:**
 - Note the specific error code shown on the display.
 - Refer to your water heater's main instruction manual for a detailed explanation of error codes and recommended actions.
 - If the error code indicates a serious malfunction, contact a qualified service technician.
- **No Display:**
 - Confirm that the water heater is powered on.
 - Check the wiring connections for any disconnections or damage.
 - If the water heater is on and connections are secure, the remote control unit may require professional inspection or replacement.

For issues not covered here or if troubleshooting steps do not resolve the problem, contact Noritz customer support or a certified service technician.

SPECIFICATIONS

Below are the key specifications for the Noritz RC-7626M Water Heater Kitchen Remote Control:

Feature	Detail
Brand	Noritz
Model Number	RC-7626M
Product Type	Water Heater Kitchen Remote Control
Mounting Type	Wall-mounted
Installation Style	Indoor Installation
Power Source	Electric (powered by water heater unit)
Unit Count	1 unit

WARRANTY AND SUPPORT

For detailed warranty information regarding your Noritz RC-7626M Water Heater Kitchen Remote Control, please refer to the warranty card included with your product or visit the official Noritz website. Warranty terms and conditions may vary by region and purchase date.

If you require technical assistance, service, or have questions not addressed in this manual, please contact Noritz customer support. You can often find contact information on the Noritz official website or through your product retailer.

You can also visit the [Noritz Brand Store](#) for more product information and support resources.