Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Southwire /
- Southwire Surge Guard 35550 Hardwire Model 50 Amp Instruction Manual

Southwire 35550

Southwire Surge Guard 35550 Hardwire Model - 50 Amp Instruction Manual

Model: 35550

1. Introduction

The Southwire Surge Guard 35550 Hardwire Model is a 50 Amp electrical protection device designed for recreational vehicles (RVs). This unit continuously monitors shore power conditions and automatically disconnects power to your RV when it detects potentially damaging electrical issues. These issues include power surges, open ground, open neutral, low or excessive voltage, miswired pedestals, reverse polarity, and elevated neutral current conditions.

As a hardwire unit, the Surge Guard 35550 is permanently installed within the RV's electrical bay, offering enhanced security against theft and protection from environmental elements. An optional Remote LCD Display is available (sold separately) for convenient remote monitoring of your RV's electrical power status.

2. KEY FEATURES

- Automatic Reset: The unit automatically resets and restores power once safe electrical conditions are detected.
- Multi-Mode Surge Suppression: Provides comprehensive protection against various types of power surges.
- 128-Second Reset Delay: Incorporates a delay to protect sensitive appliances like air conditioning compressors during power restoration.
- 3850 Joules of Protection: Offers robust surge protection capacity.
- Easy Installation: Designed for straightforward hardwire installation into your RV's electrical system.
- **Built-in Intelligence:** Detects and protects against a wide range of power anomalies including open ground, open neutral, low/excessive voltage, miswired pedestals, reverse polarity, and elevated neutral current.




Figure 2.1: Diagram highlighting key features and connection points of the Surge Guard 35550.

3. Installation

Important: Installation of the Surge Guard 35550 requires knowledge of RV electrical systems. If you are not comfortable with electrical wiring, it is recommended to seek assistance from a qualified RV technician or electrician.

- 1. **Safety First:** Ensure all power sources to the RV (shore power, generator, inverter) are disconnected before beginning installation.
- 2. **Mounting Location:** Select a dry, protected location within the RV's electrical bay or compartment. The unit should be securely mounted using appropriate fasteners.

3. Wiring Connections:

- Identify the incoming 50 Amp shore power line and the outgoing line to the RV's main electrical panel.
- Connect the incoming shore power wires to the "LINE" terminals on the Surge Guard unit. Ensure correct polarity (Line 1, Line 2, Neutral, Ground).
- Connect the outgoing wires leading to the RV's main electrical panel to the "LOAD" terminals on the Surge Guard unit, maintaining correct polarity.
- All connections must be tight and secure to prevent arcing or overheating.
- 4. **Remote Display (Optional):** If using the optional remote LCD display, connect its cable to the "REMOTE PORT" on the Surge Guard unit.
- 5. **Verify Connections:** Double-check all wiring connections for correctness and security before restoring power.







Figure 3.1: Surge Guard 35550 unit with labeled connection points and indicators.

4. OPERATION AND INDICATOR LIGHTS

The Surge Guard 35550 provides visual feedback through a series of indicator lights on its front panel. Understanding these indicators is crucial for monitoring your RV's power status.

Indicator Light Status

Indicator	Color/State	Meaning
POWER ON	Green	Indicates the unit is receiving power and is operational.
CAUTION WHEN FLASHING	Orange (Flashing)	Indicates a detected fault condition. The unit has disconnected power to the RV. Refer to Line 1 and Line 2 indicators for specific fault.
LINE 1	Green	Line 1 voltage is within acceptable limits and connected.
LINE 1	Red	Fault detected on Line 1 (e.g., low/high voltage, open neutral/ground, reverse polarity). Power to RV is disconnected.
LINE 2	Green	Line 2 voltage is within acceptable limits and connected.
LINE 2	Red	Fault detected on Line 2 (e.g., low/high voltage, open neutral/ground, reverse polarity). Power to RV is disconnected.
SURGE	White (Lit)	Indicates that the surge protection components have been compromised due to a significant surge event. The unit may still provide other protections, but surge protection is no longer active. Replacement is recommended.

When a fault is detected, the unit will disconnect power to the RV and the "CAUTION" light will flash. Once the fault condition is resolved and stable power is restored, the unit will automatically re-connect power after a 128-second delay to protect connected appliances.

5. TROUBLESHOOTING

If your Surge Guard 35550 is not functioning as expected, refer to the following troubleshooting steps:

- No Power to RV, All Lights Off:
 - Check the shore power pedestal breaker. Ensure it is ON.
 - Verify the shore power cord is securely plugged into the pedestal and the RV.
 - Inspect the wiring connections to the Surge Guard unit for any loose or disconnected wires.
- "CAUTION" Light Flashing, No Power to RV:
 - Observe the "LINE 1" and "LINE 2" indicators. A red light indicates a specific fault on that line.
 - Common Faults:
 - Low/High Voltage: The voltage from the shore power is outside safe operating limits. Try a

different pedestal if available, or wait for utility power to stabilize.

- Open Ground/Neutral: Indicates a missing or faulty ground/neutral connection at the pedestal. Do not use this power source.
- **Reverse Polarity:** Hot and neutral wires are reversed at the pedestal. This is a dangerous condition; do not use this power source.
- Elevated Neutral Current: Indicates an imbalance or fault in the neutral circuit.
- Once the fault condition at the shore power source is corrected, the Surge Guard will automatically restore power after the 128-second delay.

• "SURGE" Light is Lit (White):

- This indicates that the internal surge protection components have absorbed a significant power surge and are no longer functional.
- While other protection features (voltage, ground, neutral) may still be active, the unit will no longer protect against future surges.
- It is highly recommended to replace the Surge Guard unit to ensure full protection.

• Unit Does Not Reset After Fault Clears:

- Ensure the fault condition is truly resolved. Sometimes, intermittent issues can cause repeated tripping.
- If the unit consistently fails to reset after a confirmed stable power source, contact Southwire customer support.

6. SPECIFICATIONS

MEASUREMENT SPECIFICATIONS

11.39"

5.30"

4.93"



Figure 6.1: Physical dimensions of the Surge Guard 35550.

Technical Specifications

Attribute	Value
Brand	Southwire

Attribute	Value
Model Number	35550
Current Rating	50 Amps
Voltage	120V/240V
Surge Protection	3850 Joules
Mounting Type	Hardwire (Bolt-On Mount)
Number of Poles	2
Product Dimensions (L x W x D)	12 x 6 x 4 inches (approximate)
Item Weight	5.13 pounds

7. MAINTENANCE

The Surge Guard 35550 is designed for minimal maintenance. However, periodic checks are recommended:

- Visual Inspection: Annually inspect the unit and its wiring connections for any signs of damage, corrosion, or loose terminals. Ensure the mounting is secure.
- **Indicator Lights:** Regularly observe the indicator lights during operation to ensure they are functioning correctly and to identify any fault conditions promptly.
- Surge Protection Status: If the "SURGE" light illuminates white, the surge protection components have been expended. While the unit may continue to provide other protections, it is recommended to replace the unit to maintain full surge protection capabilities.

8. SAFETY INFORMATION AND LEGAL DISCLAIMER

WARNING:

- Always disconnect all power sources to the RV before attempting any installation, inspection, or maintenance on the Surge Guard unit.
- Installation should only be performed by individuals with appropriate electrical knowledge or a qualified technician. Improper installation can lead to electrical shock, fire, or damage to the RV's electrical system.
- Do not operate the unit if it shows signs of physical damage or if any wiring is exposed.
- This product is designed to protect against electrical anomalies but cannot prevent all possible electrical damage, especially from direct lightning strikes.
- Product may contain materials cautioned by California Proposition 65.

9. SUPPORT

For technical assistance, warranty information, or to purchase replacement parts, please refer to the official Southwire website or contact their customer support directly.

Additional resources, including PDF user guides and manuals, may be available on the manufacturer's website.

Note: This manual provides general instructions. Always refer to the latest documentation provided by the manufacturer for the most accurate and up-to-date information.

© 2025 Southwire. All rights reserved.

Related Documents - 35550



Southwire Surge Guard 50A Model 34950 Troubleshooting Guide

A comprehensive troubleshooting guide for the Southwire Surge Guard 50A Portable Device with LCD Display (Model 34950), covering common issues, error codes, and solutions for RV power protection.



Southwire Elite 500 Series Portable Power Station: Operating and Maintenance Manual

This manual provides operating and maintenance instructions for the Southwire Elite 500 Series Portable Power Station (Model 53252), detailing its features, specifications, charging methods, device powering capabilities, troubleshooting, safety guidelines, and warranty information.



Southwire LED Overhead Lights Operating Instructions T90060, T90100, T90150, T90200

Operating instructions, installation guide, and warranty information for Southwire T90060, T90100, T90150, and T90200 LED Overhead Lights. Includes product specifications, wiring instructions, safety warnings, and claims procedure.



Sumner Cricket Operator's Manual - Pipe Trolley Operation and Assembly

Comprehensive operator's manual for the Sumner Cricket pipe trolley. Details include operating instructions for the hold-down strap, procedures for loading pipes, and a complete assembly parts list with part numbers and descriptions. Covers specifications like capacity and weight.



Southwire Reel Mac Reel Stands Operating Instructions (RM70, RM60)

Operating instructions for Southwire Reel Mac Reel Stands, models RM70 and RM60. Includes important safety information, description of operation, maintenance, and specifications.



Southwire Grasshopper Pipe Dolly Operator's Manual


Operator's manual for the Southwire Grasshopper Pipe Dolly, detailing instructions for attaching and detaching pipe, safety information, and product specifications.



[pdf] Troubleshooting Guide Guide

Troubleshooting Guide Surge Guard 50A Hardwire Model 35550 Southwire RV 505 00117 B DSG rvpower southwire 2017 08 |||

TROUBLESHOOTING GUIDE 561-01044 C Model **35550** 50A Surge Guard* Hardwire Portable Device Surge Guard* RV power products protect your RV from low quality or incorrect shore power. Normally, shore power should be around 115 120 Volts AC from L1 or L2 to Neutral, or 240V from L1 to L2. When power fal... lang:en score:42 filesize: 480.15 K page_count: 4 document date: 2017-08-10




[pdf] Instructions Guide

Surge Guard 35550 Hardwire Model 50 Amp35550 User Guide Southwire Amp91K1AlnF2 Lm media amazon images I 91K1AlnF2 L $\parallel\parallel$

INSTALLATION OPERATING INSTRUCTIONS OVER/UNDER VOLTAGE PROTECTION Should voltage drop below 102V or rise above 132V for more than 8-14 seconds, power to RV is turned off. MODEL 35530 SEE TIME DELAY INDICATOR MODEL 35550 HARDWIRE HARDWIRE with cover INPUT TERMINALS cover not required ...

lang:en score:41 filesize: 758.18 K page_count: 6 document date: 2017-08-10



[pdf] User Manual Instructions

Provided by ManualsAndMore Download User Manual TRC Surge Guard 35530 Installation Operating Instructions manualsandmore |||

MODEL 35530 HARDWIRE www.SurgeGuard.com INSTALLATION OPERATING INSTRUCTIONS MODEL **35550** HARDWIRE OVER/UNDER VOLTAGE PROTECTION Should voltage drop below 102V or rise above 132V for more than 8-14 seconds, power to RV is turned off. SEE TIME DELAY INDICATOR with cover INPUT TERMINALS cover no...


lang:en score:39 filesize: 1.3 M page count: 14 document date: 2019-07-24



[pdf] User Manual Instructions Frequently Asked Questions Specifications Guide V Guard Du 800 Plus User Manual Pdf Buying Guide for DUPS Inverters 507 00000 Surge FAQ DSG rypower southwire 2017 08 50A Model 44290 Southwire RV |||

FREQUENTLY ASKED QUESTIONS Visit www.rvpower.southwire.com for additional Surge Guard product infor ... sions for the Surge Guard units 35530 5.30 W x 11.12 L x 3.78 D 40100 7.78 W x 10.00 L x 5.10 D **35550** 5.30 W x 11.39 L x 4.93 D 40240 5.84 W x 14.50 L x 5.27 D 34830 4.68 W x 21.50 L x 3.86 D 4...


lang:en score:37 filesize: 350.54 K page_count: 4 document date: 2017-08-10



[pdf] User Manual Troubleshooting Guide Guide

Surge Guard 35550 Hardwire Model 50 Amp35550 User Manual Southwire Amp81geV Lu88Lm media amazon images I 81geV Lu88L |||

TROUBLESHOOTING GUIDE 561-01044 C Model **35550** 50A Surge Guard* Hardwire Portable Device Surge Guard* RV power products protect your RV from low quality or incorrect shore power. Normally, shore power should be around 115 120 Volts AC from L1 or L2 to Neutral, or 240V from L1 to L2. When power fal... lang:en score:36 filesize: 480.15 K page_count: 4 document date: 2017-08-10




[pdf] Warranty

SURGE GUARD* 44390 blueoxtowbars media installation instruction |||

SURGE GUARD* RV POWER PROTECTION Protect What You Value Most Limited Liability Warranty with Connect ... 6 D 8 Surge Guard* 30A 50A Full Protection Hardwires Model 35530 120V, 30A 2450 Joules Model 35550 120/240V, 50A 3850 Joules Optional Optional Total electrical protection from faulty park po...

lang:en score:31 filesize: 10.97 M page_count: 24 document date: 2019-01-18




[pdf] User Manual Instructions Troubleshooting Guide

INSTALLATION OPERATING INSTRUCTIONS 2 WARNING This Surge Guard device must be installed by a licensed electrician or an RV dealer PROTECTING SOURCE AND GENERATOR POWER 1 Disconnect power cord from source ® Locate the next to transfer switch TROUBLESHOOTING FEATURES MODEL 35530 35550 Operating Current 30 Amps 50 Voltage 120 Volts 240 Maximum Watts 3600 12000 3 Mode Protection Yes L N G Energy Dissipation 2450 Joules 3850 Spike 6500A per MOV Manual rvupgradestore v vspfiles assets


MODEL 35530 HARDWIRE www.SurgeGuard.com INSTALLATION OPERATING INSTRUCTIONS MODEL **35550** HARDWIRE OVER/UNDER VOLTAGE PROTECTION Should voltage drop below 102V or rise above 132V for more than 8-14 seconds, power to RV is turned off. SEE TIME DELAY INDICATOR with cover INPUT TERMINALS cover no...

lang:en score:29 filesize: 792.01 K page_count: 6 document date: 2015-11-12



[pdf] User Manual Troubleshooting Guide Guide

Model 35550 should be properly attached see installation manual The other end of the green wire grounded to RV If there is a voltage difference between incoming neutral white and ground unit will not allow power pass through it all connections TroubleShoot rvupgradestore v vspfiles assets 561-01044A TROUBLESHOOTING GUIDE Model **35550** 50A Hardwire Surge Guard with Optional Remote LCD Display Surge Guard protects your RV from low quality or incorrect shore power. Normally shore power should be around 115 120 Volts AC from L1 or L2 to Neutral, or 240V from L1 to L2. When power falls to... lang:en score:27 filesize: 529.61 K page count: 4 document date: 2015-11-13



[pdf] Instructions

INSTALLATION OPERATING INSTRUCTIONS Southwire RV * Trademark of Company LLC Registered in the United States Page 2 WARNING This Surge Guard 91K1AlnF2 L images na ssl amazon I CAREFULLY In event you have any questions concerning care this product please contact Customer Support REMOTE PORT Connection for optional Remote LCD display PN 40298 sold separately Caution Use 6 pin cable only 505 00115C 56 1 01044 C LOAD LINE 120 240V 50Amp When green light is on L1 between 102VAC to 132VAC red greater than or below and power shut off protect your coach 3 MODE SURGE PROTECTION Protects 39 s sensitive electronic systems appliances from potentially damaging surge events without interruptions 00115 DSG rvpower southwire 2017 08

INSTALLATION OPERATING INSTRUCTIONS OVER/UNDER VOLTAGE PROTECTION Should voltage drop below 102V or rise above 132V for more than 8-14 seconds, power to RV is turned off. MODEL 35530 SEE TIME DELAY INDICATOR MODEL 35550 HARDWIRE HARDWIRE with cover INPUT TERMINALS cover not required ...

lang:en score:24 filesize: 758.18 K page_count: 6 document date: 2017-08-10

[pdf] User Manual Instructions

35550 Manual RVupgradesTIME DELAY AND FAULT INDICATOR When unit is plugged in the red caution LED flashing indicating delay of 128 secondsrvupgradestore v vspfiles assets srsltid

AfmBOoo1EvPVeGG65XJaVhH9npioq73cHQ41rvjsyQTD75rlHWeiHtDH RVupgrades35550

secondsTIME AfmBOooOFp C8uib5IR2lzQIM8PpbwaAvKggl26sawVCfkqfsoanuZrvupgradestore

AfmBOoq0flP 8NRMH2jezzWpXCqtQ5Zh6NkY6YIJIUKiehVloRuJ6s 4rvupgradestore secondsLocate

Surge Guard® next to transfer switch Unit should be located where lights are clearly visible user


MOUNTING IN RV COMPARTMENT 1 rvupgradestore


AfmBOoo1EvPVeGG65XJaVhH9npioq73cHQ41rvjsyQTD75rlHWeiHtDHrvupgradestore AfmBOoozJC3wwi3kblUraQ7Zg49Gu33wELA3OXKmc3a gkWhjs9owheY 1 Locate gkWhjs9owheYrvupgradestore

AfmBOops2B6G2Q3b7OA1Sfit4ULx8vguPCsW6oUYM012T9svdPA38CaD |||

MODEL 35530 HARDWIRE www.SurgeGuard.com INSTALLATION OPERATING INSTRUCTIONS MODEL **35550** HARDWIRE OVER/UNDER VOLTAGE PROTECTION Should voltage drop below 102V or rise above 132V for more than 8-14 seconds, power to RV is turned off. SEE TIME DELAY INDICATOR with cover INPUT TERMINALS cover no...

lang:en score:24 filesize: 792.01 K page_count: 6 document date: 2015-11-12





[pdf] User Manual Borchure

SURGE GUARD Southwire RV n Requires manual reset after a ground fault Weather resistant Most economically priced protection 510 Joules of power surge 8mA trip level Easy T Pull™ handles Compatible with Surge Guard Lock Hasp model 34590 2 10 W x 20 15 L D Perfect for Pop ups and Travel Trailers SW SurgeGuard brochure v8 rvpower southwire 2018 03 Download Brochure Voltage Regulators III

SURGE GUARD* RV POWER PROTECTION Protect What You Value Most Complete Power Protection Your RV is ... 2.00 L x 3.86 D 7 Surge Guard* 30A 50A Full Protection Hardwires Model 35530 120V, 30A Model **35550** 120/240V, 50A Limited Lifetime Warranty Optional Optional Total electrical protection from... lang:en score:23 filesize: 2.01 M page_count: 24 document date: 2018-03-02



[pdf] Instructions

Installation InstructionsSouthwire RV Surge Protector Guard 50A Hardware Packaged 35550 MMRV OnlineSOUWIRINST00011cdn shopify s files 1 0461 7758 3255 SOUWIRINST00011 v 1620140929 ||| INSTALLATION OPERATING INSTRUCTIONS OVER/UNDER VOLTAGE PROTECTION Should voltage drop below 102V or rise above 132V for more than 8-14 seconds, power to RV is turned off. MODEL 35530 SEE TIME DELAY INDICATOR MODEL 35550 HARDWIRE HARDWIRE with cover INPUT TERMINALS cover not required ...

lang:en score:23 filesize: 906.66 K page_count: 6 document date: 2018-03-07



[pdf] Warranty Borchure


BrochureSouthwire RV Surge Protector Guard 50A Hardware Packaged 35550 MMRV

OnlineSOUWIRE00694 8 19 22cdn shopify s files 1 0461 7758 3255 SOUWIRE00694 22 v 1620140917

Ш

Surge Guard* 30A 50A Full Protection Hardwires Model 35530 120V, 30A Model 35550 120/240V, 50A Limited Lifetime Warranty Optional Optional Total electrical protection from faulty park power. Provides protection against: n Power surges n Reverse polarity n Open ground n Miswired pedestal ...

lang:en score:22 filesize: 417 K page_count: 3 document date: 2018-03-23



[pdf] Troubleshooting Guide Guide

Model 35550 RVupgradesSurge Guard provides protection to your RV by turning off power when the line voltages L1 or L2 fall below 102 Volts AC go above 132 Surge Guard 35550 TroubleShootrvupgradestore v vspfiles assets TroubleShoot srsltid AfmBOoryjnG E8E6pECgOEGaVImElhj7KpMsyIG


MGGzx2J34Iv8209d RVupgradesModel protects from low quality incorrect shore Normally should be

around 115 120 Neutral Surge TroubleShoot35550 AfmBOor3a

YLoy9lJH9ch51leHd0Eu1MtWjjZHPO9FbBWxOr73dhqppIrvupgradestore |||

561-01044A TROUBLESHOOTING GUIDE Model **35550** 50A Hardwire Surge Guard with Optional Remote LCD Display Surge Guard protects your RV from low quality or incorrect shore power. Normally shore power should be around 115 120 Volts AC from L1 or L2 to Neutral, or 240V from L1 to L2. When power falls to...

lang:en score:22 filesize: 529.61 K page_count: 4 document date: 2015-11-13



[pdf] User Manual Borchure

Surgeguard Brochure RV Power Protection Surge Guard 4 5 ® Basic Portable Model 44750 With Ground Fault 120V 30A 10 3 AWG Cord n Automatically shuts off the power when ground faults are present Requires manual reset after a fault Weather resistant Most economically priced protection 510 Joules of surge 8mA trip level Easy T Pull™ handles 2 W x 20 15 L D SW SurgeGuard brochure v18 rvpower southwire 2017 05 Download 50A Hardwire 40240 Southwire |||

SURGE GUARD RV POWER PROTECTION Protect What You Value Most Complete Power Protection Surge Guard ... 22.00 L x 3.86 D 7 Surge Guard 30A 50A Full Protection Hardwires Model 35530 120V, 30A Model 35550 120/240V, 50A Surge Guard 50A Hardwire Model 40240 RV Power Protection 120/240V, 50A, 60Hz O... lang:en score:22 filesize: 1.82 M page_count: 13 document date: 2017-05-17

[pdf] Warranty Borchure

SURGE GUARD*SW SurgeGuard Brochure Updateinvertersupply media data SW Update srsltid AfmBOooJhAedskB2roUVOnpdyJg2YGkAH6MaCR7IVgVuAB9MEM6eKTGU GUARD*SURGE UpdateSW AfmBOooJhAedskB2roUVOnpdyJg2YGkAH6MaCR7IVgVuAB9MEM6eKTGUinvertersupply AfmBOoo6JCvx3TmNKiZhFz66BnRsamxCZun3V0WgIDJmzHmHOblOSUgb GUARD* Inverter Supply35550 5 30 W x 11 39 L 4 93 D Model 35530 120V 30A 2450 Joules and Southwire Company LLC Any misuse abuse tampering or modifications SW AfmBOopjuTYkbPzYPIH3 euxrXzJ2c D3aLv8yyM837F9VBRDGmRW47Hinvertersupply SupplySURGE Supply35530 12 a 35550 modifications 35550 AfmBOopyQ3eQaXKt 3VqPri46pruOWW IT6wSIRY8Ase YnX1DywxDEZinvertersupply AfmBOoo6JCvx3TmNKiZhFz66BnRsamxCZun3V0WgIDJmzHmHOblOSUgbinvertersupply

AfmBOop3OteDE 1uniyHASaXimZZah VWFoKMlkUo92lhbmb0veVTLRw AfmBOoqGk
ESXwSxuvTqJtL2o2192i1tTmM5pHpnohsqYkyT9kVR5atcinvertersupply AfmBOord0rY1
1nL4axqY23YmVdAeNCH4Q RUWlqYLpe Y2lenMQnAl2invertersupply
AfmBOoqy3AeQzyD7qJs4zgfmL5H9KsLf3rirPZPwEIS9c8DdeD90zYTWinvertersupply
AfmBOopoWxThirj8n H8KernYMlLFoVejJeMRIRHdO30n7TXGIAtwCGQinvertersupply AfmBOoolkun
dSLLo 6xc39DD dsA9D SFEeqnu4vpPU6AnbORPwFJrinvertersupply modifications 35530 Fits all
portable Surge Guard models Voltage RegulatorsSW AfmBOooxQ57w
7VN409HgVOifV9JxWMAR58PPZNLcLlyDLK01YCWid6Vinvertersupply AfmBOorS02ylKl0
g7m41oD4coymy304D6uu8pc7YOvXWYeOxBVRYSFinvertersupply AfmBOopOSBC
y3WzC7TY4OH5Pgb 1nBCR3GbtVpwqadFMte6y SM5M2qinvertersupply AfmBOopQV3Un kva
8FFgPHF4sD6gPLuhLs i1yeJFlYvaPWT0O 1Tinvertersupply AfmBOooZtah
1mDxcOpk75WMBc7pWVC55DcxXkKsn6lYz dUv49lMnrginvertersupply
VWFoKMlkUo92lhbmb0veVTLRwinvertersupply

AfmBOoo6cBCnBj503 yLr68cid2eP9QLwBZ 7YKWySSa DbGxeTWzhl2invertersupply Regulators35550

AfmBOoqPwgLah6OJQ529prJmpqiytTHRZLNbVJbsY3zsFBBzuTEkZpNxinverter supply and the property of the property of

AfmBOorbquyxIVrTwbyEgvkSRG3tVm06mn74REVHRfcYUhjPothzrKORinvertersupply

 $AfmBOorBtR1oeVfWtzNgmnzcEvvHBdix\ gZBKrij0Rn91XCMLGVKBroYinverter supply$

A fm BOoo 0 agn Xiiqw 5W 2u Gpljdku KAm K1 JJ Peb M~bwiv 5Wr 15E7 LH~el 5 inverter supply~Afm BOop 48~vpz~bwiv 5Wr 15E7 LH~el 5 inverter supply~Afm BOOp 40~vpz~bwiv 5Wr 15E7 LH~el 5 inverter supply~Afm BOOp 40~vpz~bwiv 5Wr 15E7 LH~el 5 inverter supply~Afm BOOp 4

XAnlU1YFaENSv9STFhEmu x46IKOtdTv8zVLiaft0qinvertersupply

A fm BOoqwy 96 e EyZUJf Co 6B7 ENRQ4H30 yaWJGxCpd8 jUhz 6NgreOhMpV4 inverter supply and the control of the co


AfmBOoousyXE67CCdg wUm8ZDHBPqQixQ49rD g3pHKFPAFWzeOYoMQo RegulatorsSurge protects RVs from faulty power including high low voltage miswired pedestals open neutral ground reverse polarity surges It also SW


AfmBOorcMPeMViOvladH4c6A8NDQVRVOxRIIGgSG6I9wMBVSHna8pBi0invertersupply g3pHKFPAFWzeOYoMQoinvertersupply AfmBOopl yym1IXgGTRiCy4S12SaURHN u4GizcGFyLVrPA zVbuGjzC zVbuGjzCinvertersupply

AfmBOopVMT7BspfDV7uOO43VJ0h65x5GMIRixqd5oBjOM9jXEyQQbsIB

AfmBOooORBiYX3ERnxg1b1uPHUft ykp4pBpU9ikc4nszcP hhx38shVinvertersupply |||

SURGE GUARD* RV POWER PROTECTION Protect What You Value Most Limited Liability Warranty with Connect ... 6 D 8 Surge Guard* 30A 50A Full Protection Hardwires Model 35530 120V, 30A 2450 Joules Model 35550 120/240V, 50A 3850 Joules Optional Optional Total electrical protection from faulty park po... lang:en score:20 filesize: 10.73 M page count: 24 document date: 2019-01-18






[pdf] Warranty Borchure

Surge Guard* Power Protection Brochure Information Center Southwire RV SW SurgeGuard Update rvpower southwire 2019 02 Download Automatic Transfer Switch Model 41300 40299 Inverter Supply invertersupply media data |||

SURGE GUARD* RV POWER PROTECTION Protect What You Value Most Limited Liability Warranty with Connect ... 6 D 8 Surge Guard* 30A 50A Full Protection Hardwires Model 35530 120V, 30A 2450 Joules Model 35550 120/240V, 50A 3850 Joules Optional Optional Total electrical protection from faulty park po... lang:en score:19 filesize: 10.73 M page count: 24 document date: 2019-01-18



[pdf] User Manual Troubleshooting Guide Guide

Model 35530 should be properly attached see installation manual The other end of the green wire grounded to RV If there is a voltage difference between incoming neutral white and ground unit will not allow power pass through it all connections trouble rvupgradestore v vspfiles assets TROUBLESHOOTING GUIDE 561-01043A Model 35530 30A Hardwire Surge Guard with Optional Remote LCD D ... ANT CLIGNOTANT LIGNE 1 Vert=OK, Rouge= dfaut DISPOSITIF Pas de protection une fois allume Modle 35550 PORT DISTANCE 120V, 30 Amp Joules de Protection contre les surtensions 2450 PROTECTION DE L A... lang:en score:18 filesize: 529.19 K page count: 4 document date: 2015-11-13



[pdf] User Manual Owner's Manual Catalog

ASSEMBLED SOLUTIONS 27 juil 2023 — Check owner s manual of the generator to ensure was designed with JC 100 JHK 32MAG 64 BRM200 HD MODEL DESCRIPTION FUNCTION SC cd1096b9 e25f 4eeb 86a7 dee208e85c27 images thdstatic catalog Images cd |||

ASSEMBLED SOLUTIONS CATALOG SOUTHWIRE.COM THE COMPLETE SOUTHWIRE SOLUTION WIRE AND CABLE TOOLS ... le 34950 FULL PROTECTION 30A Portable 34931 50A Portable 34951 30A Portable 35530 50A Portable 35550 Over Under Voltage Input Open Neutral Protection Input Open Ground Protection Overheati...

lang:en score:17 filesize: 15.71 M page_count: 188 document date: 2023-06-22

[pdf] Instructions Borchure

Installation InstructionsSouthwire RV Electrical Surge Protector 30A Portable Frequency Protect MMRV OnlineSouthwire TechnologyResearchCorp 00001 1 24 BROC ba8ebeca e58c 416a 8dd0 3817cce3ad2fcdn shopify s files 0461 7758 3255 Southwire 3817cce3ad2f v 1620134365 InstructionsBrochureSouthwire 3817cce3ad2fSouthwire BROCcdn 1620134365cdn 1620134310 InstructionsBrochureBrochureSouthwire Guard 50AMP LED BROCSouthwire 1cdn 1620134310cdn 1620136606 InstructionsInstallation fd21a7f0 a039 4fd6 8a9f 2b4da1cc68fbSouthwire 2b4da1cc68fb 1620136625cdn InstructionsSURGE GUARD*BrochureBrochureSouthwire 2b4da1cc68fbSW SurgeGuard brochure v8Southwire 1620136625invertersupply media data SW v8 srsltid AfmBOoo7z 87ZHcpZollLHmDDPiW1H2z99ZtlBKzWrLXTuOrrmPP EG7cdn GUARD*SURGE v8SW EG7invertersupply AfmBOoqJTU15tv13AdUOUEofRG08 bN9sFz ljdss448Z9yRRLH1RXpAcdn AfmBOoqysQNMg FuAGJuOunkXxlpOhKgSRXZBsSZLGi1VB35I EgLhJGinvertersupply AfmBOoowsjEt Gs8OwzOzBFkTF33e0GPK1G7sxuHHxHBDUR3PWEzvvinvertersupply

AfmBOoo0YC4iSGrFierSov1lkCcCisul3k2 1PXILtfEm4XIZyGGBwUxinvertersupply
AfmBOorddAbTGqKoN85rroj3NfTfwQ8E0FJWpeU9l6krvkQz9uj7xnqHinvertersupply
AfmBOop3Bie6ztqVtyil DSAOowanmY34G0ArYGGqXNkF2bw3h0 2awMinvertersupply
AfmBOopLyuXEZ8w Pb ETF Gg5Cp6kQNL89KJfKkmL08AlAiA p3XzSuinvertersupply
AfmBOor9h4iN5SMCt5E26zs2yNxGtpB1dBFUGUqbxtUpF4BuUKVQwLuKinvertersupply
ljdss448Z9yRRLH1RXpAinvertersupply AfmBOopi3u8yBbmdBlA1pF3hqirVLv XNBy0ZWswf
16UnWMM088 alvcdn AfmBOorgCfXpMELH8Nx 4kM3OVAkmhWkegqMcR2YGewTPgiRcRHFw
cOinvertersupply AfmBOopXemnLGi3SHuCAHEZTND

SDOYKCYaKEmbKTJuuBFwU9ITqwEn0invertersupply AfmBOooPJ

0JKhn9s3oz6GTLh9CUb5nF7ASDa5CoFKf6NdXUxzXZm4nUinvertersupply alvinvertersupply

AfmBOorZOIvBpKPRIFO3LJ1YanaL8nVIx9cNtwqnvd9K1JYbttMDv3G6cdn

AfmBOopPzCTLNH5uQSfQo5MGCend1nTT1wpVwc i1RpUN9jn3Bdt fBWinvertersupply

AfmBOorZOIvBpKPRIFO3LJ1YanaL8nVIx9cNtwqnvd9K1JYbttMDv3G6invertersupply

AfmBOoqqoegkLcJnicOd5TqacqZcgRTzP4p84WBdAPiePlx7mfdkggvjinvertersupply

AfmBOoo5rEtMWm8D 9 2vAPYnPW2qYFW6Q tp5taffHyOFPha oZM5mBcdn

AfmBOopjguEran8qfWsFCe2Nul92H0UG1359GO5E6J3lU9YBW bUytMinvertersupply

oZM5mBinvertersupply AfmBOooeEJhVS7wYtLwMaj07y3QO4mn2khZX4LRR1FMiOZvG56Bxgr 5cdn

AfmBOopII dOJCLnqjJTQBbGc2reukFNm8WMBcHaUkv 1R KcHFvBLe2invertersupply 5invertersupply

AfmBOorXm0KLaunJThR75N3UIIedpFYRXPCuWCA 2nsqzlyAQPPrW5vlcdn AfmBOory0pD

aFOYJIMYkmlJrecy DIEHoPFu7sRw8OhwTt7GlqpdywPinvertersupply

AfmBOorUZy6Ux5J6lybwahdlfV0GuflFt6Bydd70ohCOZhEkqlvlOBiJinvertersupply AfmBOoqQu

yqlWSoQ5s 4EtJR4YUo77M agh96Se9GzEoeSlJjgSfn8Ninvertersupply


AfmBOopRZac0odKEqePofD6ZGU1VJhDRe1gO1isTBTBM8YqrMk9ENxmeinvertersupply


 $2nsqzly AQPPrW5vlinver tersupply\ AfmBOor UPBPd8dXD7zYMndWWVk$

3uf9mHoM0wjRiLhDezG0JwlyBNlrcdn AfmBOoqoDnrdVP0at8sChn58RNe7dmowOzQ MGj4 3JKb357eH8DhgDtinvertersupply AfmBOooQO

AcTf8S4dgZ8VwXpqasZvPsCgmfqvbeVJKs7aX9l5mU1fB8invertersupply AfmBOorlizOZ BU60P0Hfhi 5CQqm xUohcQVAm5pyeACcvzTRWnuaHBinvertersupply |||

SURGE GUARD* RV POWER PROTECTION Protect What You Value Most Complete Power Protection Your RV is ... 2.00 L x 3.86 D 7 Surge Guard* 30A 50A Full Protection Hardwires Model 35530 120V, 30A Model 35550 120/240V, 50A Limited Lifetime Warranty Optional Optional Total electrical protection from... lang:en score:16 filesize: 2.01 M page count: 24 document date: 2018-03-02






Southwire Surge Guard RV Power Protection: Comprehensive Guide

Explore the full range of Southwire Surge Guard RV power protection solutions, including portable surge protectors, hardwires, and automatic transfer switches. Protect your RV from electrical hazards like surges, voltage fluctuations, and wiring faults with advanced features and reliable performance.

lang:en score:15 filesize: 2 M page_count: 24 document date: 2020-07-01



[pdf] Catalog

ASSEMBLED SOLUTIONSN POWER ECO FRIEN D LY C L E A N Page 98 SOUTHWIRE 120Vac 60Hz 40A General Resistive Tungsten 20A Ballast 62d9d45d 0db8 4eae bce9 335012de8883images thdstatic catalog Images 62 62d9d45d 335012de8883 SOLUTIONSASSEMBLED 335012de8883b14371f1 d520 4a97 bf9e 9b45297d265aimages b1 b14371f1 9b45297d265a 335012de88835eb54ea7 060e 40f0 a7c8 2f0253819eb8b14371f1 5e 5eb54ea7 2f0253819eb8images ||| ||| ASSEMBLED SOLUTIONS CATALOG SOUTHWIRE.COM THE COMPLETE SOUTHWIRE SOLUTION WIRE AND CABLE TOOLS AND EQUIPMENT POWER MANAGEMENT ELECTRICAL COMPONENTS LIGHTING SOLUTIONS OUR STORY As a family business, Southwire proudly continues building on o ||| ASSEMBLED SOLUTIONS CATALOG SOUTHWIRE.COM THE COMPLETE SOUTHWIRE SOLUTION WIRE AND CABLE TOOLS AND EQUIPMENT POWER MANAGEMENT ELECTRICAL COMPONENTS LIGHTING SOLUTIONS OUR STORY As a family business, Southwire proudly continues building on o ASSEMBLED SOLUTIONS CATALOG SOUTHWIRE.COM THE COMPLETE SOUTHWIRE SOLUTION WIRE AND CABLE TOOLS ... le 34950 FULL PROTECTION 30A Portable 34931 50A Portable 34951 30A Portable 35530 50A Portable 35550 Over Under Voltage Input Open Neutral Protection Input Open Ground Protection Overheati...

lang:en score:14 filesize: 15.71 M page count: 188 document date: 2023-06-22



[pdf] Warranty Borchure

BrochureSouthwire RV Surge Protector Guard 30A Portable 44280 MMRV OnlineSOUWIRE00694 5 18 22cdn shopify s files 1 0461 7758 3255 SOUWIRE00694 22 v 1620134923 |||

Surge Guard* 30A 50A Surge Protectors with Enhanced Diagnostics Model 44280 120V, 30A 2100 Joules ... 44290 - Surge Protectors with Enhanced Diagnostics n 34930/34950 - Full Protection Portable n 35530/35550 - Full Protection Hardwire n 44300 - Over-voltage Adapter What Is Connected Equipment Coverage...

lang:en score:14 filesize: 282.6 K page_count: 3 document date: 2018-03-23




[pdf] Catalog

ASSEMBLED SOLUTIONS WIRE AND CABLE TOOLS EQUIPMENT POWER MANAGEMENT ELECTRICAL COMPONENTS LIGHTING Page 3 4 As a family business Southwire® proudly 224f2603 b84e 4256 876f 8fc478cca59f images thdstatic catalog Images 22 |||

ASSEMBLED SOLUTIONS CATALOG SOUTHWIRE.COM THE COMPLETE SOUTHWIRE SOLUTION WIRE AND CABLE TOOLS ... le 34950 FULL PROTECTION 30A Portable 34931 50A Portable 34951 30A Portable 35530 50A Portable 35550 Over Under Voltage Input Open Neutral Protection Input Open Ground Protection Overheati...

lang:en score:13 filesize: 15.48 M page_count: 184 document date: 2024-01-05



Trailer Life Magazine - July 2018 Issue: Affordable Travel Trailers & RV Adventures

Discover the July 2018 issue of Trailer Life magazine, featuring '12 Under \$21,000' dollar-stretching trailers and toy haulers. Explore articles on road-taming suspension, single-key security, instant hot water, and thrilling RV adventures with brands like Lance, Outdoors RV, and Bigfoot. This issue provides essential insights for RV enthusiasts, covering new products, maintenance tips, and travel destinations. lang:en score:13 filesize: 47.43 M page_count: 116 document date: 2018-05-18



[pdf] Warranty

WarrantySouthwire RV Surge Protector Guard 50A Hardware Packaged 35550 MMRV
OnlineSOUWIRWTNT00002 2cdn shopify s files 1 0461 7758 3255 SOUWIRWTNT00002 2 v
1620140945 WarrantyWarrantySouthwire OnlineSouthwire 30A Portable With Ground Fault 447 3cdn
1620140945cdn 3 1620141247 WarrantyWarrantyWarrantySouthwire 44280 1620141247cdn
1620135056 |||

LIMITED LIFETIME CONNECTED EQUIPMENT WARRANTIES Limited Product Warranty Southwire Company, LLC warrants that this product, when properly installed according to Southwire s installation procedures, shall be free of defects in materials and workmanship under normal use. The warranty extends only t...

lang:en score:12 filesize: 209.46 K page_count: 2 document date: 2018-03-07




[pdf] User Manual Installation Guide

Motorhome Good Sam manual and automatic roller shades for replacement Whether you decide to do the swap yourself or let pros handle task MotorhomeMagazineMay2018 webcontent goodsam motorhomemagazine digital editions

10 MOTORHOMES THAT OFFER MORE BANG FOR YOUR BUCK ENJOY THE VIEW Winnebago s Fuel-efficient, Euro-ins ... able Surge Guard models 34930 30-amp/34950 50-amp, the hardwire Surge Guard models 35530 30-amp and **35550** 50-amp provide full electrical protection with the convenience of being wired directly into th...

lang:en score:11 filesize: 52.28 M page_count: 116 document date: 2018-03-12



[pdf] Troubleshooting Guide Guide

Model 35530 RVupgradesSurge Guard provides protection to your RV by turning off power when the line voltage L1 falls below 102 Volts AC or goes above 132 Surge Guard 35530 troublervupgradestore v vspfiles assets trouble srsltid AfmBOoq9L YyhG9uSY1zy5faK FpgxSKWK8mZ6rkFq6HVbeUWMhn wEJ


TROUBLESHOOTING GUIDE 561-01043A Model 35530 30A Hardwire Surge Guard with Optional Remote LCD D ... ANT CLIGNOTANT LIGNE 1 Vert=OK, Rouge= dfaut DISPOSITIF Pas de protection une fois allume Modle **35550** PORT DISTANCE 120V, 30 Amp Joules de Protection contre les surtensions 2450 PROTECTION DE L A... lang:en score:11 filesize: 529.19 K page_count: 4 document date: 2015-11-13



Trailer Life Magazine: May 2018 - RV Reviews, Travel Tips & Technology

Discover the May 2018 issue of Trailer Life magazine, your essential resource for RV enthusiasts. This issue features comprehensive reviews of new travel trailers and fifth wheels, including budget-friendly options. Get expert advice on RV technology, maintenance, and performance upgrades, explore travel destinations like Disney World, and find the latest RV accessories to enhance your adventures.

lang:en score:11 filesize: 48.45 M page_count: 116 document date: 2018-03-14



2021 RV & MH Parts & Accessories Catalog - Northern Wholesale Supply

Explore the 2021 Northern Wholesale Supply catalog featuring a comprehensive range of RV and MH parts and accessories, including Dometic awnings, electrical components, and sanitation solutions for recreational vehicles.

lang:en score:10 filesize: 328.58 M page_count: 1307 document date: 2021-02-09



MotorHome Magazine: 50th Anniversary Issue - July 2018

Explore the July 2018 50th Anniversary issue of MotorHome magazine, featuring articles on RV travel, tech, lifestyle, vintage motorhomes, and reader discussions on drone use in RV parks. Includes features on Newell Coach, Foretravel, Renegade, and Fleetwood RVs.

lang:en score:10 filesize: 44.99 M page_count: 112 document date: 2018-05-17