

[Manuals.plus](#) /

› [Steamfast](#) /

› Steamfast SF-520 Full Size Fabric Steamer User Manual

Steamfast SF-520

Steamfast SF-520 Full Size Fabric Steamer User Manual

Model: SF-520 | Brand: Steamfast

INTRODUCTION

The Steamfast SF-520 Full-size Fabric Steamer is designed to provide natural garment care by using steam to penetrate deep into fabrics, relaxing fibers, releasing wrinkles, and freshening clothes. This method is gentle enough for delicate fabrics and effective for heavier materials like drapes and upholstery. The unit features a quick heat-up time and provides continuous steam for extended use.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the Steamfast SF-520 Fabric Steamer. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the steamer is unplugged before filling or emptying the water tank, or when not in use.
- Do not operate the steamer with a damaged cord or plug.
- Keep the steam nozzle away from skin and eyes. Steam is hot and can cause burns.
- Use only distilled or de-mineralized water to prevent mineral buildup and prolong the life of the unit.
- This item is built to meet U.S. voltage requirements (120V) and may not function properly when used with external devices that alter or convert voltage or frequency of electricity. Improper use or shipping the product outside the U.S. will void all warranties.
- Do not immerse the steamer in water or other liquids.
- Keep out of reach of children.

PACKAGE CONTENTS

Verify that all components are present before assembly and operation:

- Fabric Steamer Base Unit
- Insulated Hose with Steam Nozzle
- Telescopic Pole
- Clothes Hanger Attachment
- Fabric Brush Attachment

Warm, clean and smooth steam.

User-friendly steam nozzle helps you get rid of wrinkles on a variety of fabrics.



Image: Steamfast SF-520 accessories including the fabric brush, steam nozzle, and clothes hanger.

PRODUCT FEATURES

- **Quick Heat-Up Time:** The 70-ounce capacity removable water tank heats up in approximately 45 seconds.
- **Extended Steam Time:** Provides up to 63 minutes of continuous steam.
- **Chemical-Free Operation:** Freshens and removes wrinkles from fabrics without the need for harsh chemicals.
- **Equipped for Versatility:** Includes a cool-touch insulated hose, telescoping pole, attachable fabric brush, clothes hanger, and integrated cord wrap.
- **Fabric Care:** Effectively removes wrinkles and odors from various items such as clothes, linens, curtains, and upholstery.

Versatile accessories.

3 accessories included for use on a wide variety of fabrics.



Image: Diagram illustrating key features and specifications of the Steamfast SF-520 steamer.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble Telescopic Pole:** Insert the bottom end of the telescopic pole into the designated opening on the steamer base. Ensure it clicks securely into place.
3. **Attach Clothes Hanger:** Slide the clothes hanger attachment onto the top of the telescopic pole until it is firmly seated.
4. **Connect Hose:** Securely attach the insulated hose to the steam outlet on the steamer base. Twist clockwise until tight. Place the steam nozzle into the hanger's holder.
5. **Fill Water Tank:** Remove the water tank from the base. Unscrew the cap and fill the tank with distilled or de-mineralized water. Do not overfill. Replace the cap and reinsert the tank into the base, ensuring it is properly seated.
6. **Extend Pole:** Adjust the telescopic pole to your desired height by releasing the clamps, extending the pole sections, and then re-securing the clamps.






Image: Fully assembled Steamfast SF-520 Full Size Fabric Steamer.

OPERATING INSTRUCTIONS

1. **Power On:** Plug the steamer into a standard 120V AC electrical outlet. Turn the power switch located on the back of the unit to the 'ON' position. The indicator light will illuminate.
2. **Heat-Up:** Allow approximately 45 seconds for the steamer to heat up and produce steam.
3. **Prepare Garment:** Hang the garment on the provided hanger attachment. For best results, gently pull the fabric taut with one hand while steaming with the other.
4. **Steam Application:** Hold the steam nozzle a few inches from the fabric. Move the nozzle in a downward motion, allowing the steam to penetrate the fibers. For stubborn wrinkles, you may gently press the fabric brush attachment against the garment while steaming.
5. **Steaming Technique:** Work from top to bottom of the garment. Overlap steam passes slightly to ensure even coverage.
6. **Finishing:** Once steaming is complete, turn the power switch to 'OFF' and unplug the unit. Allow garments to cool and dry completely before wearing or storing.





Image: A person using the Steamfast SF-520 to steam a sweater.



Image: Close-up view of the steamer head applying steam to fabric.

MAINTENANCE

Cleaning the Steamer

- Always unplug the steamer and allow it to cool completely before cleaning.
- Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Empty any remaining water from the tank after each use to prevent mineral buildup.

Descaling (Mineral Buildup Removal)

Over time, mineral deposits can accumulate inside the steamer, affecting performance. Descale your steamer regularly, especially if you notice reduced steam output or spitting.

1. Mix a solution of 50% white vinegar and 50% water.
2. Pour the solution into the water tank.

3. Plug in the steamer and turn it on. Allow it to heat up and produce steam for a few minutes.
4. Turn off and unplug the steamer. Let it sit for at least 30 minutes, or longer for heavy buildup.
5. Empty the vinegar solution from the tank.
6. Rinse the tank thoroughly with fresh water.
7. Fill the tank with fresh water and run the steamer for a few minutes to flush out any remaining vinegar residue.

Storage

When not in use, store the steamer in a cool, dry place. Ensure the water tank is empty and the cord is wrapped neatly using the integrated cord wrap.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output	Water tank is empty or low. Unit not heated sufficiently. Mineral buildup.	Refill water tank. Allow 45 seconds for heat-up. Descale the unit.
Water spitting from nozzle	Mineral buildup. Overfilling the water tank.	Descale the unit. Do not overfill the water tank.
Steamer not turning on	Not plugged in. Power switch is off. No power at outlet.	Ensure plug is fully inserted. Turn power switch to 'ON'. Check circuit breaker or try another outlet.
Hose feels hot	Normal operation.	The hose is insulated but will still feel warm. Always handle the steam nozzle by its handle.

SPECIFICATIONS

- **Model Number:** SF-520
- **Brand:** Steamfast
- **Color:** White
- **Product Dimensions:** 12.1"L x 10.1"W x 65.4"H
- **Item Weight:** 10 pounds
- **Wattage:** 1500 watts
- **Voltage:** 120 volts AC
- **Heat Time:** Approximately 45 seconds (0.75 minutes)
- **Water Tank Capacity:** 70 ounces (approx. 4.4 pounds)
- **Continuous Steam Time:** Up to 63 minutes
- **Included Components:** Fabric Steamer, Insulated Hose with Steam Nozzle, Telescopic Pole, Clothes Hanger, Fabric Brush

WARRANTY AND SUPPORT

Steamfast products are designed and supported in Andover, KS. The SF-520 Fabric Steamer comes with a **2-year limited warranty**. If the product does not meet expectations within this period, Steamfast will replace it. For warranty claims or technical assistance, please refer to the contact information provided in your product packaging or visit the official Steamfast website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question