

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Coleman](#) /

› [Coleman Family Sleeping Bag C10 \(Model 2000027256\) Instruction Manual](#)

Coleman 2000027256

Coleman Family Sleeping Bag C10

Model: 2000027256

INTRODUCTION

Thank you for choosing the Coleman Family Sleeping Bag C10. This instruction manual provides essential information for the safe and effective use, setup, maintenance, and storage of your sleeping bag. Please read this manual thoroughly before using the product and retain it for future reference.

SAFETY INFORMATION

- **Fire Hazard:** Keep the sleeping bag away from open flames, heaters, and other heat sources. The fabric may ignite and cause serious injury.
- **Suffocation Risk:** Do not use this sleeping bag for infants or very young children who cannot move freely. Ensure adequate ventilation when in use.
- **Temperature Rating:** This sleeping bag is rated for a comfort temperature of 10 degrees Celsius. Using it in temperatures significantly below this rating may lead to hypothermia. Always dress appropriately for the expected conditions.
- **Proper Use:** Ensure zippers are fully closed to prevent cold air entry. Do not obstruct breathing passages.

PACKAGE CONTENTS

Your Coleman Family Sleeping Bag C10 package includes:

- One (1) Coleman Family Sleeping Bag C10
- One (1) Storage/Carry Bag

SETUP

To prepare your sleeping bag for use:

1. Remove the sleeping bag from its storage bag.
2. Unroll the sleeping bag completely on a flat, dry surface, such as inside a tent or on a sleeping pad.
3. Allow the sleeping bag to loft for a few minutes. This allows the insulation to expand and provide maximum warmth.



Image: The Coleman Family Sleeping Bag rolled and secured in its green carry bag, ready for transport or storage.

OPERATING INSTRUCTIONS

The Coleman Family Sleeping Bag C10 is designed for comfortable sleep in various outdoor conditions, suitable for up to 3 persons. It features a zipper closure for easy entry and exit.

1. **Entry:** Unzip the sleeping bag fully or partially to create an opening. Carefully slide into the sleeping bag.
2. **Adjusting for Warmth:** Once inside, zip the sleeping bag up to your desired level. For maximum warmth, ensure the zipper is fully closed.
3. **Capacity:** This sleeping bag is designed to accommodate up to three individuals, depending on their size.



Image: Three individuals sleeping comfortably side-by-side in the Coleman Family Sleeping Bag, demonstrating its capacity within a tent setting.

MAINTENANCE AND CARE

Proper care extends the life of your sleeping bag:

- **Cleaning:** Spot clean with a damp cloth and mild soap for small stains. For a thorough cleaning, follow the care label instructions, typically machine wash cold on a gentle cycle with a front-loading washer. Use a mild detergent.
- **Drying:** Tumble dry on low heat with a few clean tennis balls to help fluff the insulation. Ensure the sleeping bag is completely dry before storing to prevent mildew. Air dry if possible.
- **Avoid Dry Cleaning:** Do not dry clean, as the chemicals can damage the insulation.

STORAGE

For long-term storage, it is recommended to store the sleeping bag uncompressed in a large mesh bag or loosely folded in a dry, cool place. This helps maintain the loft of the insulation. For transport, use the provided storage bag.



Image: The Coleman Family Sleeping Bag rolled and secured in its green carry bag, suitable for compact storage and transport.

TROUBLESHOOTING

- **Feeling Cold:** Ensure the sleeping bag is fully zipped. Check if your sleeping pad provides adequate insulation from the ground. Consider wearing additional layers of clothing.
- **Zipper Snagging:** Gently pull the fabric away from the zipper teeth while closing. Apply a silicone-based zipper lubricant if snags persist.
- **Loss of Loft:** If the sleeping bag feels flat, try tumbling it in a large dryer on low heat with a few tennis balls to redistribute and fluff the insulation.

SPECIFICATIONS

Model Number	2000027256
Product Dimensions	168 x 190 x 7.62 cm
Item Weight	3.6 kg
Temperature Rating	Comfort (10 Degree Celsius)

Occupancy	3 Person
Seasons	All Seasons
Closure Type	Zipper
Age Range (Description)	Kid

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please visit the official Coleman website or contact Coleman customer service directly. Keep your proof of purchase for any warranty claims.

Official Coleman Website: www.coleman.com