

[Manuals.plus](#) /

› [Melissa & Doug](#) /

› Melissa & Doug Sunny Patch Giddy Buggy Kids Flashlight User Manual

Melissa & Doug 6335

Melissa & Doug Sunny Patch Giddy Buggy Kids Flashlight User Manual

Model: 6335

INTRODUCTION

The Melissa & Doug Sunny Patch Giddy Buggy Kids Flashlight is designed for young adventurers. This durable flashlight features an integrated handle for easy gripping by small hands and six feet to ensure stability when placed on flat surfaces. It is suitable for both indoor and outdoor use, providing illumination for various activities.



Image: The Giddy Buggy Flashlight, a colorful bug-shaped flashlight with a yellow handle and orange front, held by a child.

WHAT'S IN THE BOX

- 1 x Giddy Buggy Flashlight

Note: 2 AA batteries are required and are not included with the product.



Image: The Giddy Buggy Flashlight shown in its clear plastic packaging, highlighting the built-in easy-grip handle.

SETUP

1. **Battery Installation:** Locate the battery compartment, typically on the underside or rear of the flashlight. Insert 2 AA batteries (not included), ensuring correct polarity (+/-).
2. **Secure Compartment:** Close the battery compartment securely.



Image: A side view of the Giddy Buggy Flashlight, illustrating its colorful body and sturdy design, where the battery compartment would typically be accessed.

OPERATING INSTRUCTIONS

To operate the Giddy Buggy Flashlight:

1. **Turn On:** Press the on/off switch located on the integrated easy-to-grip handle. The light will illuminate.
2. **Turn Off:** Press the on/off switch again to turn off the flashlight.
3. **Usage:** The flashlight can be used for various indoor and outdoor activities, providing a gentle light suitable for children. Its six feet allow it to sit steadily on flat surfaces for hands-free illumination.



Image: A child holding the Giddy Buggy Flashlight, demonstrating its easy-to-grip handle.



Image: A child lying down, pointing the Giddy Buggy Flashlight forward, showing its light output.

MAINTENANCE

- **Cleaning:** Wipe the flashlight with a soft, damp cloth. Do not immerse in water.
- **Battery Care:** Remove batteries if the flashlight will not be used for an extended period to prevent leakage. Replace old batteries with new ones as needed.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Flashlight does not turn on or light is dim.	Check if batteries are inserted correctly with the correct polarity. Replace old batteries with new AA batteries. Ensure the battery compartment is securely closed.
Light flickers.	Check battery connections; ensure they are firm. Replace batteries if they are low.

SPECIFICATIONS

Feature	Detail
Brand	Melissa & Doug
Model Number	6335
Item Type Name	Sunny Patch Giddy Buggy Flashlight With Easy-Grip Handle
Power Source	Battery Powered
Battery Type	2 AA batteries (not included)
Age Range	3+ years (Manufacturer Minimum Age: 36 months, Maximum Age: 72 months)
Color	Multicolor
Item Weight	9.6 ounces
Item Dimensions	3.3 x 8.2 x 10.5 inches
Material Type	Plastic
Educational Objective	Develop fine motor skills and encourage imaginative play through easy-to-use flashlight and bug theme

WARRANTY

This product does not come with a manufacturer's warranty.

SUPPORT

For any questions or assistance regarding your Melissa & Doug Sunny Patch Giddy Buggy Kids Flashlight, please contact Melissa & Doug customer service through their official website or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question