Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Toyota Corolla

2014 Toyota Corolla Owner's Manual

Comprehensive Guide for Your Vehicle

Introduction

This owner's manual provides detailed information and instructions for the safe and efficient operation, maintenance, and care of your 2014 Toyota Corolla. It is essential to read this manual thoroughly to understand your vehicle's features, capabilities, and important safety warnings. Keep this manual in your vehicle for quick reference.




Image: Front cover of the official 2014 Toyota Corolla Owner's Manual, displaying the Toyota logo and vehicle model year.

Getting Started

Initial Vehicle Familiarization

Before driving, familiarize yourself with the location and function of key controls. This includes the steering wheel controls, dashboard indicators, and pedal layout.

- **Ignition Switch/Start Button:** Locate the ignition switch or engine start/stop button.
- **Lighting Controls:** Understand how to operate headlights, high beams, turn signals, and hazard lights.
- **Wiper Controls:** Learn to use the windshield wipers and washer fluid.
- **Seat Adjustments:** Adjust your seat and steering wheel for optimal driving position and visibility.
- **Mirror Adjustments:** Properly adjust side and rearview mirrors.

Key and Remote Control

Your vehicle comes with a set of keys and remote controls. The remote control allows for locking/unlocking doors and activating the panic alarm. Refer to the manual for instructions on key battery replacement and remote programming.

Operating Your Vehicle

Driving Procedures

1. **Starting the Engine:** Insert the key and turn to START, or press the engine start/stop button while pressing the brake pedal.
2. **Automatic Transmission:** Shift into 'D' for Drive. Use 'P' for Park, 'R' for Reverse, and 'N' for Neutral.
3. **Braking:** Apply steady pressure to the brake pedal to slow down or stop.
4. **Parking Brake:** Engage the parking brake when parking on inclines or for extended periods.

Infotainment System

The infotainment system includes radio, CD player, and auxiliary input options. Use the touchscreen or physical buttons to navigate menus, adjust volume, and select audio sources. Bluetooth pairing instructions are detailed in the manual for hands-free calling and audio streaming.

Climate Control

Adjust the temperature, fan speed, and air distribution using the climate control panel. Options include air conditioning (A/C), heating, and defrost functions for the windshield and rear window.

Safety Features

Your Corolla is equipped with various safety features, including airbags, anti-lock braking system (ABS), electronic brake-force distribution (EBD), and vehicle stability control (VSC). Understand their functions and limitations for safe driving.

Maintenance and Care

Scheduled Maintenance

Regular maintenance is crucial for the longevity and performance of your vehicle. Refer to the maintenance schedule in this manual for recommended service intervals, including oil changes, tire rotations, and filter replacements.

Typical Maintenance Schedule (Consult Manual for Exact Intervals)

Service Item	Interval (Miles/Months)
Engine Oil & Filter Change	5,000 miles / 6 months
Tire Rotation	5,000 miles / 6 months
Cabin Air Filter Inspection	10,000 miles / 12 months
Brake Inspection	15,000 miles / 18 months

Fluid Checks

Regularly check engine oil, coolant, brake fluid, power steering fluid (if applicable), and windshield washer fluid levels. Instructions for checking and refilling each fluid are provided in the manual.

Tire Care

Maintain correct tire pressure as specified on the driver's side door jamb. Inspect tires for wear and damage. Proper tire care ensures safety and extends tire life.

Troubleshooting Common Issues

This section addresses common operational problems and provides steps for diagnosis and resolution. For complex issues, consult a certified Toyota service technician.

- **Warning Lights:** Understand the meaning of various dashboard warning lights (e.g., Check Engine, Oil Pressure, Battery, ABS).
- **Engine Not Starting:** Check battery terminals, fuel level, and ensure the transmission is in Park or Neutral.
- **Flat Tire:** Instructions for safely changing a flat tire using the spare tire and tools provided.
- **Overheating:** If the engine overheats, safely pull over, turn off the engine, and allow it to cool before checking coolant levels.

Vehicle Specifications

Key technical specifications for the 2014 Toyota Corolla are provided below. For a complete list, refer to the detailed specifications section within the manual.

2014 Toyota Corolla General Specifications

Category	Detail
Engine Type	1.8L 4-Cylinder DOHC 16-Valve with Dual VVT-i
Horsepower	132 hp @ 6,000 rpm
Torque	128 lb-ft @ 4,400 rpm
Fuel Tank Capacity	13.2 gallons (approx.)
Overall Length	182.6 inches (approx.)
Curb Weight	2,800 - 2,865 lbs (approx., varies by trim)

Warranty and Support

Your 2014 Toyota Corolla is covered by a comprehensive warranty. Details regarding warranty coverage, terms, and conditions are provided in a separate warranty booklet that accompanies this manual. For service or support, please contact your authorized Toyota dealership.
For additional assistance, visit the official Toyota website or contact Toyota Customer Service. Contact information can be found in the warranty booklet or on the Toyota corporate website.

© 2014 Toyota. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01AFGMA4W

More documents and user manuals: **https://manuals.plus/**