

[Manuals.plus](#) /

› [Skip Hop](#) /

› Skip Hop MOBY Smart Sling 3-Stage Infant Bathtub Instruction Manual

Skip Hop 235465

Skip Hop MOBY Smart Sling 3-Stage Infant Bathtub Instruction Manual

Model: 235465

1. INTRODUCTION

This manual provides instructions for the safe and effective use of your Skip Hop MOBY Smart Sling 3-Stage Infant Bathtub. This versatile bathtub is designed to adapt to your child's growth through three distinct stages, from newborn to sitter.

Important Safety Information:

- Always keep your child within arm's reach during bathing. Never leave a child unattended in the bathtub, even for a moment.
- Ensure the water temperature is appropriate for bathing. Test the water with your elbow or a thermometer before placing your child in the tub.
- Do not use this product if any components are damaged or missing.
- Maximum weight recommendation: 25 lbs (11.3 kg).



Image 1.1: The Skip Hop MOBY Smart Sling 3-Stage Infant Bathtub, shown in blue with the mesh sling in place.

2. SETUP AND ASSEMBLY

The Skip Hop MOBY Bathtub is designed for easy setup and transitions between stages.

2.1 Unpacking

Remove all components from the packaging. Ensure you have the bathtub and the mesh Smart Sling.

2.2 Attaching the Smart Sling (Newborn Position)

For newborns (0-3 months, up to 15 lbs), the Smart Sling should be in the upper position for full-body cradling.

1. Locate the four attachment points on the rim of the bathtub.
2. Attach the two upper clips of the Smart Sling to the higher attachment points on the tub.
3. Attach the two lower clips of the Smart Sling to the lower attachment points on the tub. Ensure all clips are securely fastened.



Image 2.1: Top view of the bathtub with the Smart Sling configured for newborn use (upper position).

2.3 Adjusting the Smart Sling (Infant Position)

For infants (3-6 months, up to 20 lbs) who are learning to sit, the Smart Sling can be adjusted to a lower position for seated support.

1. Carefully unclip the two upper clips of the Smart Sling from the higher attachment points.
2. Re-attach these two clips to the lower attachment points on the tub, alongside the existing lower clips. This creates a more upright, seated support.
3. Ensure all four clips are securely fastened to the lower attachment points.



Image 2.2: Top view of the bathtub with the Smart Sling configured for infant use (lower position).



Image 2.3: Hands demonstrating the adjustment of the Smart Sling.

2.4 Removing the Smart Sling (Sitter Stage)

Once your child is able to sit upright unassisted (6 months+, up to 25 lbs), the Smart Sling can be removed entirely to provide a spacious bathing area.

1. Unclip all four clips of the Smart Sling from the bathtub.
2. Remove the Smart Sling from the tub.



Image 2.4: Top view of the bathtub without the Smart Sling, suitable for older babies.

3. OPERATING INSTRUCTIONS

The Skip Hop MOBY Bathtub offers three stages of use to accommodate your child's development.

grows with baby in 3 stages



STAGE 1: 0-3 months
sling support
for newborns



STAGE 2: 3-6 months
seated support
for infants



STAGE 3: 6+ months
remove sling
for older babies

Image 3.1: Visual guide to the 3-stage design of the bathtub.

3.1 Stage 1: Newborn (0-3 months, up to 15 lbs)

Use the Smart Sling in the upper position for full-body cradling. This provides a comfortable and secure recline for newborns.

- Ensure the sling is securely attached as described in Section 2.2.
- Fill the tub with a shallow amount of warm water, ensuring the water level does not exceed your child's chest when they are in the sling.
- Gently place your newborn into the sling.

3.2 Stage 2: Infant (3-6 months, up to 20 lbs)

Adjust the Smart Sling to the lower position for seated support as your infant begins to learn to sit.

- Ensure the sling is securely attached as described in Section 2.3.
- Fill the tub with a shallow amount of warm water, ensuring the water level does not exceed your child's waist when they are seated.
- Place your infant into the sling, ensuring they are comfortably supported.



Image 3.2: An infant being bathed in the tub with the sling in the lower position.

3.3 Stage 3: Sitter (6 months+, up to 25 lbs)

Once your child can sit unassisted, remove the Smart Sling for a spacious and comfortable bathing experience.

- Ensure the sling is removed as described in Section 2.4.
- Fill the tub with warm water to a safe level, typically not exceeding your child's waist when seated.
- Place your child directly into the tub. The non-slip interior provides stability.

4. MAINTENANCE AND CARE

Proper care ensures the longevity and hygiene of your Skip Hop MOBY Bathtub.

4.1 Cleaning

Clean regularly and dry immediately after each use. Hang dry in a well-ventilated, dry setting. Use a dehumidifier or fan to dry in humid environments.

- Wipe the tub with a mild soap and water solution. Rinse thoroughly.
- The mesh Smart Sling can be hand washed with mild soap and water. Allow it to air dry completely.
- Do not use abrasive cleaners or harsh chemicals, as these may damage the product.
- The tub is not dishwasher safe.

4.2 Draining

The tub features a drain plug for easy water removal.

1. After bathing, ensure your child is safely removed from the tub.
2. Locate the star-shaped drain plug at the bottom of the tub.
3. Pull the drain plug to release the water.



Image 4.1: Removing the drain plug for water drainage.

4.3 Storage

The tub includes a swivel hook for convenient drying and space-saving storage.

- After cleaning and draining, ensure the tub is completely dry.
- Use the integrated swivel hook to hang the tub on a shower head, shower bar, or towel rack.



Image 4.2: The bathtub hanging for drying and storage.

5. TROUBLESHOOTING

This section addresses common inquiries regarding the Skip Hop MOBY Bathtub.

- **Sling not staying in place:** Ensure all four clips are securely fastened to the designated attachment points on the tub. Verify that the sling is oriented correctly.
- **Water not draining completely:** Ensure the drain plug is fully removed. Check for any obstructions in the drain opening.
- **Tub instability:** Ensure the tub is placed on a flat, stable surface before filling with water and placing your child inside.

6. SPECIFICATIONS

Model Number	235465
Brand	Skip Hop
Color	Blue
Product Dimensions	27.5" L x 19" W x 11.5" H (70 cm L x 48 cm W x 29 cm H)
Item Weight	3 lbs (1.36 kg)
Maximum Weight Recommendation	25 lbs (11.3 kg)
Age Range	Newborn to Sitter (0+ months)
Material Type	PP; 100% Polyester
Material Free	PVC Free, Phthalate Free
Included Components	Bathtub, Smart Sling
UPC	192136557142, 879674024632

7. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official Skip Hop website or contact their customer service directly.
You can visit the Skip Hop store for more information:[Skip Hop Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question