

LG LAS260B

LG LAS260B Sound Bar User Manual

Model: LAS260B

INTRODUCTION

This user manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your LG LAS260B 100 Watt 2 Channel Bluetooth Sound Bar. Please read this manual thoroughly before using the product to ensure proper and safe operation.



Figure 1: Front view of the LG LAS260B Sound Bar.

PACKAGE CONTENTS

Before you begin, ensure all items are present in the box:

- LG LAS260B Sound Bar
- Remote Control (with 2 AAA batteries included)
- User Manual (this document)
- Power Cable

Note: An optical cable for TV connection is not included and must be purchased separately if required.

SETUP

1. Placement

Place the sound bar on a stable, flat surface in front of your TV, ensuring it does not obstruct the TV's remote sensor. The slim design allows for easy integration with most TV setups.




Figure 2: Recommended placement of the sound bar in front of a TV.

2. Connecting to Power

Connect the supplied power cable to the sound bar's power input and then plug it into a wall outlet.

3. Connecting to Your TV (Audio Input Options)

The LG LAS260B offers several ways to connect to your TV or other audio sources:

- **Optical Digital Audio (Recommended):** For the best audio quality, connect an optical digital audio cable (not included) from your TV's optical output to the sound bar's optical input.
- **Bluetooth:** For wireless audio streaming from compatible devices, refer to the "Bluetooth Connection" section under Operating.

OPERATING INSTRUCTIONS

1. Basic Operation

- **Power On/Off:** Press the Power button on the remote control or on the sound bar.
- **Volume Control:** Use the Volume Up/Down buttons on the remote or sound bar to adjust the volume.
- **Input Selection:** Press the Function button on the remote or sound bar to cycle through available inputs

(Optical, Bluetooth).

2. Bluetooth Connection

The LG LAS260B allows wireless audio streaming from your smartphone, tablet, or other Bluetooth-enabled devices.

1. Press the Function button on the sound bar or remote control until "BT" (Bluetooth) appears on the display.
2. On your Bluetooth device, enable Bluetooth and search for available devices. Select "LG LAS260B" from the list.
3. Once paired, the sound bar will indicate a successful connection, and you can now stream audio wirelessly.



Figure 3: Connecting a smartphone to the sound bar via Bluetooth.

3. Sound Modes

The sound bar features various sound modes to optimize your listening experience:

- **Standard:** Default sound setting.
- **Voice:** Enhances vocal clarity, ideal for news or dialogue-heavy content.
- **Cinema:** Provides a more immersive, dynamic sound experience for movies.

Use the corresponding buttons on the remote control to switch between these modes.

4. LG Bluetooth Remote App

Download the official LG Bluetooth Remote App on your smartphone for convenient control of your sound bar. The app allows you to manage settings, inputs, and volume directly from your mobile device.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your sound bar.

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the sound bar. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the sound bar's vents are not blocked to prevent overheating.
- **Storage:** If storing the unit for an extended period, disconnect it from power and store it in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your LG LAS260B Sound Bar, refer to the table below for common problems and

solutions.

Problem	Possible Cause	Solution
No power	Power cable not connected securely.	Check power cable connection to the sound bar and wall outlet. Ensure the outlet has power.
No sound	Incorrect input selected; volume too low; audio cable not connected.	Press the Function button to select the correct input. Increase volume. Check audio cable connections (e.g., optical).
Bluetooth pairing fails	Sound bar not in pairing mode; device too far; interference.	Ensure sound bar is in BT mode. Move device closer. Turn off other Bluetooth devices. Try re-pairing.
Remote control not working	Batteries are dead or inserted incorrectly; obstruction.	Replace batteries (2 AAA). Check battery polarity. Remove any obstructions between remote and sound bar.

If the problem persists after trying these solutions, please contact LG customer support.

SPECIFICATIONS

Feature	Detail
Model Name	LAS260B
Speaker Type	Soundbar
Audio Channels	2.0 Channel
Maximum Output Power	100 Watts
Connectivity Technology	Bluetooth
Audio Output Mode	Surround
Product Dimensions (W x H x D)	101.2 x 14.5 x 17 cm
Weight	2.5 kg
Mounting Type	Tabletop
Compatible Devices	TV, Smartphone, Tablet, Laptop, MP3 player
Batteries (Remote)	2 x AAA (included)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official LG website. You can also find additional support resources and FAQs there.

Official LG Support Website: www.lg.com/uk/support

