



[Manuals.plus](#) /

› [Fastrack](#) /

› Fastrack Analog Men's Watch Model NT38022PP03 Instruction Manual

## Fastrack NT38022PP03

# Fastrack Analog Men's Watch Model NT38022PP03 Instruction Manual

Your Guide to Setup, Operation, and Care

## INTRODUCTION

---

Welcome to your new Fastrack Analog Men's Watch, Model NT38022PP03. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your watch. Please read it carefully to ensure optimal performance and longevity of your timepiece.

## SETUP

---

### Unboxing

Carefully remove the watch from its packaging. Inspect the watch for any visible damage.



Image: The Fastrack watch packaging, a black cylindrical tin with orange and grey accents and the Fastrack logo.

### **Time Setting**

1. Pull the crown (the small knob on the side of the watch case) outwards to the time-setting position.
2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to engage the movement and start the watch.



Image: A close-up side view of the Fastrack watch, showing the black case and the crown used for setting the time.

### **Strap Adjustment**

The watch features a silicone strap with a buckle clasp. Adjust the strap to fit comfortably on your wrist by selecting the appropriate hole. Ensure it is snug but not too tight to allow for proper circulation.



Image: The Fastrack watch displayed on a wrist, illustrating how it appears when worn and how the strap fits.

## OPERATING YOUR WATCH

---

### Basic Functionality

This Fastrack Analog Watch displays time using hour, minute, and second hands. It operates on a Quartz movement, powered by a single AA battery (pre-installed).

### Water Resistance

The watch has a water resistance depth of 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. It is not recommended for swimming, diving, or showering. Avoid pressing the crown while the watch is wet.

## MAINTENANCE

---

### Cleaning

To clean your watch, wipe the case and strap with a soft, dry cloth. For stubborn dirt on the silicone strap, a slightly damp cloth with mild soap can be used, followed by thorough drying. Avoid using harsh chemicals or abrasive materials.

### Battery Replacement

The watch is powered by 1 AA battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.



Image: The back of the Fastrack watch, showing the stainless steel case back with brand engraving and model information.

## Storage

When not in use for extended periods, store the watch in a cool, dry place, away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Watch not running	Dead battery	Replace battery (professional service recommended).
Incorrect time display	Crown not pushed in	Push the crown fully into its operating position.
Condensation under crystal	Exposure to extreme temperature changes or water ingress	Seek professional service immediately to prevent damage.

If the issue persists after attempting these solutions, please contact customer support.

## SPECIFICATIONS

---

- **Model Number:** NT38022PP03
- **Brand:** Fastrack
- **Display Type:** Analog
- **Movement Type:** Quartz
- **Case Diameter:** 39.5 Millimetres
- **Case Thickness:** 12 Millimetres
- **Band Material Type:** Silicone
- **Band Colour:** Black
- **Dial Colour:** Black
- **Water Resistance Depth:** 30 Metres
- **Power Source Type:** Battery Powered (1 AA battery required)
- **Item Weight:** 102.3 Grams
- **Crystal Material:** Mineral Glass

- **Clasp Type:** Buckle
- **Special Features:** Arabic Numerals, Second Hand
- **Manufacturer:** Titan Company Limited, Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129
- **Date First Available:** 12 January 2016

## WARRANTY AND SUPPORT

---

### Warranty Information

This Fastrack watch comes with a 12-month manufacturer warranty covering manufacturing defects. To avail warranty service, present your original invoice at any Titan Authorized Service Center. No warranty card is required.

### Customer Support

For further details or service-related queries, please contact Titan India toll-free at **1800-266-0123** (10 AM to 7 PM, any day of the week) or email [customercare@titan.co.in](mailto:customercare@titan.co.in).

For more information, visit the official Fastrack store: [Fastrack Store on Amazon.in](#).