



Manuals.plus /

› PLAYMOBIL /

› Playmobil 6919 City Action Police Station with Prison User Manual

PLAYMOBIL 6919

Playmobil 6919 City Action Police Station with Prison User Manual

Official Instructions for Assembly, Operation, and Maintenance

PRODUCT OVERVIEW

The Playmobil 6919 City Action Police Station with Prison is a comprehensive playset designed for imaginative play. It features a detailed police command center, a secure prison, and various accessories to simulate police operations and prisoner management. This manual provides essential information for setting up, operating, and maintaining your playset.



Figure 1: The Playmobil 6919 City Action Police Station with Prison, shown in its retail packaging. This image provides an overview of the complete set, including the main police station building, prison cells, and various play figures and accessories.

SETUP AND ASSEMBLY

The Playmobil 6919 Police Station requires assembly. Follow the included graphical instructions carefully for proper construction. All components are designed for easy interlocking. No special tools are required for assembly.

- **Unpacking:** Carefully remove all components from the packaging. Verify that all parts listed in the product contents are present.
- **Main Structure Assembly:** Begin by connecting the base plates and main wall sections of the police station and prison units. Ensure all connections are secure.
- **Adding Details:** Attach smaller elements such as windows, doors, railings, and the control tower.
- **Accessory Placement:** Position furniture, communication equipment, and other accessories within the station and prison cells as desired.
- **Figures:** Assemble the police officers, criminal, and other figures as per their individual instructions.



Figure 2: A front view of the fully assembled Playmobil Police Station. This image highlights the main entrance, the guard posts, and the overall layout of the facility, demonstrating the completed structure after assembly.

Battery Information: This product does not require batteries for its primary functions. Some accessories, such as the floodlight, may require batteries (2 x CR123A batteries required, not included). Refer to the specific accessory instructions for battery installation.

OPERATING THE PLAYSET

The Playmobil Police Station offers various interactive features for engaging play scenarios.

Key Features and Interactions:

- **Police Command Center:** Utilize the control room with its detailed console and monitors to simulate surveillance and communication. The police figures can be positioned at the desks and use the included accessories like walkie-talkies and computers.
- **Prison Cells:** The playset includes two prison cells with lockable doors. Figures can be placed inside, and accessories like beds, toilets, and sinks enhance realism.

- **Escape Mechanism:** One of the prison walls features a clever escape mechanism, allowing for dynamic play scenarios where criminals can attempt to break out.
- **Helicopter Landing Pad:** The rooftop includes a designated landing area for Playmobil police helicopters (sold separately), expanding play possibilities.
- **Guard Posts and Gates:** The front of the station features two guard posts and a movable gate for controlling access.



Figure 3: An interior view of the police command center. This section features a detailed control console with monitors and communication equipment, allowing for realistic role-play scenarios involving police operations.



Figure 4: Inside one of the prison cells, showing a prisoner figure and a guard. The cell is equipped with a bed, sink, and toilet, providing a detailed environment for play scenarios involving incarceration.



Figure 5: A dynamic scene depicting a prisoner attempting to escape through a cleverly designed break-out wall. This feature adds an exciting element to the playset, allowing for various chase and capture scenarios.

MAINTENANCE

To ensure the longevity and cleanliness of your Playmobil Police Station, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down the plastic components with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with a clean, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the plastic.
- **Drying:** Ensure all parts are thoroughly dry before storing or reassembling to prevent water spots or damage.
- **Storage:** Store the playset in a clean, dry environment away from direct sunlight and extreme temperatures to prevent material degradation and color fading.
- **Inspection:** Periodically inspect all parts for any signs of wear or damage. Replace any broken or worn-out pieces if necessary.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Playmobil Police Station.

Problem	Possible Cause	Solution
Parts do not fit together during assembly.	Incorrect orientation or misidentification of parts.	Refer to the assembly instructions carefully. Ensure parts are oriented correctly and that you are using the correct pieces for each step. Apply gentle, even pressure.
Missing components.	Packaging error or accidental disposal.	Thoroughly check all packaging materials. If parts are genuinely missing, contact Playmobil customer support (see Support section).
Interactive features (e.g., escape wall) not functioning smoothly.	Dust or debris obstructing moving parts; incorrect assembly.	Clean the mechanism with a soft cloth. Re-check the assembly steps related to the feature to ensure all parts are correctly installed.

SPECIFICATIONS

Feature	Detail
Model Number	6919
Brand	PLAYMOBIL
Product Dimensions (L x W x H)	58.5 x 50 x 12.5 cm
Item Weight	2.48 kg
Material	Plastic
Recommended Age	4 years and up (4 to 10 years)
Assembly Required	Yes
Batteries Required	Yes, for some accessories (2 x CR123A, not included)
Number of Pieces	256

WARRANTY AND SUPPORT

For information regarding product warranty, missing parts, or technical support, please contact Playmobil customer service.

Contact details can typically be found on the product packaging or on the official Playmobil website.

Please have your product model number (6919) and purchase information ready when contacting support.

