

Garden Winds LCM665BR

Garden Winds Palm Valley Swing Replacement Canopy Instruction Manual

Model: LCM665BR

1. INTRODUCTION

This manual provides instructions for the installation, use, and maintenance of your Garden Winds Palm Valley Swing Replacement Canopy. This product is designed to replace the canopy on the original Palm Valley Swing, which was previously sold at Sears. Please note that this product includes the **replacement canopy fabric only**. The swing's cushion and metal structure are **not included**.

The replacement canopy is made from UV-treated, water-resistant, and CPAI fire-retardant fabric, designed for outdoor use. The color of this replacement canopy is brown.

2. SAFETY INFORMATION

- Ensure the swing frame is stable and securely anchored before installing or using the canopy.
- Do not use the swing or canopy during strong winds, heavy rain, or snow. Remove the canopy during severe weather conditions to prevent damage.
- Keep all open flames and heat sources away from the canopy fabric.
- Regularly inspect the canopy and swing frame for any signs of wear, damage, or loose connections.
- This canopy is for shade and light weather protection only. It is not designed to withstand extreme weather.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Garden Winds Palm Valley Swing Replacement Canopy (Brown)

Note: Cushions and metal swing frame are not included.




Figure 3.1: Close-up view of the brown replacement canopy fabric. This image represents the actual product color.

4. SETUP AND INSTALLATION

Installation of the replacement canopy typically requires two people. Ensure you have a stable ladder if needed.

1. **Remove Existing Canopy:** Carefully detach the old canopy from the swing frame. Note how the old canopy was attached to understand the installation method for the new one.
2. **Identify Canopy Orientation:** Unfold the new replacement canopy. Identify the front, back, and sides. The canopy may have sleeves or pockets designed to slide over the swing frame's canopy bars.
3. **Slide onto Frame:** Starting from one side, carefully slide the canopy fabric onto the support bars of the swing frame. Ensure the fabric is evenly distributed and not snagged.
4. **Secure Attachments:** Once the canopy is positioned over the frame, secure it using any integrated ties, hooks, or fasteners provided on the canopy or the swing frame. Ensure all attachment points are firm and taut to prevent flapping in the wind.
5. **Adjust for Fit:** Gently pull and adjust the canopy fabric to ensure a snug and even fit across the entire frame. Eliminate any wrinkles or loose areas as much as possible.



Figure 4.1: Illustration of a Palm Valley Swing with a canopy installed. *Note: The canopy shown in this image is for illustrative purposes of the swing frame and is not the brown replacement canopy being sold.*

5. OPERATING INSTRUCTIONS

Once installed, the replacement canopy requires minimal operation. Ensure it remains securely attached to the swing frame at all times. Periodically check the tension and attachment points, especially after strong winds, to maintain optimal performance and prevent damage.

6. MAINTENANCE

Proper maintenance will extend the life of your replacement canopy:

- **Cleaning:** Clean the canopy regularly with a soft brush or cloth, mild soap, and lukewarm water. Rinse thoroughly with clean water and allow it to air dry completely before storage or re-installation. Do not use harsh chemicals, bleach, or abrasive cleaners, as these can damage the fabric and its protective coatings.

- **Stain Removal:** For stubborn stains, a diluted solution of mild detergent can be used. Test on an inconspicuous area first.
- **Storage:** During off-season months (e.g., winter) or periods of prolonged non-use, it is recommended to remove the canopy from the swing frame. Clean it thoroughly, ensure it is completely dry, and store it in a cool, dry place away from direct sunlight and pests. This will help prevent mildew and prolong the fabric's life and color.
- **UV Protection:** While the fabric is UV-treated, prolonged exposure to direct sunlight will naturally cause some fading over time. Applying an additional UV protectant spray designed for outdoor fabrics may help to further extend color retention.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Canopy does not fit correctly	Incorrect model identification; improper installation	Verify your swing model number (D/PMV-SWG, SKU 001696897 or 001657823) matches the product description. Re-read installation instructions and ensure the canopy is oriented correctly.
Canopy sags or collects water	Loose attachment; frame issue	Ensure all attachment points are taut. Check the swing frame for any bending or damage that might prevent proper canopy tension.
Fading color	Prolonged sun exposure	Fading is a natural process for outdoor fabrics. Regular cleaning and applying a UV protectant spray may help slow the process. Store the canopy during off-season.

8. SPECIFICATIONS

- **Brand:** Garden Winds
- **Model Number:** LCM665BR
- **Compatible Swing Model:** Palm Valley Swing (Original Sears model D/PMV-SWG, SKU 001696897, 001657823)
- **Color:** Brown
- **Material:** Polyester
- **Product Dimensions:** Approximately 69"D x 71.5"W
- **Item Weight:** Approximately 4 pounds
- **Features:** UV treated, Water resistant, CPAI fire retardant
- **UPC:** 717964166504

9. WARRANTY INFORMATION

Specific warranty details for this replacement canopy are not provided in this manual. For information regarding warranty coverage, terms, and conditions, please refer to the product packaging or contact Garden Winds directly through their official website or customer service channels.

10. SUPPORT

If you require further assistance, have questions about installation, or need to report a product issue, please contact Garden Winds customer support. Refer to the contact information provided on the product packaging or visit the official Garden Winds website for support options.

Garden Winds Store: [Visit the Garden Winds Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question