

[Manuals.plus](#) /

› [Garden Winds](#) /

› Garden Winds Durable 350 Replacement Canopy Top for Living Accents 3-Person Deluxe Swing Model 8329948 Instruction Manual

Garden Winds LCM719BR

Garden Winds Durable 350 Replacement Canopy Top

Instruction Manual for Living Accents 3-Person Deluxe Swing Model 8329948

INTRODUCTION

This manual provides instructions for the proper installation, use, and maintenance of your Garden Winds Durable 350 Replacement Canopy Top. This canopy is specifically designed to fit the Living Accents 3-Person Deluxe Swing, model number 8329948. Please read these instructions carefully before proceeding with installation to ensure correct fit and optimal performance.

PRODUCT OVERVIEW

The Garden Winds Durable 350 Replacement Canopy Top (Model LCM719BR) is engineered for outdoor use, offering protection and durability. It is constructed from 350 denier polyester fabric, which is UPF 50+ UV resistant, water resistant, and CPAI-84 fire retardant. The design includes reinforced seams and Velcro straps for a secure fit.



DURABLE



**WATER
RESISTANT**



UV PROTECTED




**FIRE
RESISTANT**

BUILT FOR THE ELEMENTS



Image: Key features of the Garden Winds replacement canopy, highlighting its durability, water resistance, UV protection, and fire retardancy.

350D HIGH DENSITY FABRIC



ULTRA STITCH

VELCRO STRAPS



PREMIUM FEATURES




Image: Close-up view of the canopy's premium features, including high-density fabric, reinforced stitching, and secure attachment straps.

COMPATIBILITY

This replacement canopy top is designed for a custom fit on the **Living Accents 3-Person Deluxe Swing, Model 8329948**. It is crucial to verify your swing model number to ensure proper fit. The canopy dimensions are approximately 74 inches wide by 46 inches deep, with a 7-inch drop.

PLEASE CHECK YOUR MODEL

Compatible with the following model numbers:
8329948



COMPATIBILITY



Image: Diagram illustrating the approximate dimensions of the replacement canopy and confirming compatibility with Living Accents swing model 8329948.

VERIFY YOUR FRAME DETAILS



FRAME IDENTIFICATION



Image: Visual guide for identifying your swing frame, showing various details and attachment points to ensure correct canopy selection.

SETUP AND INSTALLATION

Follow these general steps to install your new replacement canopy top. It is recommended to have two people for easier installation.

1. **Prepare the Swing Frame:** Ensure your Living Accents 3-Person Deluxe Swing frame (Model 8329948) is clean and free of debris. If an old canopy is present, carefully remove it by detaching any straps, ties, or corner pockets from the frame.
2. **Unfold the New Canopy:** Gently unfold the Garden Winds replacement canopy top. Identify the front, back, and sides of the canopy.
3. **Position the Canopy:** Drape the new canopy over the top of the swing frame. Align the corners and edges of the canopy with the corresponding parts of the frame.
4. **Attach Corners and Edges:** Secure the canopy to the frame using the integrated Velcro straps or corner pockets. Start with one corner and work your way around, ensuring the fabric is taut and evenly distributed. Adjust as needed to remove any slack or wrinkles.

5. **Final Adjustments:** Once all attachment points are secured, check the canopy for proper tension and alignment. Ensure it is securely fastened to withstand outdoor conditions.



Image: The Garden Winds replacement canopy top fully installed on a Living Accents 3-person deluxe swing, demonstrating a proper fit.

USAGE

Once installed, your replacement canopy provides shade and protection from light rain and UV rays. While the fabric is durable and weather-resistant, it is recommended to remove the canopy during severe weather conditions, such as strong winds, heavy rain, or snow, to prevent damage to both the canopy and the swing frame.

MAINTENANCE

- **Cleaning:** Clean the canopy regularly with a soft brush or cloth and mild soap diluted in water. Rinse thoroughly with clean water and allow it to air dry completely before storage or continued use. Do not use harsh chemicals or abrasive cleaners, as these can damage the fabric's protective coatings.

- **Inspection:** Periodically inspect the canopy for any signs of wear, tear, or damage. Address minor issues promptly to prevent further deterioration.
- **Storage:** If storing the swing or canopy for an extended period, especially during off-season or harsh weather, remove the canopy, clean it, ensure it is completely dry, and store it in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

- **Canopy Does Not Fit:** Double-check that your swing is indeed the Living Accents 3-Person Deluxe Swing, Model 8329948. Compare the dimensions of your swing frame with the canopy specifications provided. If you have a different model, the canopy may not fit correctly.
- **Water Pooling:** Ensure the canopy is installed tautly and evenly across the frame. Sagging areas can collect water. Adjust the tension if possible.
- **Fading:** Over time, exposure to sunlight can cause fabric colors to fade. This is a normal process for outdoor textiles. The canopy is UV resistant to mitigate this, but complete prevention of fading is not possible.
- **Minor Tears/Punctures:** Small damages can often be repaired with fabric repair kits designed for outdoor materials. For significant damage, replacement may be necessary.

SPECIFICATIONS

Feature	Detail
Product Model Number	LCM719BR
Compatible Swing Model	Living Accents 3-Person Deluxe Swing Model 8329948
Material	350 Denier Polyester
Color	Brown
Approximate Dimensions (W x D x H)	74" x 46" x 7"
UV Resistance	UPF 50+
Water Resistance	Yes
Fire Retardancy	CPAI-84 Certified

WARRANTY AND SUPPORT

Your Garden Winds Replacement Canopy Top is backed by a **1-year limited performance warranty**. This warranty covers manufacturing defects and performance issues under normal use. For any questions regarding fit, product performance, or support, please contact Garden Winds customer service.

Garden Winds provides US-based customer support to assist with replacement product inquiries, model identification, compatibility guidance, and post-purchase assistance.

USA BASED CUSTOMER SUPPORT



REPLACEMENT PRODUCT SPECIALISTS

MODEL IDENTIFICATION SUPPORT

FIT & COMPATIBILITY GUIDANCE

POST-PURCHASE ASSISTANCE

FAST, RESPONSIVE SUPPORT

Image: Information on Garden Winds' US-based customer support, detailing the types of assistance available.

For further assistance, please visit the official Garden Winds website or contact their customer service directly. Contact information can typically be found on the product packaging or the Garden Winds store page on Amazon: [Garden Winds Store](#)

© 2026 Garden Winds. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question