

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Broyhill](#) /
- › Broyhill Primo Vista Dresser Mirror User Manual

Broyhill 4453-236

Broyhill Primo Vista Dresser Mirror User Manual

Model: 4453-236

INTRODUCTION

Thank you for choosing the Broyhill Primo Vista Dresser Mirror. This mirror is designed with a straightforward contemporary style, featuring a black-stain finish that complements modern decor. This manual provides essential information for the safe and proper setup, use, and maintenance of your new mirror.



Image: The Broyhill Primo Vista Dresser Mirror, showcasing its black-stained wooden frame and reflective surface. The mirror is rectangular with clean lines, reflecting its contemporary design.

SAFETY INFORMATION

Please read and understand all safety instructions before assembly or use. Failure to follow these instructions may result in injury or damage to the product.

- Always handle the mirror with care. Glass can break and cause injury.

- Ensure the mirror is securely mounted to a stable surface or dresser. Improper mounting can lead to the mirror falling.
- Keep children and pets away from the mirror during assembly and installation.
- Do not hang heavy objects from the mirror frame.
- If mounting to a wall, use appropriate hardware for your wall type (e.g., drywall anchors, stud finders). Consult a professional if unsure.

SETUP AND INSTALLATION

The Primo Vista Dresser Mirror is designed to be used with a compatible dresser or mounted independently. Assembly is not required for the mirror itself, but installation involves securing it.

Option 1: Attaching to a Dresser

1. Carefully unpack the mirror and inspect for any damage.
2. Position the mirror on the back of the compatible Primo Vista dresser.
3. Locate the pre-drilled holes on the mirror supports and the dresser.
4. Align the mirror supports with the holes.
5. Secure the mirror to the dresser using the provided screws and hardware. Ensure all connections are tight and stable.

Option 2: Wall Mounting (Portrait or Landscape)

The mirror includes mirror hangers for both landscape and portrait hanging orientations.

1. Determine the desired height and orientation (portrait or landscape) for your mirror.
2. Mark the wall where the top hangers will be located. Use a level to ensure marks are straight.
3. Install appropriate wall anchors (not included, as wall types vary) suitable for the mirror's weight (approximately 29 pounds) and your wall material.
4. Securely fasten screws or hooks into the wall anchors, ensuring they are strong enough to hold the mirror.
5. Carefully lift the mirror and hang it onto the installed wall hardware. Ensure the mirror is seated securely and level.
6. Gently test the mirror's stability by applying light pressure.

OPERATING (PLACEMENT AND USE)

Once installed, the Primo Vista Dresser Mirror requires no further "operation." Its primary function is to provide a reflective surface.

- **Placement:** Position the mirror in a location where it can best serve its purpose, such as above a dresser in a bedroom or in an entryway.
- **Lighting:** Consider the lighting in the room. Natural light can enhance the mirror's reflective qualities.
- **Stability Check:** Periodically check that the mirror remains securely attached to the dresser or wall.

MAINTENANCE AND CARE

Proper care will help maintain the beauty and longevity of your Primo Vista Dresser Mirror.

- **Cleaning the Glass:** Use a soft, lint-free cloth and a non-abrasive glass cleaner. Spray the cleaner onto the cloth, not directly onto the mirror, to prevent liquid from seeping into the frame edges. Wipe gently until clean and streak-free.
- **Cleaning the Frame:** Wipe the black-stain wood frame with a soft, dry, or slightly damp cloth. Avoid harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Dusting:** Regularly dust the mirror and frame with a soft, dry cloth.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the wood finish to fade or crack over time.

- **Humidity Control:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood frame.

TROUBLESHOOTING

If you encounter any issues with your mirror, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mirror appears wobbly or unstable.	Loose screws or improper installation.	Check all screws and connections. Tighten any loose hardware. If wall-mounted, ensure wall anchors are secure and appropriate for the weight.
Streaks or smudges on the mirror surface.	Improper cleaning technique or dirty cloth.	Use a clean, lint-free microfiber cloth and a streak-free glass cleaner. Spray cleaner onto the cloth, not directly onto the mirror.
Wood frame appears dull or discolored.	Accumulation of dust or exposure to harsh chemicals/sunlight.	Clean the frame with a soft, slightly damp cloth. Avoid abrasive cleaners. Consider repositioning if exposed to direct sunlight.

SPECIFICATIONS

Feature	Detail
Brand	Broyhill
Model Number	4453-236
Style	Contemporary
Finish Type	Black
Color	Black
Material	Wood
Item Weight	29 Pounds
Product Dimensions (L x W x H)	32 x 1.25 x 38 inches
Assembly Required	No (for mirror itself, but installation is required)
Country of Origin	Viet Nam
UPC	662675131719

WARRANTY AND SUPPORT

For information regarding warranty coverage, parts replacement, or technical support, please refer to the original purchase documentation or contact Broyhill customer service. Contact details are typically available on the manufacturer's official website or on your sales receipt.

When contacting support, please have your model number (4453-236) and date of purchase readily available.

