

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### Hot Wheels DTN42

# Hot Wheels Criss Cross Crash Track Set Instruction Manual

Model: DTN42

## PRODUCT OVERVIEW

The Hot Wheels Criss Cross Crash Track Set offers high-octane racing action with four intersecting crash zones and a car feeder ramp. This motorized track set is designed for continuous racing and thrilling crash moments, encouraging creative play and experimentation. It features over 16 feet of track, including hairpin turns and motorized boosters, along with integrated parking spaces for convenient storage.



The Hot Wheels Criss Cross Crash Track Set, as seen in its retail packaging.

## SETUP INSTRUCTIONS

Assembly of the Criss Cross Crash Track Set is straightforward. The track pieces are designed to easily click together. Each track piece and corresponding base attachment point is often labeled with letters to guide correct assembly, minimizing errors.



A hand demonstrates placing a Hot Wheels car onto the feeder ramp, ready for launch.

### **Battery Installation**

The motorized booster requires 4 D batteries (not included). Ensure batteries are installed correctly according to polarity markings in the battery compartment. It is recommended to have these batteries on hand before beginning assembly to ensure immediate play.

### **Track Assembly**

Connect the track pieces to the central base unit and attach the support stands to the loops. The click-together design allows for quick setup, typically within 15 minutes. Ensure all connections are secure to prevent track separation during play.



Two children engaging in the assembly and initial play with the track set.

## OPERATING INSTRUCTIONS

Once assembled and batteries are installed, turn on the motorized booster. Place Hot Wheels vehicles onto the feeder ramp. The booster will propel the cars around the track at high speeds, leading to exciting near misses and crashes at the intersecting points.



An overhead view highlighting the central crash zone where cars intersect.

### Multi-Car Play

For enhanced excitement, introduce multiple Hot Wheels cars onto the track. The objective is to create collisions within the designated crash zones. Most standard Hot Wheels vehicles are compatible with this track set, allowing for varied play experiences.



The complete track set with several Hot Wheels cars, illustrating the potential for multi-car action.

## MAINTENANCE

---

To ensure longevity and optimal performance of your Hot Wheels Criss Cross Crash Track Set, regular maintenance is recommended.

### Cleaning

Wipe down track pieces and the central unit with a dry or slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners. Ensure no dust or debris accumulates in the motorized booster area.

### Battery Replacement

Replace all 4 D batteries when the motorized booster's speed decreases or stops functioning. Always use new batteries and dispose of old batteries responsibly.

### Storage

The track set can be partially disassembled for storage. The central blue base unit does not break down, but all other track pieces can be detached. Store in a cool, dry place away from direct sunlight to prevent material degradation.

## TROUBLESHOOTING

---

- **Cars not moving or moving slowly:** Check battery levels and replace all 4 D batteries if needed. Ensure no debris is obstructing the motorized booster's wheels. Verify that the track pieces are securely connected and aligned.
- **Cars derailing frequently:** Ensure all track pieces are firmly clicked into place and the support stands are stable. Some Hot Wheels car models may perform better than others on the track; experiment with different cars. Check for any bent track pieces, as these can affect car flow.
- **Loud noise from booster:** The motorized booster naturally produces a noticeable sound during operation. This is normal for the product's design.

## SPECIFICATIONS

---

<b>Product Dimensions</b>	29.13 x 29.13 x 7.87 inches
<b>Item Weight</b>	1.85 pounds
<b>Country of Origin</b>	China
<b>Item Model Number</b>	DTN42
<b>Manufacturer Recommended Age</b>	5 years and up
<b>Batteries Required</b>	4 D batteries (not included)
<b>Release Date</b>	April 13, 2016
<b>Manufacturer</b>	Mattel

## SAFETY INFORMATION

---

**WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.**

## WARRANTY AND SUPPORT

---

For detailed warranty information or further support, please refer to the official user guide provided by the manufacturer. A digital version of the user guide can be accessed via the following link:

[Download User Guide \(PDF\)](#)

For additional assistance, please contact Hot Wheels customer service through their official website or the retailer where the product was purchased.

© 2025 Hot Wheels. All rights reserved.