

[Manuals.plus](#) /

› [Diesel](#) /

› Diesel Sideshow Chronograph Watch DZ7378 User Manual

Diesel DZ7378

Diesel Sideshow Chronograph Watch DZ7378 User Manual

Model: DZ7378

1. PRODUCT OVERVIEW

The Diesel Sideshow Chronograph Watch Model DZ7378 is a robust timepiece featuring a quartz movement, chronograph functionality, and a durable stainless steel construction. Designed for reliability and style, this watch includes a date display and is water-resistant up to 100 meters.



Figure 1.1: Front view of the Diesel Sideshow Chronograph Watch, showcasing the gold-toned case, black dial, and chronograph subdials.

Your browser does not support the video tag.

Video 1.1: An official product overview video demonstrating the Diesel Sideshow Chronograph Watch from various angles.

2. SETUP AND INITIAL USE

2.1 Setting the Time

1. Pull the crown (B) out to position 2.
2. Turn the crown to set the hour and minute hands to the correct time.
3. Push the crown back in to position 1.

2.2 Setting the Date

1. Pull the crown (B) out to position 1.
2. Turn the crown clockwise or counter-clockwise to set the correct date.
3. Push the crown back in to the normal operating position.

2.3 Band Adjustment

The stainless steel bracelet can be adjusted for a customized fit. It is recommended to have a professional jeweler adjust the links to prevent damage to the watch or band.



Figure 2.1: Side view of the watch, highlighting the crown (B) and chronograph pushers (A and C).

3. OPERATING THE CHRONOGRAPH

The chronograph function allows for precise timing of events. The watch features three subdials to track minutes, seconds, and 24-hour time.

1. **Start/Stop:** Press pusher **A** to start the chronograph. Press pusher **A** again to stop it.
2. **Reset:** While the chronograph is stopped, press pusher **C** to reset all chronograph hands to zero.

3.1 Water Resistance

This watch is water-resistant up to 10 ATM (100 meters / 330 feet). This rating means it is suitable for bathing, swimming, snorkeling, and shallow diving. **Do not operate the crown or pushers while the watch is wet or submerged** as this can compromise the water resistance.

4. MAINTENANCE

4.1 Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and bracelet with a soft, damp cloth. For stainless steel, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly. Avoid using harsh chemicals or abrasive materials.

4.2 Battery Replacement

The watch is powered by a CR123A battery. When the watch stops or the hands move erratically, the battery may need replacement. It is highly recommended to have the battery replaced by an authorized Diesel service center or a professional watchmaker to ensure proper sealing and maintain water resistance.



Figure 4.1: Rear view of the watch, showing the case back where battery access is located.

5. TROUBLESHOOTING

- **Watch not running:** Ensure the crown is fully pushed in to the normal operating position. If the watch still does not run, the battery may need replacement.
- **Chronograph hands not resetting to zero:** If the chronograph hands do not reset to their correct zero positions after pressing pusher C, consult a professional watchmaker for adjustment.
- **Date not changing:** Ensure the time is set correctly, passing midnight to advance the date. If the date still does not change, check the crown position for date setting.

6. SPECIFICATIONS

Feature	Specification
Model Number	DZ7378
Movement Type	Quartz
Case Material	Stainless Steel
Case Diameter	55 mm
Case Thickness	14 mm
Band Material	Stainless Steel
Band Width	26 mm
Crystal Type	Mineral
Water Resistance	10 ATM (100 meters / 330 feet)
Functions	Chronograph, Date Display, 24-hour time
Power Source	Battery (1 CR123A included)
Item Weight	8.8 ounces



Figure 6.1: Angled view of the watch, showcasing its overall design and proportions.

7. WARRANTY AND SUPPORT

7.1 Manufacturer's Warranty

This Diesel watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects under normal use.

7.2 Customer Support

For any questions, service, or repair needs not covered in this manual, please contact Diesel customer support or visit an authorized service center. Contact information can usually be found on the official Diesel website or on your warranty documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question