

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sunbeam](#) /

› [Sunbeam 1200W Steam Burst Handheld Steamer User Manual](#)

Sunbeam GCSBHS-100-000

Sunbeam 1200W Steam Burst Handheld Steamer User Manual

Model: GCSBHS-100-000 | Brand: Sunbeam

INTRODUCTION

The Sunbeam 1200W Steam Burst Handheld Steamer is designed to make steaming your clothes and fabrics a breeze. This convenient steamer features dual steam settings for various fabric types, a quick 30-second heat-up time, and a continuous steam option. It includes a bristle brush attachment for enhanced fiber penetration and an anti-drip system for mess-free operation. Its stand-up stable design and 8-foot 360° swivel cord offer ease of use and storage.



Figure 1: Sunbeam 1200W Steam Burst Handheld Steamer.

PRODUCT FEATURES

- **1200W Power:** Ensures quick heat-up in just 30 seconds for immediate use.
- **Dual Steam Settings:** Offers variable steam strengths (low/high) suitable for different fabrics.
- **Continuous Steam:** Provides up to 15 minutes of continuous steam for efficient wrinkle removal.
- **Bristle Brush Attachment:** Helps penetrate fibers for effective steaming on various materials.
- **Non-Stick Faceplate:** Glides smoothly over fabrics, preventing snags and damage.
- **Anti-Drip System:** Prevents water spills and messes during operation.
- **Auto-Off Feature:** Enhances safety by automatically shutting off the steamer when not in use.
- **LED Temperature Ready Light:** Indicates when the steamer has reached the optimal temperature for use.
- **Detachable 230ml Water Tank:** Easy to remove and fill for longer steaming sessions.

- **8-Foot 360° Swivel Cord:** Allows for freedom of movement and convenient reach.

SETUP

1. Fill the Water Tank:

Remove the detachable 230ml water tank from the base of the steamer. Open the fill cap and fill the tank with distilled water up to the 'MAX' line. Close the cap securely and reattach the water tank to the steamer until it clicks into place.



Figure 2: Easy-fill removable 230ml water tank.

2. Attach Accessories (Optional):

If desired, attach the bristle brush head to the steamer's faceplate. Ensure it is securely fastened before use.



Figure 3: Bristle brush attachment head included.

3. **Power On:**

Plug the steamer into a standard 120V electrical outlet. The LED temperature ready light will illuminate, indicating the steamer is heating up. It will be ready for use in approximately 30 seconds.



Figure 4: Steamer heats up in under 30 seconds.

OPERATING INSTRUCTIONS

1. Select Steam Setting:

Once the LED light indicates readiness, select your desired steam setting (Low or High) using the switch located on the top of the steamer. Low is suitable for delicate fabrics, while High is for heavier materials and stubborn wrinkles.



BRUSH ATTACHMENT HEAD INCLUDED

Figure 5: Low/High Fabric Temperature Select and LED Ready Light.

2. **Begin Steaming:**

Hold the steamer upright, ensuring the faceplate is facing the fabric. Press the steam trigger to release steam. For continuous steam, push the locking steam trigger down. This will keep the steam flowing without needing to hold the trigger.



Figure 6: Locking Steam Trigger for Continuous Steam.

3. **Steam Garments:**

Move the steamer slowly over the wrinkled area of the fabric, either vertically for hanging garments or horizontally for upholstery. The non-stick faceplate will glide easily. For extra stubborn wrinkles, use the extra-strength burst of steam feature by pressing the trigger firmly.



Figure 7: Extra Burst of Steam Feature in use.

4. Video Demonstration:

Watch the official product video for a visual guide on operating the Sunbeam Steam Burst Handheld Steamer.

Your browser does not support the video tag.

Video 1: Sunbeam - Steam Burst Handheld Steamer. This video demonstrates the features and operation of the steamer, including its quick heat-up and effective wrinkle removal.

Your browser does not support the video tag.

Video 2: Sunbeam Power Steam Fabric Handheld Steamer. This video highlights the powerful steam action and various applications of the steamer for different fabrics and household items.

MAINTENANCE

- **Empty Water Tank:** After each use, unplug the steamer and allow it to cool completely. Empty any remaining water from the tank to prevent mineral buildup.
- **Cleaning:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. For mineral buildup on the faceplate, a solution of equal parts white vinegar and water can be used, followed by wiping clean.
- **Storage:** Store the steamer in an upright position in a cool, dry place. The stable design supports easy storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty or not properly seated; steamer not fully heated; mineral buildup.	Refill water tank and ensure it's securely attached; wait for LED light to indicate readiness; clean the steamer as per maintenance instructions.
Water leaking from faceplate.	Steamer not fully heated; overfilled water tank; mineral buildup.	Allow steamer to heat completely before use; do not overfill the water tank; perform descaling if mineral buildup is suspected.
Steamer not turning on.	Not plugged in; power outlet issue; internal fault.	Ensure steamer is securely plugged into a working outlet; try a different outlet; if problem persists, contact customer support.

SPECIFICATIONS

Brand: Sunbeam

Model: GCSBHS-100-000

Wattage: 1200 watts

Voltage: 120 Volts

Heat Time: 30 seconds

Water Tank Capacity: 230 Milliliters

Item Weight: 2.46 Pounds

Product Dimensions: 6.88 x 5.03 x 11.22 inches

Manufacturer: Star Elite Inc.

Country of Origin: China


WARRANTY AND SUPPORT






This Sunbeam 1200W Steam Burst Handheld Steamer comes with a **1-year limited warranty** from the date of purchase. For warranty claims, technical support, or any product-related inquiries, please refer to the official Sunbeam customer support channels or visit their website.

An official User Manual (PDF) is also available for download: [Download User Manual \(PDF\)](#)

© 2023 Sunbeam. All rights reserved.

Related Documents - GCSBHS-100-000

	<p>Sunbeam Power Steam Fabric Steamer Owner's Guide GCSBHS-100 GCSBHS-200</p> <p>Owner's guide for the Sunbeam Power Steam Fabric Steamer (Models GCSBHS-100, GCSBHS-200). Includes important safety instructions, product features, accessories, operating procedures, care and cleaning, and troubleshooting tips.</p>
---	--

 <p>Sunbeam Steam Burst Handheld Steamer Défroisseur à main Steam Burst</p> <p>MODEL / MODÈLE: 32610047 ITEM / ARTICLE: 11952</p> <p>Owner's Guide / Mode d'emploi www.sunbeam.com</p>	<p>Sunbeam Steam Burst Handheld Steamer: Owner's Guide & Operating Instructions</p> <p>This guide provides comprehensive instructions for using, cleaning, and maintaining the Sunbeam Steam Burst Handheld Steamer. Learn about safety precautions, operating modes, and troubleshooting tips for effective garment care.</p>
 <p>Sunbeam Power Steam Handheld Steamer Défroisseur à main Power Steam</p> <p>MODEL / MODÈLE: 32610046 Owner's Guide / Mode d'emploi READ AND SAVE THESE INSTRUCTIONS LIREZ ET GARDEZ CES INSTRUCTIONS</p>	<p>Sunbeam Power Steam Handheld Steamer Model 32610046 Owner's Guide</p> <p>Official owner's guide and instructions for the Sunbeam Power Steam Handheld Steamer, model 32610046. Learn about important safeguards, operating instructions, care, cleaning, and troubleshooting.</p>
 <p>Sunbeam Power Shot Handheld Garment Steamer</p> <p>Before First Use</p> <p>1. Remove the cap from the steam nozzle and plug it into the power cord. 2. Plug the power cord into a standard household electrical outlet. 3. Turn the power switch on the handle to the "ON" position. 4. Hold the steam nozzle against the garment and press the trigger to release steam. 5. Release the trigger to stop the steam. 6. Turn the power switch off when finished.</p> <p>Sunbeam Power Shot Handheld Garment Steamer</p> <p>1. Steam nozzle 2. Power cord 3. Trigger switch 4. On/Off switch 5. Steam nozzle cap 6. Power switch</p>	<p>Sunbeam Power Shot Handheld Garment Steamer: Before First Use Guide</p> <p>Instructions and parts identification for the Sunbeam Power Shot Handheld Garment Steamer, including initial setup and usage notes.</p>
 <p>Sunbeam AeroCeramic Iron</p> <p>Before First Use</p> <p>1. Remove the cap from the steam nozzle and plug it into the power cord. 2. Plug the power cord into a standard household electrical outlet. 3. Turn the power switch on the handle to the "ON" position. 4. Hold the steam nozzle against the garment and press the trigger to release steam. 5. Release the trigger to stop the steam. 6. Turn the power switch off when finished.</p>	<p>Sunbeam AeroCeramic Iron User Manual and Safety Instructions</p> <p>Comprehensive guide for the Sunbeam AeroCeramic Iron, covering features, operation, safety precautions, maintenance, troubleshooting, and warranty information.</p>
 <p>Sunbeam PressXPress™ Steam Generator User Guide</p>	<p>Sunbeam PressXPress™ Steam Generator STC5000 User Guide</p> <p>Comprehensive user guide for the Sunbeam PressXPress™ Steam Generator model STC5000, covering safety precautions, features, operating instructions, care, cleaning, troubleshooting, and warranty information.</p>