

[Manuals.plus](#) /

› [XP-Pen](#) /

› XP-Pen G430S Graphic Drawing Tablet User Manual

XP-Pen G430S

XP-Pen G430S Graphic Drawing Tablet User Manual

Model: G430S

INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your XP-Pen G430S Graphic Drawing Tablet. Please read this guide thoroughly to ensure proper usage and to maximize your experience with the device.

WHAT'S IN THE BOX

Verify that all components are present in your package:

- XP-Pen G430S Drawing Tablet
- P01 Battery-free Stylus
- 10 x Replacement Nibs
- Pen-Clipper
- Quick Guide



Image: The package contents, including the G430S tablet, P01 battery-free stylus, 10 replacement nibs, pen-clipper, and quick guide.

SETUP

1. Driver Installation

- 1. Remove Other Drivers:** Before installing the XP-Pen driver, remove any other brand's tablet drivers from your computer and reboot the system to prevent conflicts.
- 2. Download Driver:** Visit the official XP-Pen website (www.xp-pen.com) and navigate to Support > FAQ. Find the Star G430 model and download the latest driver compatible with your operating system (Windows 11/10/8/7 or Mac OS X 10.10 or later).
- 3. Install Driver:** Close all drawing programs. Run the downloaded driver installer as an Administrator and follow the on-screen instructions.
- 4. Mac Users:** If using a Mac, grant necessary permissions in Mac preferences after installation for the tablet to function correctly. Detailed guidelines are available on the XP-Pen official website.

2. Connecting the Tablet

Connect the tablet to your computer using the provided Micro USB to USB-A cable. If your Mac lacks a USB-A port, an OTG transfer adapter (not included) will be required.



Image: The G430S tablet is shown connected to a laptop, highlighting its plug-and-play feature, ultra-thin profile (2mm), and portability.

3. Basic Configuration

- **Work Area:** The active area is 4 x 3 inches. Ensure this size meets your specific needs.
- **Left/Right Hand Mode:** The tablet is designed for both right and left-hand users. Adjust the mode through the tablet's driver settings.

OPERATING INSTRUCTIONS

1. Stylus Features

- **Battery-Free:** The P01 stylus does not require charging, allowing for continuous use.

- **Pressure Sensitivity:** Experience 8192 levels of pen pressure sensitivity for precise control and fluidity.
- **Customizable Buttons:** The stylus features two customizable buttons for quick access to functions like pen/eraser toggle.



Image: The P01 battery-free stylus is shown with icons indicating its battery-free design, 8192 pressure levels, and customizable buttons for switching between pen and eraser functions.

2. General Usage

- **Drawing & Design:** Use the tablet for digital drawing, painting, and sketching.
- **OSU! Game:** Designed for OSU! gameplay, no driver installation is required specifically for this application.
- **E-Signatures:** Facilitates electronic signatures for documents.
- **Mouse Replacement:** Can serve as a precise replacement for a traditional mouse.



Image: A visual representation of the tablet's versatility, including uses for painting, mouse replacement, e-signatures, sketching, OSU! gameplay, and picture editing.

3. Online Teaching & Remote Work

The G430S is compatible with Microsoft Office apps (Word, PowerPoint, OneNote), Zoom, Xsplit, and other online platforms, allowing for handwritten notes and precise visual presentations during online teaching or remote work.

The Star G430S graphics tablet is also can be used to teaching online classes, remote education, remote learning, etc.



Ready to host an online meeting with ZOOM and do your remote work at home? The XP-PEN Star G430S would be a good choice for you and it offers a more efficient and intuitive way for your remote work.




Image: The tablet being used for online teaching (teacher writing on a laptop) and remote work (professional using it with a desktop monitor for presentations).

4. Performance

The tablet features a report rate of 266 RPS, ensuring quicker and smoother line flow for enhanced overall performance.



Max Report Rate: 266 RPS



Designed for both right and
left hand users

Image: The G430S tablet with its stylus, highlighting the 266 RPS maximum report rate and its design for both right and left-handed users.

MAINTENANCE

1. Replacing Pen Nibs

Use the provided pen-clipper to carefully remove worn-out nibs from the stylus and insert new replacement nibs. Ensure the nib is securely seated.

2. Cleaning the Tablet

Wipe the tablet surface with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the surface.

3. General Care

Store the tablet and stylus in a safe place to prevent scratches or damage. Avoid placing heavy objects on the tablet.

TROUBLESHOOTING

- **Driver Conflicts:** If the tablet is not responding or behaving erratically, ensure all other tablet drivers are uninstalled and the XP-Pen driver is correctly installed and updated. Reboot your computer after any driver changes.
- **Pen Not Responding:** Check the USB connection. Ensure the stylus nib is properly inserted. If using a Mac, verify that necessary permissions have been granted.
- **Compatibility Issues:** The tablet is compatible with Windows 11/10/8/7 (32/64 bit) and Mac OS X 10.10 or later. It is not compatible with iOS or iPad OS. For specific EMR or signature systems, contact XP-Pen support to confirm compatibility.

SPECIFICATIONS

Feature	Specification
Product Dimensions	8.66 x 4.84 x 1.38 inches
Item Weight	8.8 ounces
Item Model Number	StarG430
Brand	XP-Pen
Connectivity Technology	USB
Pressure Sensitivity	8192 Levels
Operating System	Windows 7 and above, Mac OS X version 10.10 or later
Special Feature	Stylus

WARRANTY & SUPPORT

For product support, driver downloads, and FAQs, please visit the official XP-Pen website. Engage with XP-Pen on social media platforms like Facebook, YouTube, and VK to potentially extend your product warranty by one month.

PRODUCT OVERVIEW VIDEO

Video: An official overview of the XP-Pen G430S graphic tablet, highlighting its ultra-slim design, portability, battery-free stylus with 8192 pressure levels, and wide application for drawing, OSU! gameplay, and e-signatures.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question