

[Manuals.plus](#) /

› [Michael Kors](#) /

› Michael Kors Slim Runway Women's Watch MK3513 User Manual

Michael Kors MK3513

Michael Kors Slim Runway Women's Watch MK3513 User Manual

Model: MK3513

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Michael Kors Slim Runway Women's Watch, Model MK3513. This timepiece features a rose gold-tone stainless steel design, a 33mm case, and a classic three-link bracelet. It is designed for everyday wear with a sophisticated aesthetic.

SETUP

1. Unboxing

Your Michael Kors watch comes securely packaged in a protective box. Carefully remove the watch and any accompanying documentation.



Image: The Michael Kors Slim Runway watch presented in its white box.

2. Setting the Time


1. **Locate the Crown:** The crown is the small knob on the right side of the watch case.
2. **Pull Out the Crown:** Gently pull the crown outwards to the time-setting position. You may feel a slight click.
3. **Adjust the Time:** Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
4. **Push In the Crown:** Once the time is set, push the crown back into its original position. This will start the watch movement.



Image: Side view of the watch, highlighting the crown used for time adjustment.

3. Bracelet Adjustment

The stainless steel bracelet is designed to be adjustable. If the watch does not fit comfortably, links can be removed by a qualified jeweler or watch technician to achieve a customized fit. Do not attempt to remove links yourself without proper tools and knowledge, as this may damage the bracelet.



Case Material
Stainless Steel



Strap Material
Stainless Steel

Image: The watch from the back, with the clasp open, illustrating the bracelet structure.

OPERATING THE WATCH

Timekeeping

Your Michael Kors Slim Runway watch features a precise quartz movement with a three-hand analog display (hour, minute, second). Once the time is set, the watch will continuously display the current time.



Image: Clear front view of the watch face, showing the hour, minute, and second hands.

Water Resistance

This watch is water resistant up to 50 meters (165 feet) or 5 ATM. This means it is suitable for short periods of recreational swimming in shallow water. It is **not** suitable for diving, snorkeling, or high-impact water sports. Avoid operating the crown while the watch is wet to prevent water intrusion.

MAINTENANCE

Cleaning

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For more thorough cleaning, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

Battery Replacement

The watch is powered by one LR44 battery. When the watch stops running or the second hand begins to skip, it indicates that the battery needs replacement. It is recommended to have the battery replaced by a professional watch technician to ensure proper sealing and water resistance.

Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight and extreme temperatures. The original watch box can be used for safe storage.

TROUBLESHOOTING

- **Watch Not Running:**

- Check if the crown is fully pushed in.
- The battery may need replacement. Consult a professional watch technician.

- **Inaccurate Time:**

- The battery may be low.
- The watch may have been exposed to strong magnetic fields.

- **Water Inside the Watch:**

- Immediately take the watch to a professional watch repair center. Do not attempt to open the watch yourself.

SPECIFICATIONS

Feature	Detail
Model Number	MK3513
Case Material	Stainless Steel
Case Diameter	33mm
Case Thickness	8mm
Dial Color	Rose
Crystal Material	Mineral
Band Material	Stainless Steel
Band Color	Rose Gold-Tone
Band Width	18mm
Movement	Quartz (Three-hand analog)
Water Resistance	50m (165ft) / 5 ATM
Battery Type	1 LR44 (included)
Product Dimensions	3.7 x 3.7 x 3.7 inches

Item Weight

3.53 ounces



Image: Visual representation of the watch dimensions, including case size, strap width, and case thickness.

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your watch or visit the official Michael Kors website. For product support, contact Michael Kors customer service or the retailer from whom the watch was purchased.

SAFETY INFORMATION

- Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes.
- Keep the watch away from strong magnetic fields, as this can affect the accuracy of the quartz movement.
- Do not attempt to open the watch case, as this may compromise its water resistance and void the warranty.
- Clean the watch regularly to prevent dirt and debris buildup, which can affect its functionality and appearance.
- If you experience any skin irritation from wearing the watch, discontinue use and consult a medical professional.