

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Farberware](#) /

› Farberware Bakeware 9x5 Inch Nonstick Loaf Pan Set (2-Piece) Instruction Manual

Farberware 46405

Farberware Bakeware 9x5 Inch Nonstick Loaf Pan Set (2-Piece) Instruction Manual

Model: 46405

1. PRODUCT OVERVIEW

The Farberware Bakeware 9x5 Inch Nonstick Loaf Pan Set is designed for baking a variety of items, including breads, cakes, and meatloaf. This set includes two rectangular loaf pans, each measuring 9 inches by 5 inches. Constructed from heavy-duty steel, these pans feature a nonstick coating for easy food release and cleanup.



Image: Farberware 9x5 Inch Nonstick Loaf Pans.

2. KEY FEATURES

- **Heavy-Duty Steel Construction:** Designed for durability and resistance to warping, ensuring long-lasting performance.
- **Nonstick Coating:** Features a nonstick surface both inside and out for effortless food release and simplified cleaning.
- **Even Heat Distribution:** The durable material promotes even heat distribution, which helps prevent hot spots and ensures consistent baking and browning.
- **Oven Safe:** Safe for use in ovens up to 450 degrees Fahrenheit (232°C).
- **Versatile Use:** Ideal for baking various quick breads, yeast breads, pound cakes, meatloaf, and other savory dishes.

3. SETUP

Before first use, wash the loaf pans thoroughly with warm, soapy water. Rinse and dry completely. It is recommended to lightly grease or flour the interior of the pan before adding ingredients, even with the nonstick coating, to ensure optimal food release and extend the life of the nonstick surface.



Image: Clean Farberware Nonstick Loaf Pan.

4. OPERATING INSTRUCTIONS

1. **Preheat Oven:** Preheat your oven to the temperature specified in your recipe. The pans are oven safe up to 450°F (232°C).
2. **Prepare Pan:** Lightly grease or flour the inside of the loaf pan(s) as desired, even with the nonstick surface.
3. **Add Ingredients:** Pour or place your batter or mixture into the prepared pan(s). Do not overfill; typically, fill to about two-thirds full to allow for rising.
4. **Bake:** Place the pan(s) in the preheated oven. Follow your recipe's baking time.
5. **Check Doneness:** Use a toothpick or internal thermometer to check if your baked good is done.
6. **Cool:** Once baking is complete, carefully remove the pan(s) from the oven using oven mitts. Allow the baked good

to cool in the pan for 10-15 minutes before inverting onto a wire rack to cool completely.

VERSATILE PERFORMANCE



PERFECT FOR BOTH SWEET
AND SAVORY DISHES

FARBERWARE®

Image: Baked loaf in a Farberware pan.

5. MAINTENANCE AND CARE

- **Hand Washing Recommended:** For best results and to preserve the nonstick coating, hand wash the pans with warm, soapy water. Rinse thoroughly and dry immediately.
- **Avoid Abrasive Cleaners:** Do not use abrasive cleaners, scouring pads, or metal utensils, as these can damage the nonstick surface.
- **Proper Storage:** Store pans carefully to prevent scratching of the nonstick surface. Placing a paper towel or cloth between stacked pans can help.
- **Oven Use Only:** These pans are designed for oven use. Do not use on stovetops, under broiler, or in microwave ovens.



Image: Farberware Bakeware in a dishwasher. Hand washing is recommended for optimal care.


6. TROUBLESHOOTING

- **Food Sticking:** Ensure the pan was adequately greased or floured before adding ingredients. Over time, nonstick coatings can degrade; consider using parchment paper for very sticky recipes.
- **Uneven Baking:** Verify your oven temperature with an oven thermometer. Ensure pans are placed in the center of the oven rack for even heat circulation. Avoid overcrowding the oven.
- **Pan Warping:** While designed to resist warping, extreme temperature changes can affect metal bakeware. Allow pans to cool gradually before washing.
- **Discoloration:** Minor discoloration over time is normal with bakeware and does not affect performance.

7. SPECIFICATIONS

Brand	Farberware
-------	------------

Model Number	46405
Material	Heavy-Duty Steel
Color	Gray
Shape	Rectangular
Dimensions (each pan)	9 inches x 5 inches (22.86 cm x 12.7 cm)
Included Components	Two (2) Loaf Pans
Oven Safe Temperature	Up to 450°F (232°C)
Special Features	Nonstick, Oven Safe



9 x 5 in. Loaf Pans (2)

2-piece Bakeware Set

FARBERWARE®

8. WARRANTY AND SUPPORT

Farberware provides a quality assurance guarantee for this bakeware set. For specific details regarding warranty coverage, claims, or product support, please refer to the official Farberware website or contact their customer service directly.

For additional information or to explore other Farberware products, visit the [Farberware Store on Amazon](#).