

## BedJet BedJet 3

# BedJet 3 Climate Comfort System User Manual

Model: BedJet 3 - Any Size Bed Single Temp. Zone

Brand: BedJet

## 1. INTRODUCTION

The BedJet 3 Climate Comfort System is designed to provide on-demand cooling, warming, and sweat-drying comfort directly in your bed. This system works with any size bed or mattress, including adjustable beds, offering a personalized sleep environment. It is engineered for ease of use and integrates advanced climate control technology to enhance sleep quality.



Image 1.1: The BedJet 3 unit and its advanced remote control, showcasing the compact design and user interface.

## Key Features:

- **Instant Cooling & Warming:** Provides rapid temperature adjustments for a comfortable sleep environment.
- **Sweat Elimination:** Powered ventilation cooling effectively wicks away body heat and moisture, addressing night sweats and hot flashes.
- **Therapeutic Warmth:** Delivers a deep, sauna-like warmth in seconds, beneficial for cold feet and legs, and a safer alternative to electric blankets.
- **Biorhythm Sleep Technology:** Allows for automated, smart temperature control by programming different settings for each hour of the night.
- **Compact Design:** The BedJet 3 is 30% smaller than previous models, allowing for discreet placement.
- **Advanced Remote Control:** Features a color LCD screen and backlit keys for intuitive operation.

## 2. SETUP GUIDE

Proper setup ensures optimal performance of your BedJet 3 system. Follow these steps carefully.

### 2.1 Unboxing and Components

Before beginning, verify all components are present in the box:



Image 2.1: Contents of the BedJet 3 package. Note: Cloud Sheet is sold separately.

- BedJet 3 Unit
- Air Hose
- Nozzle
- Mattress Bracket
- Smart Remote
- 2 x AA Batteries (for remote)

### 2.2 Unit Placement

Position the BedJet 3 unit on the floor next to your bed, ensuring it fits comfortably under the bed frame. The unit is designed to be compact and discreet.



Image 2.2: The BedJet 3 unit is designed to fit under most bed frames, with a height of approximately 5.75 inches.



Image 2.3: Proper placement of the BedJet 3 unit under the bed, ensuring adequate space for airflow.

## 2.3 Hose and Nozzle Connection

1. Connect the air hose to the BedJet 3 unit's air outlet.
2. Attach the nozzle to the other end of the air hose.
3. Secure the nozzle and hose assembly using the mattress bracket, positioning it between your mattress and box spring/bed frame. Ensure the nozzle points towards the foot of the bed, directing airflow under your bedding.



Image 2.4: The BedJet 3 unit with its hose connected and positioned to direct airflow under the bedding.



Image 2.5: Visual guide for connecting the BedJet 3 to your bed, illustrating the hose and nozzle setup.

## 2.4 Power Connection

Plug the BedJet 3 unit into a standard electrical outlet. The unit is now ready for operation.

## 3. OPERATING INSTRUCTIONS

The BedJet 3 offers various modes and settings for personalized climate control. Use the included smart remote control or the BedJet app (if applicable) to manage your comfort.



Image 3.1: The BedJet 3 smart remote control, featuring a color LCD screen and intuitive buttons.

### 3.1 Basic Controls

- **Power On/Off:** Press the **OFF** button to turn the unit on or off.
- **Cooling Mode:** Press the **COOL** button to activate cooling. Adjust fan speed with **FAN +/-** and temperature with **TEMP +/-**.
- **Heating Mode:** Press the **HEAT** button to activate heating. Adjust fan speed with **FAN +/-** and temperature with **TEMP +/-**.
- **Fan Speed:** Use the **FAN +/-** buttons to increase or decrease the airflow intensity.
- **Temperature Adjustment:** Use the **TEMP +/-** buttons to set your desired temperature.

### 3.2 Advanced Functions

- **Biorhythm Sleep Technology:** This feature allows you to program a personalized temperature profile for each hour of the night. Access this function via the remote's menu or the BedJet app to set varying temperatures throughout your sleep cycle.
- **Memory Settings (M1, M2, M3):** Save your favorite cooling or heating settings for quick access. Press and hold an **M** button to save the current settings, then press briefly to recall them.
- **Turbo Mode:** For rapid cooling or heating, press the **TURBO** button. This will temporarily maximize airflow and temperature output.
- **Dry Mode:** The **DRY** button activates a specialized mode to help wick away moisture and dry out bedding, particularly useful for night sweats.
- **Timer (10H):** Use the **10H** button to set a sleep timer for up to 10 hours of continuous operation.

## 4. MAINTENANCE

Maintaining your BedJet 3 is simple and ensures its longevity and optimal performance.

### 4.1 Cleaning

- **Unit Exterior:** Wipe the exterior of the BedJet 3 unit with a dry, soft cloth to remove dust and debris. Do not use liquid cleaners or abrasive materials.
- **Air Filter:** Periodically check the air intake filter on the unit. Clean or replace as necessary to maintain optimal airflow and prevent dust buildup. Refer to the full product manual for detailed filter maintenance instructions.

### 4.2 General Care

- Ensure the air hose is not kinked or obstructed during use.
- Keep the area around the BedJet 3 unit clear to allow for proper air intake and exhaust.
- Store the unit in a dry, cool place when not in use for extended periods.

## 5. TROUBLESHOOTING

This section addresses common questions and issues you might encounter with your BedJet 3.

### 5.1 Performance Expectations

It is important to understand the operational principles of the BedJet 3:

**BedJet is NOT a Portable Air Conditioner:** The BedJet 3 moves ambient temperature air with convective cooling. It does not actively chill the air like an air conditioning unit. If your bedroom temperature is regularly over 78°F (25.5°C), the extreme heat may overwhelm the cooling method. For very warm rooms, investing in an air conditioner is recommended first.

The BedJet 3 is designed to provide personalized climate control within your bedding, not to cool an entire room.

### 5.2 Noise Levels

The BedJet 3 operates with a quiet DC motor. Its noise level is comparable to a soft whisper or gentle rainfall, providing a low-level white noise that many users find conducive to sleep.


# Clinically proven by doctors to help you sleep better



fell asleep faster,  
stayed asleep longer,  
woke less frequently



had improvement in  
daytime function and  
reduced fatigue



got significant relief  
from night sweats and  
hot flashes

\*Based on an IRB approved clinical study published by The North American Menopause Society (NAMS).  
The Efficacy of the BedJet Climate System® for Peri-Menopausal Night Sweat and Hot Flash Symptoms and Corresponding Impact on Sleep, 2018.

Image 5.1: BedJet 3 noise levels typically range from 30-46 dB(A), comparable to a soft whisper (30 dB(A)) or less than rainfall (50 dB(A)).

## 5.3 Common Issues

- **Unit Not Powering On:** Ensure the power cord is securely plugged into both the unit and a working electrical outlet.
- **No Airflow:** Check that the air hose is properly connected and not kinked or obstructed. Verify the air intake on the unit is clear of blockages.
- **Remote Not Responding:** Replace the AA batteries in the remote control. Ensure there are no obstructions between the remote and the BedJet unit.
- **Temperature Not Reaching Desired Level:** Confirm the room temperature is within a reasonable range for the BedJet to operate effectively. Remember it uses ambient air.

## 6. SPECIFICATIONS

Detailed technical specifications for the BedJet 3 Climate Comfort System.

| Specification     | Detail     |
|-------------------|------------|
| Brand             | BedJet     |
| Model Name        | BedJet 3   |
| Item Model Number | BedJet 3   |
| ASIN              | B01BMCWJ7G |

| Specification             | Detail                                   |
|---------------------------|------------------------------------------|
| UPC                       | 858086005095                             |
| Manufacturer              | BEDJET LLC                               |
| Product Dimensions        | 15.5 x 10.5 x 6 inches                   |
| Item Weight               | 14.34 pounds                             |
| Color                     | White                                    |
| Material                  | Plastic                                  |
| Special Feature           | Adjustable, Cooling                      |
| Product Care Instructions | Wipe with dry cloth                      |
| Batteries Required        | Yes (2 AA batteries included for remote) |

## 7. WARRANTY AND SUPPORT

BedJet is committed to providing high-quality products and customer satisfaction.

### 7.1 Warranty Information

The BedJet 3 Climate Comfort System comes with a **2-Year Protection** warranty. This bumper-to-bumper coverage applies to the BedJet unit and any accessory parts included in the box.

### 7.2 Return Policy

A 30-day refund or replacement policy is typically available for this product. Please refer to your purchase documentation or retailer's policy for specific details regarding returns.

### 7.3 Customer Support

For further assistance, technical support, or warranty claims, please contact BedJet customer service. Visit the official BedJet website for contact information and additional resources.

© 2025 BedJet LLC. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**