

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [mDesign](#) /

› [Instruction Manual for mDesign Large Plastic Storage Bin](#)

mDesign 1660MDBAEU

Instruction Manual for mDesign Large Plastic Storage Bin

Model: 1660MDBAEU

PRODUCT OVERVIEW

The mDesign Large Plastic Storage Bin is designed to help organize various items in your home, particularly in bathrooms, cupboards, cabinets, under sinks, or on counters. Its clear design allows for easy visibility of contents, and integrated handles provide convenient portability.



Image: The mDesign Large Plastic Storage Bin, shown here filled with various bath products and a body brush, demonstrating its capacity and clear design.

SETUP AND INITIAL USE

- Unpacking:** Carefully remove the storage bin from its packaging. Inspect for any damage during transit.
- Initial Cleaning:** Before first use, it is recommended to wash the bin with mild soap and water. Rinse thoroughly and dry completely with a soft cloth. Avoid abrasive cleaners or scrubbers that could scratch the plastic surface.
- Placement:** Place the bin in your desired location, such as a bathroom cabinet, under the sink, on a counter, or in a cupboard. Ensure the surface is stable and level.



Image: An empty mDesign Large Plastic Storage Bin, highlighting its clear construction and integrated handles, ready for use.

OPERATING INSTRUCTIONS

This storage bin is designed for versatile organization throughout your home. Its clear construction allows for quick identification of contents, making it ideal for various storage needs.

- **Bathroom Organization:** Use the bin to store toiletries, hair tools, makeup, cleaning supplies, or extra toilet paper. Its size is suitable for fitting into most standard bathroom cabinets or under sinks.



Image: Two mDesign storage bins neatly placed inside a white bathroom cabinet, demonstrating their fit and capacity for organizing towels and various bottles.

- **Multi-Room Versatility:** The bin can be utilized in various rooms beyond the bathroom. Consider using it in:
 - *Kitchen:* For pantry items, snacks, or cleaning supplies.
 - *Laundry Room:* For detergents, dryer sheets, or cleaning accessories.
 - *Playroom:* For small toys, craft supplies, or art materials.
 - *Bedroom/Closet:* For accessories, socks, or small clothing items.

KITCHEN



LAUNDRY



TOYS



BATH



Image: A composite image illustrating the versatile use of the mDesign storage bin across different home areas: kitchen (holding jars), laundry (holding detergent and dryer balls), toys (holding colorful balls), and bath (holding large bottles).

- **Portability:** The integrated handles allow for easy transport of the bin from one location to another, even when filled.

MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your mDesign storage bin.

- **Cleaning:** Clean the bin regularly with mild soap and water. Use a soft cloth or sponge to wipe surfaces. Rinse thoroughly to remove all soap residue.
- **Drying:** Dry the bin immediately after cleaning to prevent water spots, especially on the clear plastic. A microfiber cloth is ideal for a streak-free finish.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, ammonia-based products, or solvents (like alcohol or paint thinner) as these can damage or cloud the plastic.

- **Prevent Scratches:** Avoid dragging the bin across rough surfaces. Do not use sharp objects inside the bin that could scratch the interior. Store items carefully to prevent impact damage.
- **Temperature:** Do not expose the bin to extreme temperatures, such as direct sunlight for prolonged periods or very hot liquids, as this may cause warping or discoloration.

TROUBLESHOOTING

While the mDesign storage bin is a simple and durable product, here are some common considerations and their solutions:

Issue	Possible Cause / Solution
Bin appears scratched or scuffed upon arrival.	While products are inspected, minor surface imperfections can sometimes occur during manufacturing or shipping. If the damage significantly impacts functionality or aesthetics, please contact customer support for assistance.
Bin does not fit in intended space.	Always measure your intended storage space (width, depth, height) before purchasing. Refer to the "Specifications" section for exact product dimensions.
Plastic appears cloudy or discolored over time.	This can be caused by using harsh cleaning chemicals, prolonged exposure to direct sunlight, or accumulation of hard water stains. Ensure you follow the "Maintenance and Care" guidelines. For hard water stains, a diluted vinegar solution followed by thorough rinsing may help.
Bin feels unstable when filled.	Ensure the bin is placed on a flat, stable surface. Distribute contents evenly to maintain balance. Avoid overfilling, especially with heavy items.

SPECIFICATIONS

Detailed specifications for the mDesign Large Plastic Storage Bin:

Feature	Detail
Model Number	1660MDBAEU
Material	Plastic
Color	Clear
Product Dimensions (L x W x H)	16" L x 5.75" W x 6" H (40.6cm L x 14.6cm W x 15.2cm H)

Feature	Detail
Item Weight	1.43 pounds
Special Feature	Integrated Handle(s)
UPC	841247116600




Image: A diagram illustrating the precise dimensions of the mDesign storage bin, including its length (16 inches / 40.6 cm), width (5.75 inches / 14.6 cm), and height (6 inches / 15.2 cm).

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For any product-related inquiries, support, or warranty claims, please refer to the manufacturer's official website or contact their customer service directly.

You can typically find contact information on the product packaging or by visiting the mDesign official website [Visit the mDesign Store on Amazon](#)

© 2024 mDesign. All rights reserved.