

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NERF](#) /

› [Nerf Modulus Tri-Strike Blaster Toy Instruction Manual](#)

## NERF B5577EU4

# Nerf Modulus Tri-Strike Blaster Toy Instruction Manual

Model: B5577EU4

## PRODUCT OVERVIEW

The Nerf Modulus Tri-Strike blaster offers three distinct ways to engage in play, allowing for versatile configurations. This system enables users to combine different components to create a customized blaster for various scenarios. It includes an Elite Dart Blaster, a Mega Barrel Extension, and a Missile Launcher with a Missile Launcher Stock.



Figure 1: The Nerf Modulus Tri-Strike Blaster fully assembled, showcasing its modular design.

## SAFETY INFORMATION

Please read and understand all safety warnings before use. This product is recommended for ages 8 and up.

- **CAUTION:** Do not aim at eyes or face.
- **TO AVOID INJURY:** Use only darts designed for this product. Do not modify darts or dart blaster.
- **WARNING: CHOKING HAZARD** – Small parts may be generated. Not for children under 3 years.

## SETUP AND ASSEMBLY

The Nerf Modulus Tri-Strike blaster comes with several components that can be assembled in various configurations. Follow these steps for initial setup:

1. **Unpack Components:** Carefully remove all parts from the packaging. You should have the Elite Dart Blaster, Mega Barrel Extension, Missile Launcher, Missile Launcher Stock, 10 Elite darts, 4 Mega darts, and 1 missile.
2. **Assemble Elite Dart Blaster:** This is the core component. Ensure it is ready for attachments.
3. **Attach Mega Barrel Extension:** Slide the Mega Barrel Extension onto the front of the Elite Dart Blaster until it clicks securely into place. This allows for firing Mega darts.
4. **Attach Missile Launcher and Stock:** The Missile Launcher can be attached to the top tactical rail of the Elite Dart Blaster. The Missile Launcher Stock attaches to the rear of the Elite Dart Blaster. These can also be combined to form a standalone missile blaster.



Figure 2: Packaging view showing the main components of the Nerf Modulus Tri-Strike Blaster.

## OPERATING INSTRUCTIONS

The Tri-Strike blaster offers three primary firing modes:

### 1. Elite Dart Blaster Operation

1. **Load Magazine:** Insert Elite darts into the 10-dart clip.
2. **Insert Magazine:** Push the loaded magazine firmly into the magazine well of the Elite Dart Blaster until it locks into place.
3. **Prime Blaster:** Pull the priming handle (located on either side of the blaster) all the way back and then push it forward to chamber a dart.
4. **Fire:** Pull the trigger to fire a single Elite dart. For rapid-sliding-bolt-action, continue priming and firing.

### 2. Mega Barrel Extension Operation

(Requires Mega Barrel Extension attached to Elite Dart Blaster)

- Load Mega Darts:** Insert Mega darts into the front of the Mega Barrel Extension.
- Prime and Fire:** The Mega Barrel Extension operates independently. Pump the handle located on the underside of the Mega Barrel Extension to fire a Mega dart.

### 3. Missile Launcher Operation

(Can be attached to Elite Dart Blaster or used as a standalone unit)

- Load Missile:** Push the missile onto the launching post at the front of the Missile Launcher.
- Prime Launcher:** Pull the pump handle on the Missile Launcher Stock back and forth several times to build air pressure.
- Fire:** Press the trigger on the Missile Launcher to launch the missile.

## MAINTENANCE

To ensure the longevity and optimal performance of your Nerf Modulus Tri-Strike Blaster, follow these maintenance guidelines:

- Cleaning:** Wipe down the blaster with a dry or slightly damp cloth. Do not submerge the blaster in water or use harsh chemicals.
- Dart Care:** Store darts in a clean, dry place. Avoid bending or crushing darts, as this can affect their performance.
- Storage:** Store the blaster and its components in a cool, dry environment away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

If you encounter issues with your Nerf Modulus Tri-Strike Blaster, try the following solutions:

- Darts Not Firing or Jamming:**
  - Ensure darts are fully inserted into the magazine or barrel.
  - Check if darts are damaged or bent; replace if necessary.
  - Ensure the blaster is fully primed before pulling the trigger.
  - For Elite Dart Blaster, ensure the magazine is securely inserted.
- Missile Not Launching:**
  - Ensure the missile is properly seated on the launching post.
  - Pump the Missile Launcher Stock sufficiently to build enough air pressure.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	13.39 x 12.6 x 5.91 inches
Item Weight	4.59 pounds
Item Model Number	B5577EU4

Manufacturer Recommended Age	8 - 18 years
Material	Plastic
Manufacturer	Hasbro
Release Date	January 1, 2018

## **WARRANTY AND SUPPORT**

---

For warranty information or product support, please refer to the documentation included with your purchase or visit the official NERF website. Contact information for customer service can typically be found on the product packaging or the manufacturer's website.

---

© 2024 NERF. All rights reserved.