

Manuals.plus /

› Schleich /

› Schleich Wild Life Oryx Toy Figurine Instruction Manual

Schleich 14759

Schleich Wild Life Oryx Toy Figurine Instruction Manual

Brand: Schleich

Model: 14759

1. INTRODUCTION

This manual provides essential information for the safe and enjoyable use of your Schleich Wild Life Oryx Toy Figurine. Designed for realistic play, this figurine encourages imaginative storytelling and learning about wildlife. Please read this manual thoroughly to understand the product's features and care requirements.

2. SAFETY INFORMATION

The Schleich Wild Life Oryx Toy Figurine is suitable for children aged 3 years and older. This product does not require specific safety labeling beyond age recommendations. Ensure children play with the figurine under appropriate supervision, especially younger children, to prevent misuse.

3. PACKAGE CONTENTS

- 1 Schleich Wild Life Oryx Toy Figurine

4. SETUP

The Schleich Oryx Toy Figurine is ready for play directly out of its packaging. No assembly is required. Simply remove the figurine from its packaging to begin play.

5. OPERATING INSTRUCTIONS

The Oryx Toy Figurine is designed for imaginative play. Children can integrate it into various play scenarios, such as safari adventures, desert explorations, or animal collections. Its realistic design supports educational play about wildlife.



Figure 1: Front view of the Schleich Wild Life Oryx Toy Figurine, showcasing its detailed features and coloration.



Figure 2: Side view of the Schleich Wild Life Oryx Toy Figurine, highlighting its long, distinctive horns and body markings.



Figure 3: Rear view of the Schleich Wild Life Oryx Toy Figurine, showing tail and hind leg details.

Product Video

Your browser does not support the video tag.

Video 1: An official product video showcasing the Schleich Wild Life Oryx Toy Figurine from various angles. This video provides a dynamic view of the figurine's design and detail.

6. MAINTENANCE

To maintain the quality and appearance of your figurine:

- **Cleaning:** Wipe the figurine with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as these may damage the paint or material.
- **Storage:** Store in a cool, dry place away from direct sunlight to prevent material degradation or color fading.

7. TROUBLESHOOTING

This section addresses common minor concerns with the product.

- **Issue:** Figurine appears dirty or dusty.
Solution: Refer to the 'Maintenance' section for cleaning instructions. Gentle wiping with a damp cloth is usually sufficient.
- **Issue:** Minor scuffs or marks on the figurine.
Solution: These are typically cosmetic and do not affect the figurine's function or durability. Gentle cleaning may reduce their appearance.

8. SPECIFICATIONS




Figure 4: The Oryx Toy Figurine with approximate dimensions of 4.4 inches (11 cm) in height.

Feature	Detail
Product Dimensions	4.3 x 4.3 x 4.5 inches
Item Weight	2.27 ounces
ASIN	B01BPF6SEK
Item Model Number	14759
Manufacturer Recommended Age	36 months - 8 years
Release Date	July 1, 2016
Manufacturer	Schleich

9. WARRANTY

Schleich products are manufactured to high-quality standards and are designed for durability and longevity. While specific warranty terms may vary by region, Schleich is committed to producing toys that are built to last for generations and meet national and international safety standards. For detailed warranty information or specific inquiries, please refer to the official Schleich website or contact customer support.

10. SUPPORT

For further assistance, product information, or to explore other Schleich products, please visit the official Schleich website:

www.schleich-s.com

You may also find contact information for customer service on the website for direct support.

