

[Manuals.plus](#) /

› [Avital](#) /

› Avital 7352L 2-Way LCD Replacement Remote for Avital 5303L Instruction Manual

Avital 7352L

Avital 7352L 2-Way LCD Replacement Remote

INSTRUCTION MANUAL

Introduction

This manual provides comprehensive instructions for the proper use, setup, and maintenance of your Avital 7352L 2-Way LCD Replacement Remote. This remote is designed as a direct replacement for the Avital 5303L remote start with security system, offering two-way communication and an LCD display for system status feedback.



Figure 1: Avital 7352L 2-Way LCD Replacement Remote. A black and grey two-way LCD remote control with a key ring. The LCD screen displays 'AM 5:21', a padlock icon, a signal icon, a battery level indicator, and a graphic of a red car. Below the screen are two buttons: one with a closed padlock icon (Lock) and one with an open padlock icon (Unlock).

Setup

1. Battery Installation

The Avital 7352L remote requires a specific battery type (typically a CR2032 coin cell, though it's best to check the existing battery or the remote's battery compartment for confirmation). To install or replace the battery:

1. Carefully open the remote casing. This usually involves prying open a seam with a small flat-head screwdriver or a

plastic opening tool.

2. Remove the old battery, noting its orientation (positive (+) side up or down).
3. Insert the new battery with the correct orientation.
4. Snap the remote casing back together securely.

2. Remote Programming/Pairing

The 7352L remote must be programmed to your Avital 5303L system to function correctly. This process typically involves using the system's Valet button. Refer to your Avital 5303L system's main instruction manual for detailed programming steps. A common procedure involves:

1. Locate the Valet button in your vehicle (often under the dash or near the fuse box).
2. Turn the vehicle's ignition to the ON position.
3. Press and release the Valet button a specific number of times (e.g., once for channel 1, twice for channel 2, etc.) to enter programming mode. The system will usually respond with chirps.
4. Press the Lock button on your new 7352L remote. The system should chirp to confirm successful programming.
5. Turn the ignition OFF to exit programming mode.

Note: Exact programming steps may vary. Always consult the primary Avital 5303L system manual or a qualified installer for precise instructions.

Operating Instructions

The Avital 7352L remote provides intuitive control over your vehicle's security and remote start features. The LCD screen offers visual feedback on the system's status.

Remote Buttons:

- **Lock Button (🔒):** Press to arm the security system and lock the vehicle doors. The remote will typically chirp and the LCD will display a locked padlock icon.
- **Unlock Button (🔓):** Press to disarm the security system and unlock the vehicle doors. The remote will chirp and the LCD will display an unlocked padlock icon.
- *Additional buttons/functions may be available depending on your specific 5303L system configuration. Refer to your system's manual for details on remote start, trunk release, or auxiliary functions.*

LCD Display Indicators:

- **Time Display:** Shows the current time (e.g., "AM 5:21").
- **Lock/Unlock Status:** A padlock icon indicates the armed/disarmed status of the vehicle.
- **Signal Strength:** Indicates the strength of the signal between the remote and the vehicle.
- **Battery Level:** Displays the remaining battery life of the remote. Replace batteries when the indicator is low.
- **Vehicle Status Graphic:** A graphic of a car may indicate door open/closed, trunk status, or other system alerts.

Maintenance

Battery Replacement:

When the battery indicator on the LCD shows low power, or if the remote's range decreases significantly, it's time to replace the battery. Follow the "Battery Installation" steps in the Setup section.

Cleaning:

To clean the remote, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap can be used, but ensure no moisture enters the remote's internal components. Do not use harsh chemicals or abrasive cleaners.

Storage:

Store the remote in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding / No communication with vehicle.	• Low or dead battery in remote. • Remote is out of range. • Remote is not programmed to the system. • Interference.	• Replace the remote battery. • Move closer to the vehicle. • Re-program the remote (refer to Setup section). • Move away from sources of strong radio interference.
LCD display is dim or blank.	• Low or dead battery. • LCD damage.	• Replace the remote battery. • If battery replacement does not resolve, the LCD may be damaged and require replacement of the remote.
Buttons feel sticky or unresponsive.	• Dirt or debris under buttons. • Internal component wear.	• Clean the remote thoroughly. • If cleaning does not help, the remote may need replacement.

If troubleshooting steps do not resolve the issue, contact a professional Avital installer or customer support for further assistance.

Specifications

Feature	Detail
Model Number	7352L
Compatibility	Avital 5303L system
Type	2-Way LCD Replacement Remote
Connectivity Technology	Infrared (<i>Note: While listed as Infrared, car remotes typically use RF. This might be a data entry error in the source. Users should rely on the system's actual technology.</i>)
Max Number of Supported Devices	1 (per remote)
Special Feature	Ergonomic design

Feature	Detail
Item Weight	0.01 ounces
Manufacturer	AVITAL

Warranty and Support

For specific warranty information regarding your Avital 7352L replacement remote, please refer to the documentation provided with your original Avital 5303L system or contact the authorized Avital dealer or installer from whom you purchased the product. Warranty terms typically cover manufacturing defects.

For technical support, programming assistance, or service, it is recommended to contact your authorized Avital installer or visit the official Avital website for support resources and contact information. Ensure you have your product model number (7352L) and your Avital 5303L system details ready when seeking support.

You can find more information and potentially contact support via the [Avital Store on Amazon](#).

© 2025 Avital. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question