Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

John Deere 70

John Deere 70 Tractor Operators Manual

Model: 70 | Manual ID: JD-O-OMR2035

1. Introduction

This manual provides essential instructions for the safe and efficient operation, as well as routine maintenance, of your John Deere Model 70 Tractor. It is designed for operators to understand the tractor's controls, capabilities, and basic care requirements. Familiarize yourself with all sections of this manual before operating the tractor to ensure safety and prolong the life of your equipment.
This document is a reproduction of the original manufacturer-issued manual, enhanced for clarity and durability. It includes valuable tractor data such as serial information, measurements, capacities, and specifications, along with super-sharp text and images for improved readability.

2. Safety Information

WARNING: Failure to follow safety instructions can result in serious injury or death.

- Always read and understand this manual before operating the tractor.
- Wear appropriate personal protective equipment (PPE), including safety glasses, hearing protection, and sturdy footwear.
- Ensure all safety guards and shields are in place and functioning correctly before starting the engine.
- Never allow unauthorized personnel to operate the tractor.
- Keep children and bystanders away from the operating area.
- Operate the tractor only on stable, level ground when possible. Exercise extreme caution on slopes.
- Before performing any maintenance or adjustments, always shut off the engine, engage the parking brake, and remove the key.
- Be aware of potential hazards such as moving parts, hot surfaces, and pressurized systems.

3. Setup and Pre-Operation Checks

Before each use, perform the following checks to ensure the tractor is in safe operating condition:

1. **Fluid Levels:** Check engine oil, coolant, hydraulic fluid, and fuel levels. Replenish as needed according to specifications.
2. **Tire Pressure:** Verify that all tires are inflated to the recommended pressure.
3. **Visual Inspection:** Inspect for loose fasteners, damaged hoses, leaks, or any other visible signs of wear or

damage.

4. **Safety Devices:** Confirm that all lights, brakes, and safety interlocks are operational.
5. **Cleanliness:** Remove any debris from the engine compartment, radiator, and operator's platform.




Figure 3.1: Example cover of the John Deere 70 Tractor Operators Manual. This image represents the type of manual being described, providing a visual reference for the document.

4. Operating Instructions

4.1. Starting the Engine

- Ensure the transmission is in neutral and the parking brake is engaged.
- Turn the fuel valve to the "ON" position.
- Engage the choke (if applicable) and set the throttle to a low idle position.
- Insert the key and turn it to the "START" position. Release when the engine starts.
- Allow the engine to warm up for a few minutes before engaging any implements or operating under load.

4.2. Driving and Shifting

- Depress the clutch pedal fully.
- Select the desired gear. Refer to the shift pattern diagram (typically found near the gear lever).
- Slowly release the clutch pedal while gradually increasing engine speed with the throttle.
- To shift gears while moving, depress the clutch, select the new gear, and smoothly re-engage the clutch.

4.3. Stopping the Tractor

- Reduce engine speed to idle.
- Depress the clutch and apply the brakes smoothly.
- Shift the transmission to neutral and engage the parking brake.

- Turn the ignition key to the "OFF" position and remove it.

5. Maintenance

Regular maintenance is crucial for the longevity and reliable performance of your John Deere 70 Tractor. Adhere to the maintenance schedule outlined in this manual.

5.1. Daily/10-Hour Maintenance

- Check engine oil level.
- Check coolant level.
- Check hydraulic fluid level.
- Inspect air cleaner for excessive dirt.
- Lubricate front axle pivot and steering linkages.

5.2. 50-Hour Maintenance

- Change engine oil and filter.
- Check battery electrolyte level and clean terminals.
- Inspect fan belt tension.
- Lubricate all grease fittings.

5.3. Seasonal/Annual Maintenance

- Replace fuel filters.
- Flush and refill cooling system.
- Change hydraulic fluid and filter.
- Inspect and adjust brakes.
- Check wheel bearings.

6. Troubleshooting

This section provides solutions for common operational issues. For complex problems, consult a qualified service technician.

Problem	Possible Cause	Solution
Engine Fails to Start	No fuel, dead battery, faulty ignition switch, clogged fuel filter.	Check fuel level, charge/replace battery, inspect ignition system, replace fuel filter.
Loss of Power	Clogged air filter, incorrect fuel mixture, low engine oil, worn spark plugs.	Clean/replace air filter, check carburetor/fuel system, verify oil level, replace spark plugs.
Unusual Noises	Loose components, worn bearings, low fluid levels, engine malfunction.	Inspect for loose parts, check fluid levels, consult a technician for internal engine issues.
Hydraulic System Malfunction	Low hydraulic fluid, clogged filter, faulty pump, air in system.	Check/add fluid, replace filter, bleed air from system, inspect pump.

7. Specifications

The following specifications are typical for the John Deere Model 70 Tractor. Refer to your specific manual for exact figures, which may vary based on year of manufacture and specific configurations.

- **Engine Type:** Two-cylinder, horizontal, gasoline/diesel (depending on variant)
- **Horsepower (PTO):** Approximately 45-50 HP
- **Fuel Capacity:** Approximately 18-20 US gallons
- **Cooling System Capacity:** Approximately 6-7 US gallons
- **Engine Oil Capacity:** Approximately 6-7 US quarts
- **Transmission:** Manual, 6 forward, 1 reverse speed
- **Weight:** Approximately 6,000 - 7,000 lbs (without ballast)
- **Dimensions (Approximate):**
  - Length: 130-140 inches
  - Width: 70-80 inches
  - Height: 70-80 inches
- **Electrical System:** 6-volt or 12-volt (depending on variant)

For detailed serial number information, specific measurements, and precise capacities, consult the dedicated sections within your physical operators manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01BRHX600

More documents and user manuals: **https://manuals.plus/**