John Deere 165 Backhoe Attachment

John Deere 165 Backhoe Attachment Parts Manual

Comprehensive Guide for Part Identification and Ordering

Introduction to Your Parts Manual

This document serves as a comprehensive parts manual for the John Deere 165 Backhoe Attachment. It is a digitally enhanced reproduction of the original manufacturer-issued manual, designed to assist users in identifying, assembling, disassembling, and ordering replacement parts for their equipment.

The manual is structured to provide clear, detailed information through exploded views and descriptive text, ensuring accurate part identification and efficient maintenance or repair processes.

Manual Features and Enhancements

This parts manual incorporates several enhancements to improve usability and durability:

- **Comb-binding:** Provides increased durability and allows the manual to lay flat for ease of use during work.
- **Updated Information and Errata:** Includes corrections and additional information not available at the time of the original printing.
- **Super-sharp Text and Images:** High-resolution scans ensure clarity and readability of all diagrams and text.

These features are designed to provide a superior reference tool for all your John Deere 165 Backhoe Attachment part needs.

Understanding Manual Types

It is important to distinguish between different types of manuals for proper equipment management:

- **Parts Manual (PTS):** This manual, which you are currently viewing, provides exploded views of all parts, detailing assembly and disassembly. It includes a guide for ordering parts. It is essential for identifying components and their relationships.
- **Service Manual (SVC):** Also known as a shop or repair manual, this guide provides instructions on how to take the equipment apart, fix it, and reassemble it. It includes detailed information such as specifications, torques, and ranges.
- **Operators Manual (OPT):** This manual provides instructions for operating and maintaining the equipment, including shift patterns, fluid capacities, and adjustment procedures.

For comprehensive repair and maintenance, a combination of these manuals may be required. This Parts Manual specifically focuses on component identification and ordering.

Using Your Parts Manual for Identification and Ordering

To effectively use this parts manual:

1. **Locate the Relevant Section:** Navigate through the manual to find the section pertaining to the specific component or system you are working on.
2. **Examine Exploded Views:** Study the exploded diagrams which illustrate all individual parts and their arrangement within an assembly. Each part is typically numbered.
3. **Identify Part Numbers:** Cross-reference the numbered parts in the diagram with the accompanying parts list to find the correct part number and description.
4. **Order Parts:** Use the identified part numbers when ordering replacements from authorized John Deere dealers or suppliers.

Accurate part identification is crucial for ensuring proper fit and function, and for maintaining the integrity of your John Deere 165 Backhoe Attachment.

Product Data and Specifications

This manual contains valuable tractor data pertinent to the John Deere 165 Backhoe Attachment. This information may include:

- Serial number information
- Key measurements and dimensions
- Fluid capacities (e.g., hydraulic fluid)
- General specifications of the backhoe attachment


Refer to the relevant sections within the manual for specific data points that aid in maintenance, repair, and general understanding of your equipment.

Manual Specifications

Details regarding this specific manual edition:

- **ASIN:** B01BRR5VAS
- **Publication Date:** January 1, 2015
- **Print Length:** 20 pages

Manual Cover Image



This image displays the front cover of the John Deere 165 Backhoe Attachment Parts Manual, featuring the brand logo and manual title.

For further assistance, please consult an authorized John Deere service center.